


Figure 11.31 Factors for blower electric power conservation



(1) Reduce the operating time.

Too early start of blowers before the factory operation starts, or very late stop of blowers after close of the factory is often seen in factories. Also, blowers in operation, although the entire factory is at a stop because of some troubles, are often seen in general factories. Since such useless operation of blowers is a significant adverse factor for energy conservation, it is necessary for the factory manager to give special attention.

The most direct method to eliminate this useless operation of blower is ON-OFF operation of blowers. Countermeasures and precautions for prevention of general idle operation for motors were described in the section for Motors. However, blowers generally have great  $GD^2$  and special precautions for ON-OFF operation are as follows:

A) Check the motor for mechanical and electric life.

When new equipment is established, the daily number of times for start-up as the conditions is indicated to the manufacture and the equipment fit for the condition is ordered. Therefore, there will be no problem. However, when the blower being almost continuously operated at present is going to be changed to operate to this system, it is necessary to carefully study problems concerning mechanical strength and heat, etc. of the motor caused by frequent start-up.

B) Voltage drop of power source

Since the blower has been started while other loads are at a stop, voltage drop to the starting current has not become a problem. However, when ON and OFF is repeated while other loads are in operation, troubles by voltage drop of power source may occur.

Electric machinery and apparatus are generally designed to perform their functions even at a voltage drop of about 10% and they are likely to cause trouble at a voltage drop of more than that. Therefore, in this case, appropriate countermeasures such as reactor starting or adoption of VVVF will be required.

C) Life of starting equipment






Reactors for start-up and starting compensator are generally of a short-time rating and when they are changed to very frequent use, the temperature of winding in these equipment will increase, possibly resulting in insulation deterioration and a burning accident. Therefore, for very frequent use, it is necessary to carefully study the temperature rise beforehand.

D) Others

Precautions other than the foregoing are for generated heat for power source cable and life of switches, etc.

Table 11.19 and Table 11.20 show comparison of various starting systems when an induction motor is used for a blower, and general life of switches respectively.

**Table 11.19 Comparison of Various Starting Systems**

Starting system	Composition diagram	Starting current	Starting torque	Voltage when starting	Electromagnetic force	Armature heating capacity	Problems when starting at multi-frequency
Direct starting	 Coupling	100 (6 to 7 times full-load current)	100 (About 150% on rated torque)	100	100 (In proportion to square of current)	$100 \left( \frac{GD^2 \cdot N_0^2}{730} [J] \right)$	Power voltage drop, Motor life, Breaker life
Reactor starting	 Reactor	50, 65, 80	25, 42, 64	50, 65, 80 (Standard tap)	25, 42, 64	100	Reactor heating capacity, motor life, breaker life
Closed circuit transition auto-transformer starting	 Autotransformer	25, 42, 64	25, 42, 64	50, 65, 80 (Standard tap)	25, 42, 64	100	Starting compensator heating capacity, motor life, breaker life
VVVF Starting		17 or less (Any value below rated current)	70 or less (Any value below rated torque)	0 - 100 (In proportion to speed)	2 - 3 (Large when there is inrush current)	Hardly any	Transient torque (when switched from VVVF to main power source), inrush current (when switched from VVVF to main power source), effects from higher harmonic (motor temperature rise, occurrence of shaft voltage, resonance of pulsating torque and shaft torsion, surging voltage when commutating)
Secondary side resistor starting (limited to wound-rotor type)	 External resistance	18 - 40 (Optional)	80 - 200 (Optional)	100	3 - 16	Hardly any (Consumed by external resistance)	External resistance heating capacity, breaker life, slip ring heating capacity, mechanical life of brush lifting mechanisms, life of motor for brush lifting

(Note) (1) Value at direct starting is regarded as 100%.

(2) Starting torque is generated torque of motor and shall be (Starting torque + Stalling torque)/2.

**Table 11.20 Life of Switch (when not repaired)**

	Mechanical life	Electrical life (rated current opening and closing)
Oil breaker	10,000 times	2,000 - 5,000 times
Vacuum breaker	10,000 times	10,000 times
Gas (SF6) breaker	10,000 times	10,000 times
	Possible also for 50,000 times	
High voltage electromagnetic contactor	5 million times (Class 1)	500 thousand times (Class 1)

(2) Adopt high-efficiency equipment

Remarkable points are:

- a. Efficiency of blowers
- b. Efficiency of power transmission equipment
- c. Efficiency of motors.

Especially for blowers, it is necessary to select the optimum type according to fluctuation range for air flow, pressure and temperature.

Recently, new products with higher efficiency by improving shape of blade, even of the same type, have been developed.

(3) Reduce air power.

As described in the section for compressors, lowering the air flow, pressure and intake temperature reduces the required power. In the case of a blower, it is generally used with an excessive air flow. For example, when dust collecting effect is sufficient at reduced air flow, the blower is operated at full capacity because the proper air flow is not decided. Also, when a blower for cooling has no problems, even if the air flow is reduced according to the season, it is operated at full capacity. These examples are often seen.

That is, to reduce the air flow, it is necessary to study the following:

- a. What is the proper air flow?
- b. To acquire this proper air flow, what is the most efficient method?
- c. Does not air leak from piping and at the place for use?

There are two methods to reduce the air flow; fixed type, and variable type of rotation numbers.

A) Fixed types

Table 11.21 shows method for fixed types.


**Table 11.21 Method to Reduce Blow Air Capacity (Fixed Type)**

Main classification	Sub-classification
Reduction in blowing capacity	When blowers are operated, reduce the number. Replace blower. Blower impellers (replace or cut)
Damper, vane opening adjustment	Reducing damper opening Reducing vane opening
Change in rotating speed	Replace motor. Replace belt-driven pulley. Insert or replace reducer.

a. Reduction in units

In case two blowers with the same specifications are operated in parallel, when the required air flow is changed from  $Q_1$  to  $1/2$  of  $Q_1$  as shown in Fig. 11.32, it is necessary to change the resistance curve of the piping system including damper from (3) to (5). The required power at this point is in proportion to  $P_2 \times Q_2$ . On the other hand, when the operated blowers are reduced to one unit and the resistance curve is changed to (4) the required power at this point is in proportion to  $P_1 \times Q_2$ . That is, the difference in blowing power between two units and one unit operation is in proportion to  $P_2 \times Q_2 - P_1 \times Q_2 = Q_2 \times (P_2 - P_1)$  and it gives a great energy conservation effect. Since, in fact, the difference in efficiency is added to this, this effect will be greater.

Figure 11.32 Performance Curve during Parallel Operation



- (1) Static pressure curve when two units are operating
- (2) Static pressure curve when one unit is operating
- (3) Resistance curve to obtain required air capacity,  $Q_1$   
(When two units are operating)
- (4) Resistance curve to obtain required air capacity,  $Q_2$   
(When one unit is operating)
- (5) Resistance curve to obtain required air capacity,  $Q_2$   
(When two units are operating)

b. Replacement of impellers

When the blower output becomes too high and the damper is exceedingly narrowed down after the amount of air used is reduced, or when the gas specific weight becomes higher, the wind pressure is too high and the motor is overloaded, it is desirable to replace the impellers.

Assuming the diameter of impeller as  $D$ , the air flow as  $Q$ , the pressure as  $P$  and the axial power as  $L$ , the following relations generally exist.

$$\begin{aligned}
 Q &\propto D^2 \\
 P &\propto D^2 \dots\dots\dots (5) \\
 L &\propto D^4
 \end{aligned}$$

Accordingly, diminishing the diameter of the impeller as required will bring very great energy conservation. In this case, it is of course necessary after working to adjust the balance. If there is a large amount of working in the case of multi-stage block, the blade in the 1st stage or 2nd stage may be removed. Adjustment of blowing capacity by this method is limited to about 20%.

c. Damper, vane opening adjustment

The damper is installed vertically to the air duct shaft direction to change the opening and when installed on the outlet side, the opening changes the resistance curve and, when installed on the inlet side, the opening changes the static pressure curve.

The vane means a movable blade which is installed at the inlet of the blower and provides the gas entering the blower impeller with swirl in the direction of rotation. Accordingly, adjusting the vane changes the wind pressure-air flow curve.

Special features of this method are shown in Table 11.22, in which the rotating speed control method is specified for comparison.

Table 11.22 Damper, Vane Opening Adjustment

Method	Discharge damper opening adjustment	Intake damper opening adjustment (discharge side piping)	Intake vane control	Changing the rotating speed
Principle	Change blower resistance curve by intentionally increasing resistance of the piping system.	Since damper resistance is provided on intake side, it serves as a negative pressure and pressure curve slightly changes. Axial power curve also changes slightly.	Reduce the impeller work done by intentionally changing gas flowing angle against blower impellers, thus changing the pressure and power curves at the same time.	Air capacity is in proportion to the rotating speed, the pressure to square of the rotating speed, and the axial power to cube of the rotating speed.
Diagram of principle				
	When damper is closed, resistance increases and operating point changes from $(P_1, L_1, Q_1)$ to $(P_2, L_2, Q_2)$ . Note: Operating point is a point of intersection of pressure and resistance curves.	When damper is closed, pressure curve falls and operating point changes from $(P_1, L_1, Q_1)$ to $(P_2, L_2, Q_2)$ .	Reducing vane lowers pressure and axial power curves. Operating point changes from $(P_1, L_1, Q_1)$ to $(P_2, L_2, Q_2)$ . Reduction in axial power is far larger than damper opening adjustment.	Changing the rotating speed from $N_1$ to $N_2$ shifts the pressure and axial power curves from (1) to (2), and the operating point from $(P_1, L_1, Q_1)$ to $(P_2, L_2, Q_2)$ .
Special features	<ol style="list-style-type: none"> <li>1) Surging area is wide and effective air capacity control cannot be performed.</li> <li>2) Axial power does not lower much even in low air capacity area.</li> </ol>	<ol style="list-style-type: none"> <li>1) Surging area is narrower than for discharge damper.</li> <li>2) Axial power lowers almost in proportion to air capacity.</li> </ol>	<ol style="list-style-type: none"> <li>1) Same as at left.</li> <li>2) Axial power lowers almost in proportion to air capacity and tends to lower much more than the intake damper.</li> </ol>	Axial power lowers most and this is the best method for electric power conservation.

d. Change in rotating speed (change of motor or diameter of pulley)

Assuming the rotating speed of blower as N,

$$\begin{aligned} Q &\propto N \\ P &\propto N^2 \dots\dots\dots (6) \\ L &\propto N^3 \end{aligned}$$

Since there is the above relation, when it is possible to replace with a motor with lower rotating speed, energy can be greatly saved. However, in this case, once it is changed, it cannot be easily returned to the original position unlike the damper adjustment. Therefore, carefully investigate the resistance curve of load, etc. and be careful so that the air flow is not insufficient after replacement. Also, in the case of belt-drive, it is an effective method to lower the rotating speed by changing the diameter of the pulley.

B) Variable types

In variable control systems of air flow, there are various systems as shown in Table 11.23, of which we will describe the eddy current joint control and Scherbius control.


**Table 11.23 Method to Control Air Flow (Variable System)**

Discharge damper control (Variable)	Intake damper control (Variable)
Intake vane control (Variable)	Change in number of poles
Eddy current coupling control	Secondary resistance control
VVVF control	Scherbius control
	Others

Fig. 11.33 shows motor input (%) of various variable air flow control methods specified in Table 11.23.



**Figure 11.33 Comparison of Blower Motor's Input**



## 11.6 Pump

As electric power consumed by pumps in various facilities is huge, improvement of their efficiency is one of the most important concerns for electric power conservation. So far the head of pumps was designed to allow considerable excess on account of the secular increase of line resistance of piping facilities. Also, many of these pumps have excess capacity in prospect of future increase of supply or drainage quantity, so the flow rate is adjusted by valves.

In these cases, while pump efficiency itself is high, efficiency of the pump facilities as a whole is low, resulting in wasteful consumption of electric power.


### 11.6.1 Type and construction of pumps

Pumps are classified into turbo pumps, positive displacement pumps and other pumps, as shown in Table 11.24. The turbo pump rotates the impeller in the casing to give fluid energy. Centrifugal pumps, mixed flow pumps and axial flow pumps belong to this category. As there is no seal between the impeller and casing in the pump body, the discharge varies largely by pressure.

Whereas the positive displacement pump is that which delivers fluid from the suction side to the discharge side by means of displacement or change of enclosed space which is generated between the casing and inscribed movable members. Reciprocating pumps and rotary pumps belong to this category. As there is a seal line provided between the casing and the movable members, keeping leakage at a minimum, discharge is hardly affected even when the discharge pressure is varied.

Other pumps include jet pumps and air lift pumps, both of which are used for pumping of water.

**Table 11.24 General Classification of Pumps**



However, as pumps, turbo pumps are used for the most. So, the following descriptions mainly refer to turbo pumps:

(1) Centrifugal pump

In this type of pumps, flow discharged from the impeller is mainly within a plane perpendicular to the pump shaft, and there are volute pumps which give water a velocity energy by centrifugal force of the impeller, and convert it to a pressure energy in the volute chamber, and diffuser pumps which convert the velocity energy to a pressure energy by means of the guide vane type diffuser. The specific velocity of pump  $N_s$  is 100 - 700.

(2) Mixed flow pump

In this type of pumps, velocity energy and pressure energy is given to water by centrifugal force of the impeller and lift of the vane, and the water flows in from the axial direction to the impeller and discharged to a conical plane having the center line of the pump shaft as its axis. Generally, these pumps have a guide vane type diffuser on the discharge side of the impeller, but some pumps have a direct volute type casing. The specific velocity of pump  $N_s$  is 700 - 1,200.

(3) Axial flow pump

The propeller shaped impeller gives water a velocity energy and pressure energy by lift of the vane, and the water flows in from the axial direction to the impeller and discharged into a cylinder which is provided coaxially with the pump shaft. The specific velocity of pump  $N_s$  is 1,200 - 2,000.

Shapes of these pumps are shown in Figure 11.34.

Figure 11.34 Pump Shapes

Type		Shape
Centrifugal pump	Volute pump	<p>Discharge opening Impeller Volute chamber</p>
	Diffuser pump	<p>Discharge opening guide vane Impeller Volute chamber</p>
Mixed flow pump	Volute pump	<p>Impeller Volute chamber</p>
	Mixed flow pump	<p>Impeller Guide vane X-X section</p>
Axial flow pump		<p>Impeller Guide vane X-X section</p>

## 11.6.2 Characteristic curves and operating points of pumps

### (1) Specific velocity

Specification of a pump is decided basically by discharge  $Q$  ( $\text{m}^3/\text{min}$ ), total head  $H$  (m) and rotating speed  $N$  (rpm).  $Q$  and  $H$  are decided by purpose and  $N$  by selection of suitable model. For pumps, generally the specific velocity is understood as a guideline for characteristic classification. The specific velocity  $N_s$  is a value set to be constant for impellers with similar shape, irrespective of the size and rotational speed of each pump, and is used as the model number of impellers.

Specific velocity  $N_s$  is determined by the following formula:

$$N_s = N \cdot Q^{1/2} / H^{3/4} \dots\dots\dots (1)$$

$N$ : Revolution/min

$Q$ : Discharge at max. efficiency point ( $\text{m}^3/\text{min}$ ) (Provided,  $1/2Q$  for double suction)


$H$ : Total head at max. efficiency point (m)

(Provided, total head of each stage for multistage pumps)

As it is clear from formula (1), when  $N_s$  is small, this means a pump with small flow rate and high head, and when  $N_s$  is large, this means a pump with large flow rate and low head.

Figure 11.35 shows the relationship of  $N_s$  and impeller shape.

Figure 11.35  $N_s$  and Impeller Shape



(2) Operating point of pump


Pumps are not always operated under constantly fixed conditions. However, in each operating state, stable operation is performed at that point of time. This indicates that the state of pipe connected before and after a pump, and of the whole pump system including the water level condition at the suction valve and discharge valve are in a balanced state. Factors that determine the operating point are pressure loss of the line itself, the throttling of valves in the line, and difference of water level between the suction valve and discharge valve, etc. which are not related to the pump characteristics.

Generally, performance of volute pumps is shown in Figure 11.36.

Each pump uses a feed pipe to supply water, and the resistance increases almost proportionately to the velocity squared inside the pipe. A resistance curve  $R_1$  of Figure 11-36 is the addition of the line resistance of the feed pipe to the actual head of the pump and a pressure required at the end of the feed pipe, and the pump operates with the flow rate  $Q_1$  and head  $H_1$  at a point of intersection  $A_1$  of this resistance curve  $R_1$  and performance curve of the pump. In this case, the axial power of pump is a point of intersection  $L_1$  of a vertical line drawn from the point  $A_1$  with the power curve, and the pumping efficiency is a point of intersection  $E_1$  of the same vertical line with the efficiency curve.

Admitting that the actual head and the pressure at the end of the feed pipe are necessary, electric power can be saved by minimizing the resistance of the feed pipe, since the total head  $H_1$  of the pump can be reduced accordingly.

Figure 11.36 Performance Curve of Pump



### 11.6.3 Necessary power and pump drive motor

(1) Necessary power

The theoretical power of a pump is given by the following formula:

$$P = 0.163 \cdot \gamma \cdot Q \cdot H \text{ [kW]} \dots\dots\dots (2)$$

$\gamma$ : Weight of fluid per capacity (kg/L)

$Q$ : Discharge of the pump (m<sup>3</sup>/min)

$H$ : Total head of the pump (m)

An output (axial power) which is required of the motor is given by the following formula:


$$P = 0.163 \cdot \gamma \cdot Q \cdot H \frac{100}{\eta} (1 + \alpha) \dots\dots\dots (3)$$

$\eta$ : Efficiency of the pump (%)

$\alpha$ : Tolerance

The approximate values of  $\eta$  and  $\alpha$  are shown in Figure 11.37 and Table 11.25.

Figure 11.37 Standard Efficiency General Purpose Pumps



**Table 11.25 Tolerance of Pumps**

Pump type	Tolerance (%)	
	Fluctuation of head is relatively small.	Fluctuation of head is relatively large.
Volute pump { High head Medium, low head	15	20
	10	15
Mixed flow pump	15	20
Axial flow pump	20	25

(2) Pump drive motor

In selecting the motor, it is necessary to grasp the torque characteristics of the pump at start and during acceleration, as well as the operation system. To start a pump from the stationary state, the motor should have a power exceeding the static friction torque of the bearing, but when the pump is rotating, a dynamic friction which is smaller than the static friction is generated, and a load torque is generated as the pump is accelerated.

Relationship of rotating speed and load torque of each pump is different depending on the pump type and opening state of the discharge valve. In particular, it should be noted that the starting-torque characteristic differs according to opening state of the discharge valve.

Axial power of the pump when the discharge valve is closed shows a minimum for models with 650 or less of  $N_s$ , and exceeds 100% of rated load torque and even reaches 200% for models with 650 and over of  $N_s$ . For the centrifugal pump of which  $N_s$  is 100 ~ 700, the starting torque is small when the valve is closed at start, and for the mixed flow pump of which  $N_s$  is 700 ~ 1,200, the starting torque is 150% ~ 200% when the discharge valve is closed.

Therefore, for the centrifugal pump, start from the state with the discharge valve closed, and for the mixed flow pump and axial flow pump which are not operable with the valve closed, special care is needed to start. To start axial flow pump small capacities, a method in which the discharge valve closes in the beginning and opens with the increase of rotating speed up to 100% torque at the rated speed is adopted.

For the case of large-capacity axial flow pumps, sometimes a movable vane is adopted (partly for adjustment of the flow rate) to allow start at 100% torque with the discharge valve closed. Therefore, the pump torque at the rated speed during start may be considered to be 40% ~ 80% for centrifugal pumps, and 100% for mixed flow pumps and axial flow pumps.

Additionally, vertical type pumps have large static friction due to the thrust bearing, with some reaching up to 40% torque.

The above may be summarized as shown in Figure 11.38.

Each pump drive motor should be selected by considering the given start conditions. Generally, squirrel cage motors are often used, and while inconveniences such as start delay do not occur in the case of direct-input start, start delay may occur due to torque drop during acceleration in the case of start under reduced voltage such as reactor start.

**Figure 11.38 Start Characteristics of Pumps**

Pump type		Start torque characteristics	GD <sup>2</sup>
Centrifugal pump	$N_s \leq 300$		Small
	$300 < N_s \leq 450$		Small
Mixed flow pump Axial flow pump			Small

However, when wound-rotor induction motors are used, start jam does not occur. In the case of synchronous motors, sometimes almost 100% pull-in torque is required.



### 11.6.4 Resistance of feed pipe

Generally, resistance of feed pipes is calculated by Darcy's formula (formula (4)) when the feed pipe is rather short.

$$H_f = \lambda \cdot \frac{L}{D} \cdot \frac{v^2}{2g} \dots\dots\dots (4)$$

$H_f$  : Resistance of feed pipe (m)

$\lambda$  : Loss factor

$L$  : Length of feed pipe (m)


$D$  : Inside diameter of pipe (m)

$v$  : Velocity in pipe (m<sup>3</sup>/s)

$g$  : Gravity acceleration 9.8 m/s<sup>2</sup>

The value of  $\lambda$  is normally set as  $\lambda = 0.02 + 1/2,000D$ , which is multiplied by a modulus determined by the smoothness of the internal face of the feed pipe. For this calculation, the loss factor by Colebrook's experimental formula, as shown in Figure 11.39, will facilitate the procedure.


**Figure 11.39  $\lambda$  Values by Colebrook**



### 11.6.5 Pump performance when the outside diameter is worked upon

Volute pumps, like the frame number of motors, fabricate impellers according to the pump specification, within the ranges of a certain flow rate and head as a single barrel. Therefore, in cases where specifications are prepared in prospect of the future but have too much leeway performance for the time being as previously mentioned, it is economical to first fabricate the impeller according to a broken line in Figure 11.40, and then make a new one when the flow rate later becomes insufficient due to increase of line resistance.

**Figure 11.40 Pump Performance and Resistance Curve**



Also, when impeller is rebuilt by increasing the size of the feed pipe to shift the resistance curve from  $R_1$  to  $R_2$ , with the same actual head, it allows the operating point of the pump to change from  $A_1$  to  $A_3$ , thus saving electric power by  $(L_1 - L_2)$ .

Change of performance when the outside diameter  $D_1$  of the impeller of an operating pump is worked to  $D_2$  as shown in Figure 11.41 is illustrated in Figure 11.42. When the outside diameter of the impeller is worked from  $D_1$  to  $D_2$  in Figure 11.41, the flow rate, head and power are obtained by equations (5), (6) and (7), respectively.

**Figure 11.41 Working the Impeller of Its Outside Diameter**





Figure 11.42 Change of Performance by Working on Impeller Diameter



$$\frac{Q_2}{Q_1} = \left(\frac{D_2}{D_1}\right)^2 \dots\dots\dots (5)$$

$$\frac{H_2}{H_1} = \left(\frac{D_2}{D_1}\right)^2 \dots\dots\dots (6)$$

$$\frac{L_2}{L_1} = \left(\frac{D_2}{D_1}\right)^4 \dots\dots\dots (7)$$

Connect an optional point A, on the Q-H curve of outside diameter D1, to the origin with a line, and obtain a point B from  $H_2 = (D_2/D_1)^2 \times H_1$ , or  $Q_2 = (D_2/D_1)^2 \times Q_1$ . Determine several points for the performance of outside diameter D2 in the same manner, and prepare the Q-H curve of outside diameter D2 by connecting these points. Likewise, calculate the power from  $L_2 = (D_2/D_1)^4 \times L_1$ , and obtain a point L2 on the vertical line BQ2. Determine several points in the same manner, and prepare the power curve by connecting these points.

- Points to be noted on working the diameter of the impeller
  - 1) As the impeller is balanced during fabrication, it should be re-balanced after worked.
  - 2) For cases when the work ratio of the outside diameter of the impeller,  $(D_1 - D_2)/D_1 \times 100\%$ , exceeds 20%, the equations (5), (6) and (7) will sometimes not apply, not enabling pumping.
  - 3) Note that working on the outside diameter is not necessarily available depending on the materials of the impeller, such as pressed stainless steel.

### 11.6.6 Rotating speed control of pump

Rotating speed control may be adopted for purposes as process control, flow rate control of pumps, or energy conservation. As methods of rotating speed control for pump drive motors, there are various methods as described in 11.3, (3). To perform rotating speed control, relations of the equations (8), (9), (10) are established by supposing the rotating speed of the pump to be  $N_0$  and  $N_1$ , the flow rate  $Q_0$  and  $Q_1$ , the pump head  $H_0$  and  $H_1$ , and the axial force  $L_0$  and  $L_1$ :

$$\frac{Q_1}{Q_0} = \frac{N_1}{N_0} \dots\dots\dots (8)$$

$$\frac{H_1}{H_0} = \left(\frac{N_1}{N_0}\right)^2 \dots\dots\dots (9)$$

$$\frac{L_1}{L_0} = \left(\frac{N_1}{N_0}\right)^3 \dots\dots\dots (10)$$

Figure 11.43 shows changes in characteristics of the pump when the rotating speed is changed, where the flow rate, head and axial power are changed in a manner so that the expressions (8), (9) and (10) show their relations to the rotating speed. When the resistance curve of the feed pipe is  $R_3$  in Figure 11.43, and when the rotating speed of the pump is changed from  $N_0$  to  $N_1$  and  $N_2$ , the operating point of the pump is changed from  $A_3$  to  $B_3$  and  $C_3$ , and the flow rate from  $Q_3$  to  $Q_2$  and  $Q_1$ .

If the rotating speed of the pump is left as  $N_1$  when the necessary flow rate is  $Q_1$ , the resistance curve must be changed from  $R_3$  to  $R_1$  by throttling the valve, when the operating point of the pump is  $A_1$  and the axial power is  $L'_1$ . When the rotating speed is changed to  $N_2$ , it will change the operating point to  $C_3$  and axial power to  $L_1$  while leaving the resistance curve as  $R_3$ . Therefore, a considerable amount of electric power can be saved.

Figure 11.43 Changes of Characteristics by Change of Rotational Speed





Figure 11.44 Difference of Axial Power by Actual Head Power



Provided, however, it should be noted that, as the above description applies only when the actual head is small like  $H_A$  and the line resistance is large as shown in Figure 11.44, rotating speed would not result in a significant electric power conservation if made when the line resistance is small and the actual head is  $H_B$ .

- Method to determine rotating speed to change flow rate from  $Q_0$  to  $Q_2$

Suppose that the pump is operating on the operating point A of Figure 11.45. The resistance curve can be determined from the actual head  $H_A$  and the total head  $H_0$ . On the resistance curve, the total head is  $H_2$  and operating point C when the discharge is  $Q_2$ .

A curve CB is a quadratic curve passing the origin, obtained as follows:

Supposing the quadratic curve to be,

$$H = a \times Q^2$$

the modulus  $a$  is obtained from the point C,

$$a = H_2/Q_2^2$$

When factors of Figure 11.45 are substituted,


$$a = 22.5/(1.5)^2 = 10$$

Therefore, curve CB is expressed as,

$$H = 10 \times Q^2$$

The point of intersection of this curve with the pump performance curve at the rotating speed  $N_1$  would be point B. From the figure, the discharge  $Q_1 = 1.7 \text{ m}^3/\text{min}$ , total head  $H_1 = 28.2 \text{ m}$ , and axial power  $L_1 = 10.8 \text{ kW}$ .

**Figure 11.45 Change of Pump Performance by Rotational Speed**



To determine a rotating speed of the pump for reaching the operating point C required by the facility, it is calculated by equation (9), as,

$$N_2 = \frac{N_1}{(H_1/H_2)^{1/2}} = \frac{1,450}{(28.2/22.5)^{1/2}} = 1,295 \text{ rpm}$$

Here, the axial power is obtained from equation (10), as


$$L_2 = L_1 \times \left( \frac{N_2}{N_1} \right)^3 = 10.8 \times \left( \frac{1,295}{1,450} \right)^3 = 7.7 \text{ kW}$$

As the axial power is 11.0 kW at point A of Figure 11.45, it is reduced to 7.7 kW by changing the rotating speed.

### 11.6.7 Pump unit control

Even if flow control is performed by operating the valve of a large-capacity pump when the required volume of water varies seasonally or by time, or by rotating speed control, the max. efficiency point of the pump is in a zone with large flow rate, and the efficiency is low in zones with small flow rates. In such a case as shown in Figure 11.46, the number of pumps may be made multiple to perform parallel operation for cases requiring a large volume of water and use only one pump in cases requiring a small volume of water, so that operation can always be performed in zones with high pump efficiency, resulting in electric power conservation. However, it is necessary to make sure of the operating point in order to avoid overload of motor.

Figure 11.46 Parallel Operation Characteristics of Pump



If the actual head is  $H_B$  and the resistance curve of the feed pipe is  $R_2$ , the flow rate is  $Q_3$  when 3 pumps are in operation. Therefore, if only one pump is used, the pump must be operated at the flow rate  $Q_3/3$ . However, since the flow rate is smaller and resistance of the feed pipe smaller when only one pump is used, the operating point of the pump is B, consequently resulting in a flow rate  $Q_1$  larger than  $Q_3/3$ . Therefore, study should be made so the motor is free of overloading even when the pump is operated at the flow rate  $Q_1$ .

Also, for pumps with small actual head  $H_A$ , and the resistance curve of the feed pipe  $R_1$ , the flow rate of a pump, when only one pump is to be operated, will exceed the max. flow rate of the pump, requiring an additional resistance by throttling the discharge valve.

### 11.6.8 Electric power conservation measures of pump

Since both gas and liquid are fluid and the basic theories are the same, the method which was discussed about the blower thus applies similarly. However, an exception is that the valve control is performed only on the discharge side and not on the suction side. Valve control on the discharge side is the worst method for power conservation purpose.

The electric power saving flow of pumps is shown in Figure 11.47.


The 3 factors of electric power conservation of pumps are (1) reduction of required flow rate, (2) reduction of pipe resistance, and (3) efficient flow rate control.

#### (1) Reduction of required flow rate

The first to be done is to reduce the required flow rate. Pumps should be those that meet the required flow rate, however actually in most cases the pump performance is larger than the actually required head and flow rate, because of the following reasons.

- i) In many cases pumps having considerable excess capacity in their total head are installed in prospect of an increase of secular loss of piping.
- ii) Many facilities are installed with excess capacity of flow rate in prospect of a future increase of supply and drainage quantities.

Figure 11.47 Electric Power Saving Flow of Pumps





iii) Because of the current JIS test standard which states that the actual flow rate-head curve should not be below the prescribed head by means of the flow rate as decided by pump specifications, most pumps have capacities above the flow rate and head as set by the specifications.

(2) Reduction of pipe resistance

Although pipe resistance is mostly fixed at construction and rebuilding of existing facilities is difficult, factors which form the resistance may be described as follows:

i) Friction loss of direct pipe

According to Darcy's formula (formula (4)), friction loss of a direct pipe is proportionate to (resistance modulus of pipe)  $\times$  (velocity)<sup>2</sup>  $\times$  (pipe length)/(pipe diameter).

ii) Loss at piping elements

Suction port, bends, acute expanded portions, acute shrunk portions, orifices, diverting points, confluent points, effluent outlet, etc.

iii) Loss at valves

In short, piping should be arranged closest to the direct pipe with large diameter and short length, excluding unnecessary accessories from the piping for practical purposes in order to reduce the resistance.

(3) Efficient flow rate control

When the required flow rate is reduceable, methods of electric power conservation of pumps are discussed as follows:

i) Intermittent operation

When water use is clearly distinct between periods of need and no need, pumps may be stopped during unnecessary periods.

That is, pumps may be run by intermittent operation. It is a simple method, but turning on and off within short cycles too frequently should be refrained to avoid water-hammer effects.

ii) Pump unit control

A method varying the number of pumps according to the fluctuation of flow rate aims at reducing the axial power of pumps so they can be operated with relatively favorable efficiency meeting the fluctuation range of flow rate.

The control system is simple and risks can be avoided by increasing the number of pumps, but discharge changes by stages. Therefore, when the resistance curve is steep, there exist many problems such as discharge does not increase so much even when there are more pumps, and so on.

iii) Rotating speed control

In spite of high initial investment cost, this method offers several such advantages as great reduction in electric power costs and smooth pump operation even at low flow rate. This method is effective for pumps with large capacities, and for cases with large head fluctuation ranges.

iv) Replacing pumps

Replacing pumps with those meeting the required flow rate when the discharge load is stable but the flow rate has dropped lower than before, or when the flow rate fluctuates seasonally, is simple method but has some problems such that flow control is not available, and it takes much time for replacement.

Additionally, sometimes only motors are replaced for the purpose of reducing the flow rate by changing the revolution.

v) Replacing the impeller

It is applicable for volute pumps operated under fixed discharge load, and afford efficient changes of pump performance. However, disassembling and assembling of pumps are necessary.

## 11.7 Lighting

### 11.7.1 Factory lighting

#### (1) Purpose of factory lighting

Good lighting facilitates various visual operations and has the following effects:

##### A) Improved operation efficiency

Proper illuminance diminishes nerve strain, reduces defective products and improves the operation efficiency.

##### B) Improved operation safety

Since things can be clearly seen and the visual range is widened, employees are careful for their operation and any disasters due to mistakes, etc. can be prevented.

##### C) Thorough shop management

It becomes easier to point out any defects in the operation and shop, morale for proper arrangement and environmental hygiene is enhanced, and management for the operation and equipment, etc. can be thoroughly achieved.

##### D) Improved operator's morale

A shop with a well-ordered working environment including lighting enhances the employees' pride and responsibility for their appointed tasks, and excites their desire to work.

#### (2) Good factory lighting

Good factory lighting has the following factors:

- Proper illuminance and illuminating distribution
- Free from flickering and glare
- Color rendering properties of light source should not be exceedingly improper.
- Good economical efficiency

For proper illuminance, the necessary value is determined by content of the operation, size of the object and color, etc. Values specified in Table 11.26 are recommended as illuminance standard values in Japan. For the aged, these standard values should be somewhat increased.

Also, flickering and glare cause eye fatigue, hindering the operation and lowering the efficiency. Color rendering properties may also hinder some operations.

**Table 11.26 Illumination Standard**

Illumination [lx]	Place	Operation
3,000	Instrument panel and control panel in control room, etc.	Exceedingly fine visual operation in manufacture of precision machines and electronic parts, printing factory, etc., such as ◦ assembly a, ◦ inspection a, ◦ test a, ◦ selection a, ◦ design, ◦ drawing.
2,000		
1,500	Design and drawing rooms	Fine visual operation in selection and inspection in textile mills, typesetting and proofreading in printing factory, analysis, etc. in chemical industry, such as ◦ assembly b, ◦ inspection b, ◦ test b, ◦ selection b.
1,000		
750	Control room	Ordinary visual operation in general manufacturing processes, etc., such as ◦ assembly c, ◦ inspection c, ◦ test c, ◦ selection c, ◦ packing a, ◦ desk work in warehouses.
500		
300		
200	Electricity room and air conditioning machine room	Rough visual operation such as ◦ packing a, ◦ wrapping b, ◦ restricted operation
150	Entrance/exit, corridor, passage, warehouses involving operation, staircases, lavatories	Very rough visual operation such as ◦ wrapping c, ◦ packing b, ◦ restricted operation
100		
75	Indoor emergency staircases, warehouses, outdoor power equipment	Operation such as ◦ loading, unloading, load transfer, etc.
50		
30	Outdoor (for passage and safety guard within compound)	
20		
10		

**(Remarks)**

1. Similar operations are divided into the following three according to the object to view and nature of the operation:
  - (1) a in the above table indicates fine, dark colored, weak-contrasted, specially expensive, hygiene-related ones and when high precision is required or when long working hours are required, etc.
  - (2) b in the above table indicates an intermediate between (1) and (3).
  - (3) c in the above table indicates coarse, light-colored, strong-contrasted, robust, not so expensive ones.
2. For dangerous operation, double above shall be required.
3. For places for operation marked ◦, this illumination may be obtained by local lighting. It is desirable that illumination for general lighting in this case is more than 1/10 of illumination by local lighting.

### 11.7.2 Energy conservation for lighting

As an equation for general lighting in a factory and office, the following equation is well known.

$$E = \frac{N \times F \times U \times M}{A} (\text{lx}) \dots\dots\dots (1)$$

where

- E : Illuminance (lx)
- A : Area of room (m<sup>2</sup>)
- N : Number of lamps
- F : Luminous flux emitted from one lamp (lm)
- U : Utilization factor (See Note 1)
- M : Maintenance factor (See Note 2)

Note 1: Utilization factor U is the ratio of luminous flux applied to the working plane against the full luminous flux from the lamp, and varies with luminous intensity of the luminaire, installed position, room condition, etc.

Note 2: Maintenance factor is the predicted lowering rate (figure) of initial illuminance with lapse of the working time. This varies with how well the equipment will be maintained, which is determined at the design stage.

Determining the energy required for lighting by transforming equation (1),

$$W \cdot H = \frac{N \times F}{\eta} \times t = \frac{A \times E \times t}{U \times M \times \eta} [\text{Wh}] \dots\dots\dots (2)$$

where W·H: Watt-Hour

- η : Lamp efficiency
- t : Lighting time (hour)

Since the actual electric power consumed for lighting contains the distribution line loss for lighting added to this equation (2), the following can be considered for energy conservation for lighting:

- Reduce the lighting time.
- Reduce the distribution line loss.
- Keep the illuminance proper.
- Use high-efficient luminaires.
- Improve the utilization factor.
- Improve the maintenance factor.

### 11.7.3 Concrete measure for energy conservation

#### (1) Reduce the lighting time

Concrete measures are:





- a. Lights-out while unnecessary, including noon recess
- b. Individual lights-out near windows
- c. Provide many switches for individual lights-out.
- d. Lights-out in quiet areas
- e. Adopt automatic switches or timer switches for outdoor lamps, etc.

In any case, these countermeasures much depend upon the employees' consciousness and therefore, it is necessary to endeavour to enhance it.

#### (2) Reduce the distribution line loss

Since the distribution line loss greatly varies with the distribution system (See Table 11.27), it is desirable to compare and study well for determination when establishing new equipment. Besides, to increase voltage level in the distribution line and to improve power factor, etc. must be studied.

Table 11.27 Comparison of Loss by Wiring System

Wiring system	Connection	Loss calculation	Loss ratio
Single phase two wire system		$P = EI \times 10^{-3} [\text{kVA}]$ $\text{Loss } W = I^2 \times 2LR_1 = \left( \frac{P}{E} \times 10^3 \right)^2 \times 2LR_1 = \frac{2P^2LR_1}{E^2} \times 10^6 [\text{W}]$	100%
Single phase three wire system		$\frac{P}{2} = EI \times 10^{-3} [\text{kVA}]$ $W = 2I^2LR_1 = \left( \frac{P}{2E} \times 10^3 \right)^2 \times 2LR_1 = \frac{P^2LR_1}{2E^2} \times 10^6 [\text{W}]$	25%
Three phase three wire system		$\frac{P}{3} = E \times \frac{I}{\sqrt{3}} \times 10^{-3} [\text{kVA}]$ $W = 3I^2LR_1 = \left( \frac{P \times 10^3}{\sqrt{3}E} \right)^2 \times 3LR_1 = \frac{P^2LR_1}{E^2} \times 10^6 [\text{W}]$	50%
Three phase four wire system		$\frac{P}{3} = EI \times 10^{-3} [\text{kW}]$ $W = 3I^2LR_1 = 3 \left( \frac{P \times 10^3}{3E} \right)^2 \times LR_1 = \frac{P^2LR_1}{3E^2} \times 10^6 [\text{W}]$	16.7%

NOTE: Each cable size is same.

(3) Keep the illuminance proper

Although it is of course important to secure illuminance required for the operation, it is important for energy conservation to reexamine the lighting level and provide local lighting for passages, places where persons do not much enter and outdoor lighting, etc.

Also, when establishing a new factory, adoption of natural daylight should be positively considered.

(4) Use high-efficient luminaires

Luminaires here mean stabilizers, lamps and light reflectors. Table 11.28 shows one example of stabilizers' characteristics. To diminish the distribution line size, the current when starting should be smaller, and to reduce the distribution line loss, the power factor should be higher. However, the weight and cost increase in inverse proportion to these and, therefore, it is necessary for selection of kinds of luminaires to study the economical efficiency.

Table 11.29 and Table 11.30 show features and general applications of various lamps.

**Table 11.28 Example of Stabilizer Characteristic (for 400W Mercury Lamp)**

	Non-dimming type			Dimming type				
	Low power factor type	High power factor type	Constant power type	Constant power type		General type		
Input voltage (V)	200	200	200	200		200		
Voltage tap (V)	200, 220	200, 220	200	200		200, 220		
Input current (A)				Normal	Dimmed	Normal	Dimmed	
	When starting	5.7	4.0	2.3	2.3	—	3.8	—
	When stabilized	3.3	2.3	2.3	2.3	1.3	2.4	1.3
Input power (W)	425	425	435	435	255	432	255	
Power factor (%)	64	90	95	95	95	90	95	
Weight (kg)	4.6	5.2	10.0	13.5		7.0		
Volume ratio (%)	100	160	270	340		220		
Price ratio (%)	100	150	240	310		260		



**Table 11.29 Special Features and Applications of Various Lamps**

Class of lamps	Special features	Scope of size (W)	Main performance of standard quality				Applications
			Efficiency (lm/w)	Color temperature (K)	Color rendering index (Ra)	Life	
Incandescent lamp	<ul style="list-style-type: none"> <li>• Stable light color</li> <li>• Possible to light as-is.</li> <li>• Instantaneous lighting high luminance</li> </ul>	Several W ~ Several kW	100 W				Residence, store, office
			15	2,850	100	1,000	
Tungsten halogen lamp	Small-size, high efficiency and long life lamp	Several 10 W ~ Several kW	For general use 500 W				For floodlamp, for automobiles, for projection, for photography, for copying machine, studio
			21	3,000	100	2,000	
Fluorescent lamp	<ul style="list-style-type: none"> <li>• High efficiency and long life</li> <li>• A wide variety of light colors</li> <li>• Little glare</li> </ul>	4 ~ 220 W	White 40 W				Residence, office, store
			82	4,500	69	10,000	
Mercury lamp	High efficiency, long life, high luminance lamp	40 ~ 2 kW	400 W				For floodlamp (baseball ground, golf course)
			51	5,800	23	12,000	
Fluorescent mercury lamp	Mercury lamp with luster improved	40 ~ 1 kW	400 W				Roads, factory, street lighting, arcade lighting
			56	4,100	44	12,000	
Choreless mercury lamp	Mercury lamp requiring no stabilizer	160, 250, 500 W	500 W				For works, stores
			27	3,000	42	6,000	
Halide lamp	Higher efficiency and lustrous lamp than mercury lamp	250 ~ 1 kW	400 W				Gymnasium, factory, shopping street, open space, park
			80	4,500	65	9,000	
High lustrous halide lamp	High lustrous, high luminous lamp	250 ~ 400 W	400 W				Gymnasium, lobby, hall
			50	5,000	92	6,000	
Low pressure sodium lamp	Highest efficiency, yellow, luminous lamp	35 ~ 180 W	180 W				Tunnel, high-way, switch-yard
			175	—	—	9,000	
High pressure sodium lamp	Highest efficiency, luminous lamp for general lighting	150 ~ 1,000 W	180 W				Gymnasium, high-ceiling factory, warehouse, roads, open space
			120	2,100	29	12,000	

Note: Efficiency of fluorescent and mercury lamps is of 100 hrs value.

**Table 11.30 Selection of Lamps from Standpoint of Typical Applications**

Class of lamps		Incandescent lamp			Fluorescent lamp			Mercury lamp			Halide lamp		Sodium lamp		Xenon lamp
		General lamp	Reflector lamp	Halogen lamp	General fluorescent lamp	High color rendering properties	High output type	Transparent mercury lamp	Fluorescent mercury lamp	Reflector mercury lamp	Stabilizer built-in type	General type	High lustrous type	High pressure	
Residence		⊙	○	△	⊙	○	×	×	×	×	×	×	×	×	×
Office	General office	△	△	△	⊙	△	○	×	×	×	×	△	△	×	×
	High-ceiling office, lobby	○	○	○	○	△	○	×	○	○	△	⊙	○	×	×
	Single room, drawing room	○	○	△	⊙	○	×	×	△	×	×	△	△	×	×
Store	General stores	⊙	⊙	○	⊙	⊙	○	×	○	△	△	△	△	×	×
	High-ceiling stores	○	○	○	○	○	⊙	×	○	○	○	⊙	○	△	×
	Exhibits, showcase	⊙	⊙	⊙	⊙	⊙	○	×	△	△	○	○	○	×	×
Factory	Low-ceiling factory	△	△	○	⊙	○	○	×	△	△	△	△	△	△	×
	High-ceiling factory	△	△	○	△	△	⊙	×	⊙	○	○	⊙	○	○	×
	Warehouse	○	△	○	⊙	△	○	△	⊙	○	○	○	△	○	×
School	Class room	△	△	△	⊙	○	△	×	△	×	×	△	△	×	×
Hospital	Operating room	○	○	△	⊙	⊙	△	×	×	×	×	×	×	×	×
Theater, hall	Spectator's seats	⊙	⊙	⊙	⊙	○	△	×	△	△	△	○	○	×	×
	Stage	⊙	⊙	⊙	⊙	○	○	×	△	△	△	△	△	×	×
Art museum, museum	General	⊙	⊙	○	○	⊙	△	×	△	△	△	○	○	×	×
	Exhibits	⊙	⊙	○	○	⊙	△	×	×	×	×	○	○	×	×
Roads	Automobiles exclusive roads	×	×	×	△	×	×	△	⊙	×	×	△	×	○	△
	Automobiles exclusive tunnel	×	×	×	△	×	×	△	○	×	×	△	×	○	⊙
	Streets	△	×	×	○	×	×	△	⊙	△	△	△	△	○	△
	Shopping streets	○	×	○	○	△	⊙	×	⊙	△	△	⊙	△	○	×
	Roads in resident area	○	×	×	○	×	×	△	⊙	△	×	△	×	○	×
Parking zone	Indoor	△	△	△	⊙	×	○	×	○	△	△	△	△	○	×
	Outdoor	△	△	△	○	×	×	△	⊙	○	△	△	△	○	△
Open space, park, garden		○	△	△	○	△	×	△	⊙	△	△	○	△	○	△
Floodlight lighting	Structure	○	○	○	×	×	×	△	⊙	⊙	○	○	○	△	○
	Advertisement, signboards	○	⊙	⊙	○	○	○	△	⊙	⊙	△	○	○	△	×
Sports	Indoor	○	○	⊙	○	○	○	△	⊙	○	△	⊙	○	△	×
	Outdoor	○	○	○	×	×	×	△	⊙	○	△	⊙	○	⊙	×

(5) Improving utilization factor

Table 11.31 shows an example of the utilization factory table. Room index RI in this table is calculated in the following equation:

**Table 11.31 Example of Coefficient of Utilization Table**

Ceiling		80%									50%								
Wall	60%			30%			10%			60%			30%			10%			
Floor surface	40%	20%	10%	40%	20%	10%	40%	20%	10%	40%	20%	10%	40%	20%	10%	40%	20%	10%	
Room index	Utilization factor																		
0.60	.45	.42	.40	.31	.30	.30	.26	.25	.25	.41	.39	.38	.30	.29	.29	.25	.25	.25	
0.80	.56	.51	.49	.41	.39	.38	.35	.34	.33	.51	.48	.47	.39	.38	.37	.34	.33	.33	
1.00	.63	.57	.55	.47	.45	.44	.41	.40	.35	.57	.53	.52	.45	.44	.43	.40	.39	.38	
1.25	.71	.63	.60	.55	.52	.50	.48	.46	.45	.64	.59	.57	.52	.50	.49	.46	.45	.44	
1.50	.76	.66	.64	.61	.56	.54	.54	.51	.50	.68	.63	.61	.57	.54	.53	.52	.50	.49	
2.00	.85	.75	.70	.71	.65	.62	.64	.59	.57	.76	.70	.67	.66	.62	.60	.60	.58	.56	
2.50	.91	.79	.74	.78	.70	.66	.71	.65	.62	.80	.73	.70	.71	.67	.65	.66	.63	.61	
3.00	.95	.82	.76	.83	.74	.70	.77	.69	.66	.84	.76	.73	.76	.70	.68	.71	.67	.65	
4.00	1.01	.86	.80	.91	.79	.75	.85	.76	.71	.88	.80	.77	.78	.75	.72	.78	.72	.70	
5.00	1.09	.88	.82	.96	3.8	.77	.91	.79	.78	.91	.82	.79	.88	.78	.78	.82	.76	.73	
10.00	1.13	.93	.86	1.08	.90	.84	1.05	.89	.82	.97	.87	.83	.94	.85	.81	.92	.84	.80	

Light output ratio: 83% Light source: FL 40 SW 3,400 lm Fluorescent lamp reflector used

$$RI = \frac{W \times L}{H(W + L)} \dots \dots \dots (3)$$

Where

W: Width of room (m)

L : Depth of room (m)

H : Height of light source from the working plane (m)

The room index has a higher value when it is a square room. And the utilization factor will be higher with the higher reflectivity of the inner wall and floor and the higher room index.


(6) Improving maintenance factor

The maintenance factor means the estimated rate of the initial luminous flux lowering due to dirt on the luminaires with lapse of the working time.


To improve the maintenance factor, first adopt luminaires with less lowering of luminous flux with lapse of the working time and secondly periodically clean the luminaires and replace the lamps. However, under the actual circumstances of the factory with much expenditures in labor cost, it will be unavoidable to replace the lamps and clean the luminaires when the lamps are burnt out. Therefore, the first countermeasure is to use luminaires with less lowering rate.

Fig. 11.48 and Fig. 11.49 show the lowering tendency of the luminous flux of lamp itself and the lowered luminous flux when dirt accumulates on luminaires respectively.

**Figure 11.48 Lumen Maintenance Characteristic of Various Light Sources**



**Figure 11.49 Lowered Lumen When Dirt Accumulated on Lamp and Lighting Equipment**



(7) Others

Other precautions for lighting are not to fluctuate the supply voltage. Although motors, etc. are capable of operating smoothly even at  $\pm 10\%$  fluctuation, lamps are manufactured to perform their best functions and ensure the longest lives at the rated voltage. Therefore, it is desirable to separate illuminating circuits from motor circuits and also to restrict the voltage fluctuation with  $\pm 5\%$ .

Also for ambient temperatures, it is important not to deviate from the manufacturer's specified value.

## **11.8 Electric Heating Systems**

### **11.8.1 Types of electric heating systems**

The electric heating systems are classified as shown in Table 11.32. Their common features are as stated below.

a. **High temperature**

It is possible to heat to the high temperature of 2,000°C or more by arc heating and direct or by directly making a current flow through a heating unit.

b. **High heating efficiency**

The heating efficiency is high because an object generates heat and there is no exhaust gas loss. However, it is necessary to make a general judgement of the power generation process including heat loss and input conversion efficiency.

c. **Quick heating**

It is possible to change the direct electric power to heat in an object heated and conduct quick heating by raising the electric power density.

d. **Easy temperature control**

As automatic control and remote control can be made easily, it is possible to control the temperature precisely.

e. **Easy atmospheric control**

Atmospheric control can be made easily because no combustion is involved.

**Table 11.32 Type and Main Applications of Electric Heating Systems**

Heating method	System for converting electric energy to heat		Main applications and examples of units
	Conversion system	Heating system	
Utilization of Joule heat and arc heat	Resistance heating	Indirect resistance heating (50/50 Hz)	Various types of heat treatment furnaces using resistance heating means, sintering furnace, diffusion furnace, brazing furnace, salt bath furnace, and fluid bed heating
		Direct resistance heating (50/60 Hz) (DC)	Direct energizing heating of metal, graphitizing furnace, glass melting furnace, and ESR furnace
	Infrared ray heating	Proximate infrared ray heating (0.76 - 2.5 m)	Baking of painted surface, drying, and molding and processing of plastics
		Remote infrared ray heating (2.5 - 2.5 m)	Heating at 650°C or less, drying of painting, braking, resin hardening and processing, bread baking, heating, plant rearing
	Arc heating	Arc heating (50/60 Hz)	Steel making, dissolution of fire resisting materials, and dissolution of vacuum arc
		Plasma arc heating (DC)	Dissolution of heat resisting steel, Ni alloy steel, high melting point metal and alloy, dissolution of high melting point compound, production of single crystal, and high temperature thermochemical processing of other materials
Utilization of electromagnetic induction	Surface leather heating	High frequency induction heating (50/60 Hz - 450 kHz)	Dissolution of metal and alloy, heating for thermal processing, heat treatment of metal, welding, and brazing
		Low frequency induction heating	Dissolution of cast steel and heating of large-sized steel
	Transverse flux heating		Heating of sheets such as non-ferrous metal and stainless steel
	Short-circuit heating	For metal dissolution	Groove-shaped blast furnace and temperature rise of molten bath
		For metal heating	Interference of metal parts
	Utilization of high frequency electric field	Induction heating (3 - 40 MHz)	
Heat developed by the impact of electronic and ion flow	Electron beam heating		Evaporation of metal, dissolution of high melting point metal, and fine processing of metal
	Ion and ion beam heating and processing		Ion carburizing, heat treatment such as nitriding, surface coat treatment, etching of semiconductor, implantation, and other surface treatment
	Glow discharge heating		Surface heat treatment of metal and metal heating
Utilization of electromagnetic wave	Laser heating and processing (1 - 11mm)		Drilling processing of process-resistant material, welding, heat treatment and cutting of metal material, welding and processing of electronic parts, etc.
	Microwave heating (915, 2,450 MHz)		Preparation (electronic oven), drying and thawing of food, heating and vulcanization of rubber, and sterilization of food and chemicals
Utilization of electric mechanical power	Heat pump system	For household use	Air conditioning, hot water supply, and building air conditioning
		For industrial use	Drying of food, lumber and leather, effective utilization of exhaust heat, and others

## 11.8.2 Energy conservation for heating systems

### (1) Conversion of the heat source

When one considers the power generation in thermal power generation and atomic power generation, the energy efficiency is approximately 35%, including the electricity loss during transmission and distribution, so heating method is extremely inferior as compared to other sources of heat. If there are no reasons for using electric heat as given above, other sources of heat (e.g. petroleum, coal, gas, and steam) should be used.

Even when the electric heat should be used, if it is possible to convert the heating method (e.g. indirect heating → direct heating), then the thermal efficiency might be raised.

### (2) Correction of the capacity of equipment

In the electric heating systems, a continuous operation with a constant load would be desirable. Intermittent operation would repeat heating and cooling, resulting in the waste of power, so that the difference in the heat efficiency between the continuous and intermittent operations becomes enormous. It will therefore be necessary to restudy the production processes and work procedures and to select the capacity of equipment which would result in a continuous operation.

In particular, the electric heating systems tend to deteriorate by adopting easily the larger equipment when the smaller one is sufficient, so the power consumption per process becomes large, and therefore it will be necessary to compute sufficiently the power consumption and find a method which would enable operation at a minimum loss.

### (3) Reinforced heat insulation

The electric heating systems generate various heat losses, as compared to the motors and transformers, so that the differences in heat efficiencies depends on the heat retaining property. Measuring the heat loss by the temperature sensors and heat flow meters attached to various parts of the equipment and strengthening the heat insulation in the parts of significant heat loss will be needed in order to raise the heat efficiency.

## 11.9 Heat Pump


### 11.9.1 Heat pump system

Electricity is not directly converted to heat but used as power source to convey heat in a heat pump system. Therefore, a heat source is always required.

Basically heat flows from a higher temperature place to a lower temperature place. The same is true for water; water flows from a higher level to a lower level. However, using a pump, water is allowed to flow from a lower level to a higher level. Because of functioning as a pump, a term "heat pump" was coined.

As shown in Figure 11.50, a vapor compression heat pump system needs a compressor, condenser, evaporator and expansion valve. The heat pump system performs heating operation by warming air or water through heat reaction in the condenser. On the other hand, by switching refrigerant circuits, the system can perform cooling operation by cooling air or water using cooling reaction in the evaporator. That is, the system can perform heating and cooling by alternating the heat radiation side and heat absorbing side.

Figure 11.50 Configuration of Heat Pump System



An absorption heat pump is driven by heat energy.

The mechanism is the same as in the vapor compression type in that it utilizes evaporation and condensation of operation media. However, it uses absorption liquid in order to pressure low-pressure vapor, which then absorbs vapor and is transferred to a high pressure portion. By adding heat externally, the operation media is vaporized again. The absorption liquid is recycled by returned back from high-pressure side to low-pressure side. Hence, the basic configuration of an absorption heat pump includes an absorber, liquid pump and generator, instead of a compressor.



## 11.9.2 Features of heat pump system

### (1) Features of heat pump system

- One unit can perform heating and cooling.
- Energy efficiency is excellent.
- Ease of control and ease of operation can contribute to labor-saving.
- Because no combustion accompanies, it is highly safe and clean.
- Because it does not require any related facilities (chimney, oil reservoir, etc.) as in the case of boilers, installation space can be saved.
- Electricity is the only required energy as utility.

### (2) Coefficient of performance (COP)

The figure of Coefficient of Performance, or COP, is used to express the relationship between heat output from the heat pump and power required for the heat pump.

$$\text{Coefficient of performance } (\varepsilon) = \frac{\text{Heat output (kcal / h)}}{\text{Power required (kWh / h)} \times 860 \text{ (kcal / kWh)}} \\ (\text{COP})$$

This equation is used to determine the efficiency of the heat pump and to obtain required power for necessary heat amount.

It may be meaningless if fuel consumption heat amount required to generate power for heat pump operation is larger than the direct combustion. In general the fuel consumption heat amount is 2,250 kcal for 1 kWh power generation.

Heat output of a heat pump with COP ( $\varepsilon$ ) is  $860 \varepsilon$  (kcal/kWh) for required power of 1 kWh. The figure 860 is heat output from 1 kWh electric heater.

To realize energy conservation from a heat pump, at least the following equation needs to be satisfied.

$$860 \varepsilon > 2,250 \\ \varepsilon > 2.62$$


According to the heat pump operation fact research report for industry use (March, 1988) offered by the Heat Pump Technology Center of Japan, the COPs of actually operating heat pumps range from 3 to 20, all exceeding 2.62. This means contribution to energy conservation.

### 11.9.3 Application range of heat pump

#### (1) Building airconditioning by regenerative heat pump

It is assumed that the load of air conditioning per day represents the area enclosed by thick line in Figure 11.51. The capacity of building air conditioning is conventionally determined based on the time period of maximum load (14:00 in the figure). In case of the regenerative system, however, about 50% of the air conditioning load is reserved at night and utilized in the daytime. Thereby, the facility capacity can be lessened and the facility can be operated constantly at high load areas. As a result, high efficiency can be established.

Figure 11.51 Cooling Load Characteristics Curve



As shown in Figure 11.51, the heat pump is operated at night from 22:00 to 8:00 a.m. and warm and cool water equivalent to 50% (portion A in the figure) of heat load is reserved in the heat storage tank. In the daytime, while the heat pump is operated, warm or cool water (portion B in the figure) in the heat storage tank is pumped up to the air conditioner. Then warm or cool air is fed for air conditioning.

Thus, the heat pump capacity can be reduced and the facility cost becomes less. This brings high facility operation rate and efficient operation. In addition, the following advantages can be expected:

- As a result of reduction in facility capacity, the contract power amount can be graded down and then demand charge is reduced. Further, night-use incentive may reduce the operation cost.
- The heat pump can be installed on the rooftop, resulting in efficient use of building areas.

- Automatization is easy for energy conservation.
- Combustion is not required; it is superior in safety and fireproof. It is also effective for environmental protection.

(2) District heating and cooling by a heat pump

Unutilized energy source in cities (urban waste heat) tends to increase year by year. This is because most of the energy supplied to cities is eventually wasted. The most of waste heat is of low temperature of less than 50 °C, generating sources of which are urban facilities such as subways, sewage treatment facilities, incinerators, power plants and substations, houses, factories, etc.

A number of advantages can be brought by using waste heat as heat source for the heat pump.

(2)-1 Advantages of district heating and cooling

- Air pollution by combustion facilities and thermal pollution by waste heat can be reduced, resulting in environmental improvement.
- Urban waste heat and heat in atmosphere, rivers and sea water can be recycled for the use of heat source to the heat pump. Thus, a system with high efficiency of energy conservation can be built. It will be also possible to effectively reduce the capacity of heat source facilities and lower the cost by introducing a heat storage system and combining heat load.
- Handling and storing of dangerous items such as petroleum fuel can be eliminated, so that centralized control will promise safety of the facilities.

(2)-2 Method of district heating and cooling system

① Centralized system

As shown in Figure 11.52 (a), the centralized system produces heat in a central plant at temperatures close to what is required by the demand site. Then it transfers heat to each local site. It is suited for city areas where load density is high and local piping length is relatively short.

② Distributed system


As shown in Figure 11.52 (b), heat pump temperature of heat source can be lowered (15 - 20 deg. C) and heat loss of the heat source water supplied can be reduced. Hence, cost of heat insulation work can be saved. This system is suited for areas where heat load is low and demanding sites expand widely.

### ③ Centralized and distributed system

In the case that a site in the centralized system area requires high temperature heat, heat source temperature is raised at the substation on the demand site. If the demand site is located nearby, heat is transferred through a dedicated line from the center plant.

The above-mentioned heat-pump-type district heating and cooling system will greatly contribute to waste heat recycling in city areas.

**Figure 11.52 Heat-pump-type Local Air Conditioning System**



### (3) Heat pump application to the industry

The application effect expected from a process largely depends on the stance to introduce the system; e.g., where to apply the heat pump system in the existing production process, or whether to implement the multi-function heat pump system as an indispensable element in the planning and design of a process.

For home appliances, because temperatures for air conditioning and hot water supply are considered almost constant, the system configuration of a heat pump may be relatively simple. For industry use, on the other hand, the heat pump system is required to fit to various conditions of production processes. The planning and design of the heat pump system varies in a thousand different ways depending on sectors and production processes.

Therefore, it is important on one hand to know the trend of heat energy utilization in each sector of the industry. On the other hand, however, when introducing a heat pump system, it is also important to conduct a deliberate planning; finding applicable points in the production process, reviewing material balancing (economic distribution of utilities, etc.) in the process concerning energy and production, and obtaining advantages from quality-improved products through improved quality control accuracy of energy.

Figure 11.53 shows a flow of heat utilization mainly with a heat pump .

The characteristics of heat pump usage cover a wide range of applications such as general air conditioning that mainly controls indoor temperature and humidity, a system that raises energy efficiency and economic effect by voparization separation of liquid, as is seen in the latent heat recycling heat pump for industry use, as well as a system that replaces combustion heating with heat pump heating and contributes to environmental improvement.

**Figure 11.53 Heat Flow Diagram Using a Heat Pump System**




Table 11.33 shows the outline of the heat pump system performance. As for compressors, the main equipment of the system, rotary and reciprocating-types are employed for small size main equipment, and turbo and screw-types are employed for large size compressors.

Heat media is freon gas in general. However, special materials (water, hydrocarbon family material) are used for high temperatures (more than 100 °C).

Table 11.33 Performance of Heat Pump

Type of heat pump	General-purpose heat pump			Latent heat recycling heat pump		Super-heat pump
				Direct	Indirect	
Heat source	Air (sensible heat)	Air (sensible heat)	Waste heat, etc.	Waste heat (latent heat)	Waste heat (latent heat)	Waste heat, etc.
Application	Air conditioning, hot water supply, etc.	Air conditioning, hot water supply, etc.	Warming, hot water supply, drying, heating	Food, chemical factory	Food, medicine, photos, plating factory	Various factories, local heat supply
Heat media	Freon (R-22, R-12, etc.)	Freon (R-22, R-12, etc.)	Freon (R-22, R-114, etc.)	Water, etc.	Water, hydrocarbon, freon, etc.	Non-azetropic mixture
Applied temperature	20 ~ 60°C	20 ~ 60°C	60 ~ 110°C	80 ~ 120°C	15 ~ 185°C	150 ~ 300°C
COP	About 3	About 4	About 4 - 5	About 10 - 20	About 2.5 - 6	About 6 - 8
Compressors	Rotary, reciprocating, screw, turbo, etc.	Reciprocating, screw, turbo, etc.	Reciprocating, screw, turbo, etc.	Turbo, roots, screw, etc.	Turbo, screw, reciprocating, etc.	Multi-stage turbo, etc.
Characteristics	For air conditioning use		For high temperature and heat recovery	High temperature, high efficiency, evaporation separation, concentration.	High temperature, high efficiency, heat recovery, low-temperature concentration, etc.	Under development

Table 11.34 shows major applications and installations by technology utilized.

**Table 11.34 Application and Installation Fields**

Technology	Application field
Air conditioning	Houses, buildings, housing complex (department store, school, hospital, public facilities), factories, clean room, public plantation, plant farming facility, etc.
Hot water supply	Pool, public bath, hotel, golf field, dying factory, ham factory, broiler factory, road heating, snow melting, etc.
Heating, cooling	Wine production, plantation facility, fish breeding, dairy farming, chemicals production, food, plating, etc.
Drying, humidity adjustment	Wood, fish, vegetables, fibers, gelatine, printed matters, peat, sewage, rubber products coating, etc.
Condensing, vaporization separation	Saccharated liquid, milk, glycerine, amino acid, antibiotic substance, agricultural chemicals, pulp, beat sugar, rayon fiber liquid, various waste liquid, etc.
Heat recycling	Organic solvent distillation, inorganic chemicals distillation, ethanol distillation, propylene, propane distillation

Waste heat utilization temperature distribution by sector is shown in Figure 11.54. Temperature of waste heat ranges 40 to 100 °C in a process. The shape of waste heat is vapor, hot water, air or gas (air containing solvent, dust), most of them including waste materials from the process.

Used temperature ranges 50 - 60 to 160 °C in a process. In the petrochemical industry and steel industry, waste heat source extends 500 to 1,500 °C high-temperature areas. Effective use of these waste heat is a subject for the future technological development.

Figure 11.54 Heat Utilization Temperature Distribution by Sector




Table 11.35 shows each temperature level and heat demand rate of some industrial sectors. As is found in the table, sectors other than chemical industry and rubber manufacturing industry use heat level of 100 - 150 °C.



**Table 11.35 Temperature Level Used by Sector (%)**

Sector	Temperature	Less than 100° C	~ 150° C	~ 183° C	More than 183° C
Food, tabaco industry		2.5	62.3	16.6	18.6
Fiber industry		0.4	50.3	49.3	0
Wood, wooden product manufacturing		1.1	9.3	6.6	83.0
Pulb paper processing industry		0	85.9	4.1	0
Chemical industry		4.8	26.9	50.0	18.8
Rubber product manufacturing		0	26.3	53.4	20.4
Leather product		0	100.0	0	0
Ceramic and stone manufacturing		0	85.6	14.4	0

Table 11.36 shows application examples of heat pumps currently used, effect of energy conservation, COP of the system, applied places and used temperatures.

According to the table, VRC systems that use latent heat as heat source show high values of COP, 4.5 to 26. High efficiency of energy conservation is realized.

The heat pump system employed in a production process provides different cost performance largely depending on the cost of petroleum (Heavy oil, raw oil, naphtha, light oil) or gas (LPG, LNG) used as heat source. It is important to select investment timing to make the best use of the introduction of a heat pump system.

Heat pump systems for heating or cooling should be used systematically and comprehensively in combination with high temperature heat storage (hot water heat storage, hydrate heat storage) and low temperature heat storage (ice heat storage, inorganic salt and water). Thereby, energy efficiency is raised higher. It also provides reduction of initial cost and running cost, and other advantageous points such as labor-saving and space-saving. Further, larger effects than the aspect of energy utilization can be expected in other aspects such as improvement of product quality, improvement of yielding rate, speeding up of production, and environmental protection by recycling of waste heat and waste materials.

**Table 11.36 Heat Pump System Application and Advantages of Energy Saving Effect**

	Applied place	Type	Temperature used (°C)	COP	Energy conservation effect	Comments
Drying and concentration	Drying of peat	VRC	130-180	4.5	About 75% reduction	4-stage turbo: Water content 60% → 10%, 3 → 14kg/cm <sup>2</sup> g
	Drying of gelatin	C	30-40	—	About 50% reduction	Quality: Water content 67% → 13%
	Drying of laminated processed paper	C	40-50	About 4	About 50% reduction	Improved controllability of capacity
	Drying of golf balls	C	H40 C15	6.24 (2.56, 3.68)	About 50% reduction	Quality
	Drying of fruits and vegetables	VRC	100		About 56% reduction	Quality: Water content 90% → 12%
	Drying of seaweed	C	20-30		About 14% reduction	Quality: Safety
	Calcination of beer malt	C	65-	4	About 58% reduction	Quality
	Concentration of oil raw materials	VRC	100	15	About 93% reduction	Density: 10% → 50%
	Concentration of pulp	VRC	100	21	About 90% reduction	Density: 8% → 40% (3EF 40% → 70%)
	Concentration of wheat juice	VRC	100	7	About 50% reduction	About 10% vaporized
	Concentration of waste whisky	VRC	100	20		Density: 3% → 35% 1 Æ 1.23kg/cm <sup>3</sup> g
	Concentration of amino acid	VRC	88-90	21-25	About 90% reduction	Density: 35%wt → 60%wt
	Concentration of gelatin	VRC	60-70	19		
	Concentration of anti-biotic substance	IVRC	25-30	18		Improvement of controllability and productivity
	Concentration of coarse phosphoric acid	IVRC	20	6	About 50% reduction	Density: 25% → 48%
Concentration of sugar liquid	VRC	93	21-26	About 66-75% reduction	Density: 7% → 48%	
Distillation	Ethyl alcohol purification	VRC	73-105	5.6	About 66% reduction	
	Organic solvent purification	VRC	100	15	About 90% reduction	
	BTX purification	VRC	145	6		Demonstration plant
Heating and cooling	Preprocess before coating	C	52	5	About 30% reduction	Closing, quality
	Tofu production process	C	0			Ice heat storage, quality
	Eel breeding pond heating	C	3		About 33% reduction	Use of nighttime power service
	Dying hot water supply	C	50		About 60% reduction	Production speed: 4 times/day → 5 times/day
	Hot water supply for broiler	C	65	4.8	About 56% reduction	Refrigerating waste heat recycling

Note: VRC: Vapour recompression, C: compress-type IVRC: Indirect type Quality: quality improvement 3EF: tripple effect can

## 11.10 Air Conditioning

### 11.10.1 Introduction

Air conditioning refers to control of air conditions of rooms or plants to their optimal states fit for its usage and purposes. As other indices for judging the quality of a room atmosphere, there are acoustic impression, visual impression and sense of freedom, but air conditioning has nothing to do with them unless the facility factors affect them adversely.

Air condition of rooms to be controlled include the following 4 factors.

#### (1) Temperature

The room air is either cooled or heated for control to the prescribed value of the dry-bulb thermometer.

#### (2) Humidity

The room air is controlled to the prescribed comfortable relative humidity.

#### (3) Cleanliness

The room air is removed of dusts below the allowable dust concentration, and at the same time it is maintained so that fume, CO<sub>2</sub>, odor, toxic gases, etc. are kept below the allowable concentration.

#### (4) Distribution

To facilitate uniform distribution of conditioned air in the room, a proper air flow is produced and a constant temperature condition of the whole room is maintained.

Purposes of this air-conditioning can be classified largely into a) hygienic air-conditioning and b) process air-conditioning.


##### a) Hygienic air conditioning

Hygienic air-conditioning means to maintain the room air in a state which maintains the hygienic environment for the human body and gives a sense of comfort and amenity namely to maintain the room air to a state suited for people living or working there. The 2 major factors governing the optimal air condition are temperature and humidity. Figure 11.55 shows the comfortable zones during winter and summer in Japan.

Meanwhile, apart from this figure, it is considered desirable to keep the room temperature not so greatly different from the outdoor temperature and to keep the humidity at a minimum level. And, the difference between room and outdoor temperatures is considered most suitable when it is 5° ~ 7°C.

For general office work, design conditions are set at 18° ~ 22°C and 30% ~ 50% (R.H) during heating, and 25° ~ 28°C and 50% ~ 60% (R.H) during cooling. When energy conservation is given priority, values near the lower limit of the given values, namely 18°C and 40% during winter, and 28°C and 50% during summer are adopted.

**Figure 11.55 Comfort Zone**



**b) Process air conditioning**

Of processes of industrial production, many including processes from raw materials to completion and storage of products require independent conditions for retaining the facility and quality. As processes often require coexistence of operators, workers there, process air conditioning should take factors of hygienic air conditioning into consideration. Generally, process air conditioning precedes, and for the human body hygienic performance is assured by local air conditioning and other means.


Table 11.37 shows typical design air conditioning states of various industrial processes. However, the table shows mere guidelines, and individual design should be determined by thorough study.



### 11.10.2 Composition of air conditioning system

The final means for performing air conditioning is the air, and generally air conditioning is performed by letting out the air with proper temperature, moisture and cleanliness from blowing outlets into rooms. And there are various devices for achieving this aim, of which a composition of a relatively large-scale air conditioning system is shown in Figure 11.56. Here descriptions are given mainly on cooling, based on this composition.

**Figure 11.56** Composition Example of Large Scale Air Conditioning System (during cooling)



During cooling, heat load flows from the outside into the room, which is transferred from air to chilled water within the air conditioner and carried to the heat source unit (refrigerator), and after pumped up by the refrigerator, is discharged through the cooling tower into the atmosphere.

During heating, oil or gas is burnt by boiler, and this heat, after transferred to warm water, is carried to the air conditioner, and supplied into the room by means of air conditioner.

(1) Heat source unit

The heat source unit supplies warm water (heating medium) or chilled water (coolant) to the air conditioner. Heat source units for heating the heating medium include boiler, regenerator tank, heat pump, etc., and that for cooling the coolant include the refrigerator. Besides them are heat exchangers, pumps, blowers and pipings as auxiliary equipment.

(2) Air conditioner

A unit for preparing the blow air to a temperature, moisture and cleanliness suited for the required room conditions. It therefore is equipped with various equipment within for purifying, cooling, temperature reducing, heating, humidifying, blowing, etc.

(3) Supply unit

A unit for supplying fluid and gas is composed of blower, pump, duct, piping, etc. That is, the air conditioned through the air conditioner is supplied through the duct to a room to be cooled. And, the warm room air is absorbed by negative pressure of the blower and sent into the air-conditioner.

(4) Diffuser

Installed at the outlet or inlet of the duct, composed of blowing outlet, suction port, muffler, damper, etc.

(5) Switch board, control panel, monitor panel

These are electric facilities for operating, controlling and monitoring the air conditioning system.

The above-mentioned units are not necessarily installed separately, and there are systems which combine several units in one or those in which all of them form a single unit, like a package-type air-conditioner, depending on the scale of air-conditioners.

### 11.10.3 Heat load of air conditioning system and its calculation

Figure 11.57 shows the inflow sections of heat load to a room.

Table 11.38 lists the type and composition of heat load, and calculation formulas corresponding to Fig. 11.57. Additionally, accumulated heat load is generated during ordinary intermittent operation, which is accumulated in the building framework by invasion of external heat during the night when the air conditioner is stopped and is gradually flown away as load after resuming operation. Both heating load and cooling load are largely affected when operation is stopped during the night and during the day respectively by heat accumulation.

Figure 11.58 shows a cooling load example at a plant office. Construction of the building is as shown in Figure 11.59.

According to Figure 11.58, load due to heat transfer is the largest, followed by lighting, external air, solar radiation and human body in that order.

Figure 11.57 Type of Heat Load and Inflow Sections (Cooling)




Figure 11.58 Example of Air Conditioning Load in Factory Office (during Cooling)

Load due to human body	11%	
Load due to solar radiation	15%	
Load due to external air	15%	
Load due to lighting	16%	
Load due to heat transfer	43%	Total 17,045 kcal/h



Figure 11.59 Example of Office




Table 11.38 Types and Composition of Air Conditioning Heat Loads, and Calculation Formulas

Type of load	Symbol	Calculation formula		Remarks
		Sensible heat load	Latent heat load	
<b>Room load RL</b>				
Heat source (oil, etc.) and heat sink (cooling tower-atmospheric air) load				
Air conditioner load ACL				
Heat source unit (boiler, refrigerator, etc.) load HACL				
<b>Outdoor load</b>				
Glass-transmitted solar radiation	$q_R$	$S_c \cdot A \cdot I$		$S_c$ : Shield modulus, A: Area, I: Standard solar radiation gain
Transfer through external wall and roof	$q_w$	$K \cdot A \cdot \Delta t_e$		K: Heat transfer coefficient $\frac{1}{K} = \frac{1}{\alpha_i} + \sum \frac{d_j}{\lambda_j} + \frac{1}{\alpha_o}$
Transfer through external wall glass	$q_g$	$K \cdot A \cdot \Delta t_g$		$\alpha_i$ : Indoor heat transfer rate - 8 kcal/h·m <sup>2</sup> ·°C $\alpha_o$ : Outdoor heat transfer rate - 20 (summer), 30 (winter) [kcal/h·m <sup>2</sup> ·°C]
Infiltration	$q_{in,L}$	$0.28V_i \cdot \Delta t_o$	$715V_i \cdot \Delta C_o$	d: Thickness of layer of component member, $\lambda_j$ : Thermal conductivity [kcal/m·h·°C]
Accumulated heat load	$q_{st}$			For all-day air conditioning $\phi_{ST-0}$ : Effective temperature difference (°C)
<b>Internal load</b>				
Lighting	$q_L$	$860b \cdot L$		b: Ballast coefficient, incandescent lamp b=1.0, fluorescent lamp b=1.2, L: Lighting power [kW]
Human body	$q_{hs,L}$	$h_s \cdot B$	$h_s \cdot B$	$h_s$ : Sensible heat and latent heat generated from a human body, B: Number of persons
Equipment	$q_{es,L}$	$q_{es}$	$q_{eL}$	Use measured value (facility capacity $\neq$ load factor)
<b>External air load</b>				
Duct heat reception and leakage	$q_{os,L}$	$0.28V_o \cdot \Delta t_o$	$715V_o \cdot \Delta C_o$	$V_o$ : Amount of air intake $\Delta t_o = t_o - t_r$ , $\Delta C_o = C_o - C_r$
Fan heat	$q_f$	$(K \cdot A \cdot \Delta t) / (0.28V_o \cdot \Delta t_o)$	$(715V_o \cdot \Delta C_o)$	$V_o$ : Amount of leaked air 5-20% of RL
Reheat load	$q_h$	$860W_r$		$W_r$ : Fan drive power [kW]
Piping heat reception	$q_p$	$q_h$		Use measured value of reheat quantity
Pump heat	$q_{pp}$	$860W_p$		$\Delta t$ : Difference between water temperature and ambient temperature 2-5% of ACL
Accumulator tank loss	$q_{ta}$	$(K \cdot A \cdot \Delta t)$		Use measured value of reheat quantity
Refrigerator drive power	$q_{hp}$	$860W_{hp}$		Wp: Pump drive power
Cooling water pump heat	$q_{pc}$	$860W_{pc}$		5-15% of HACL (Total 1-day value)
Boiler waste heat	$q_c$	$\left[ \frac{1}{\eta} - 1 \right] HACL$		For heat pump, it is included as part of heat source (during heating) Wp: Pump drive power [kW] $\eta$ : Boiler efficiency

#### 11.10.4 Energy conservation of air conditioning facility

For air conditioners, the load to be air conditioned is determined first, and secondly a suitable air conditioning system for this load is selected. Therefore, in considering energy conservation of an air conditioning facility, reducing the cooling load (1st step), and selecting an energy-saving air conditioner or system for the remaining cooling load (2nd step) are very important. Here, measures are considered mainly in relation to existing buildings.

##### (1) Heat insulation

The transfer heat load is expressed by  $K \cdot A \cdot \Delta t_e$ . The area  $A$  and effective temperature difference  $\Delta t_e$  are determined by the shape of building, weather condition and heat capacity, so when these cannot be changed, it is easiest to insulate the heat, that is, vary the heat transfer coefficient  $K$ . As methods of heat insulation, there are the following 3 methods.

##### a. Heat insulation of walls and windows

While external heat insulation has an advantage of being able to cut off heat without obstacles from the outside, internal heat insulation has disadvantages such as restrictions due to furniture or reduction of the room area.

##### b. Heat insulation of roofs and floors

##### c. Heat insulation of window glass

Heat insulation of window glass is done by doubling of window glass or doubling of window sashes. For the heat transfer coefficient, there is not so much difference as far as the number of window glasses is the same.

##### (2) Light shielding

The glass transmitted solar radiation load is expressed by  $S_c \cdot A \cdot I$ . The standard solar radiation gain is decided by weather condition and layout of the building, and methods are adopted for varying the shielding factor and window area.

##### a. Fitting blinds and curtains

It should be noted that the shielding effect is available only under the condition that sure open/close operations of blinds are carried out. Also, since the shield effect is connected with the use of day light, it is essential to obtain a method which makes the sum of cooling/heating energy and lighting energy at a minimum.

##### b. Fitting louvers and hoods

Provide fixed hoods, louvers, etc. outside windows with considerations made so as to shield solar radiation during the summer and not shield it during the winter.

c. Repairing window glass

Window glass is replaced with heat ray absorbing glass or reflecting glass, without having to change sashes, and the amount of transmitted solar radiation through window glass is reduced by bonding solar radiation adjusting film, to reduce cooling load.

(3) Preventing infiltration

Load  $q_i$  kcal/h due to infiltration is caused by natural ventilation, namely entrance of external air through crevices of windows and doors and the open and close operations, and it is expressed by the following formula.

$$q_i = 0.28V_1 \cdot \Delta t_o + 715V_1 \cdot \Delta x_o$$

$$= 0.28n \cdot V \cdot \Delta t_o + 715n \cdot V \cdot \Delta x_o$$

where

n : Number of times for natural ventilation (see Table 11.39)

V: Room capacity (m<sup>3</sup>)

**Table 11.39 Number of Times for Natural Ventilation (n)**

Class of room	n
1 wall surface facing outside air and having window or door	1
2 walls surface facing outside air and having window or door	1.5
3 walls surface facing outside air and having window or door	2
4 walls surface facing outside air and having window or door	2
Room without window facing the outside air or door	1/2 - 3/4

For air-tight window, 1/2 of this table shall be used. However, n shall be more than 1/2 in any case.

To reduce infiltration load, windows and doors may be sealed, and the number of (open/close) operations may be reduced, as practicable, much as possible by automatic doors. However, since  $\Delta t_o$  will become negative when the outdoor temperature is below the room temperature during the nighttime, and it means more reduction of cooling load, and cooling effect is obtained by opening windows and doors to introduce external air.

(4) Producing heat values generated by equipment in the room

It is preferable not to place any equipment which generated heat inside the air-conditioned room. For lighting as well, adoption of local lighting and high-efficiency lamps and improvement of lighting appliances for more efficiency of lighting, or adoption of a ventilation system for disposing generated heat by lighting equipment separately, are desirable.

(5) External air load

The external air load  $q_0$  is produced by forced ventilation and is expressed by the following formula.

$$q_0 = 0.28V_0 \cdot \Delta t_0 + 715V_0 \cdot \Delta x_0$$


The ventilation volume  $V_0$  is regulated mainly from the safety and hygiene for man. Suppose the allowable  $\text{CO}_2$  concentration is 0.1%, the required volume of external air is approx.  $30 \text{ m}^3/\text{h}/\text{person}$ .

At any rate, in order to reduce external air load, it is important to minimize the volume of ventilation within a range in which  $\text{CO}_2$  concentration is below 0.1%.

Where there is a circulation system as shown in Figure 11.60, introduction of external air should be reduced, as much as possible, by recirculating within the system. The damper of the circulation system is increased in size to increase return air, and at the same time opening of the damper at the external air intake system is reduced to cut down on the intake volume of external air.

What should be noted in the system (Figure 11.60) is that the room pressure becomes negative against the outdoors when return air is made excessive, resulting in a state which readily allows invasion of air and dusts from outside. Therefore, it is desirable to maintain the room pressure in the positive state at  $0.1 \text{ mm Aq} \sim 1 \text{ mmAq}$  against the outdoors.

**Figure 11.60 Air Conditioning System when Return Air is Available**



(6) Alleviating the set room temperature


By raising the set temperature during cooling, cooling load by heat transfer from wall surfaces, which is proportionate to difference between temperatures inside and outside the room, is greatly reduced. In the case shown in Figure 11.58, for example, raising set temperature from 26°C to 27°C reduced cooling load by approx. 100 kcal/h.

(7) Review of room humidity

In the case of air conditioners having a dehumidifying function, alleviation of humidity condition is an effective measure toward energy conservation. According to the example calculations, variations of air conditioning load by varying humidity and by varying temperatures are as shown in Figure 11.61.

While approx. 4.2 kcal/h of load reduction can be attained when humidity is alleviated from 40% RH to 60% RH at 23°C, load reduction is approx. 0.7 kcal/h only when temperature is alleviated from 21°C to 25°C at relative humidity 50% RH - alleviation of humidity is about 6 times more effective as energy conservation. However, it should be noted that excessively high humidity would give uncomfortableness to man and affect on products quality adversely.

Figure 11.61 Energies Required for Temperature and Humidity Changes



(8) Improving control method

As mentioned before, control of heat load is available by method which varies flow rate, and by method which varies set temperature with flow rate set constant. Reduction effect of drive power for the fan and pump is larger in the former, and it results in energy conservation.

As control methods for flow rate, there are control of dampers and vanes, and various rotating speed controls. Power consumption is ranked as discharge damper control > inlet vane control > rotating speed control. As rotating speed control by VVVF is easily available for existing motor facilities with considerable effects, it should be studied first among other possibilities.

(9) Regular maintenance

a. Cooling water piping

Accumulation of scale and sludge in piping will increase resistance and require more pump output for the same flow rate. If the water quality is poor, it will naturally accelerate accumulation of scale and sludge. Therefore, control of water quality is necessary. Reference values for the control criterion are shown in Table 11.40.

**Table 11.40 Quality Standard of Cooling Water**  
(Japan Refrigeration and Air Conditioning Industrial Association Standard)

	Item		Standard value for makeup water	Standard value for cooling water *1	Tendency *3	
					Corrosion	Scale
Standard item	PH (25°C)		6.0 ~ 8.0	6.0 ~ 8.0	○	○
	Conductivity	(mv/m)	200 or less	500 or less (1,000 or less)	○	
	Chlorine ion Cl	(ppm)	50 or less	200 or less	○	
	Sulfuric acid ion SO <sub>4</sub>	(ppm)	50 or less	200 or less	○	
	Total iron Fe	(ppm)	0.3 or less	1.0 or less *2	○	○
	M Alkalinity CaCO <sub>3</sub>	(ppm)	50 or less	100 or less		○
	Total hardness CaCO <sub>3</sub>	(ppm)	50 or less	200 or less		○
Reference item	Sulfur ion S	(ppm)	Not be	Not be detected	○	
	Ammonium ion NH <sub>4</sub>	(ppm)	detected	Not be detected	○	
	Silicon oxide SiO <sub>2</sub>	(ppm)		50 or less		○

\*1 Cooling water means water passing through condenser for both transient and circulation systems.

\*2 Standard value for plastic piping shall be 0.5 ppm or below.

\*3 Mark ○ in "Tendency" column indicates a factor concerning either corrosion or scale tendency.

b. Heat exchanger

When scale, sludge and microbes are generated in the evaporator and condenser by cooling water, they will be accumulated to drop the efficiency of heat exchange, and increase power consumption per refrigeration ton. Therefore, periodical cleaning is necessary.

c. Air duct

When filters are used for cleaning the air, periodical cleaning is inevitable. Clogging of filters increases pressure loss and reduce air volume to degrade cooling capacity. As air conditioners are quickly contaminated when installed at places under poor atmospheric conditions, cleaning is required at least once a week.



d. Others

It is desirable to reduce air-conditioning load, as possible, by performing reviews of air-conditioning zones through studies on unbalanced supercooling/superheating of rooms, review of air-conditioning levels at corridors, etc. in each season.

Also, in installing any air conditioning systems, studies should be made carefully, including appropriateness of installing heat accumulation tanks, appropriateness of using waste heat, selection of the most efficient air conditioning duct system, etc., all of which are realized by placing emphasis on reduction of the running costs.

## 12. Thermal Insulation Calculation with a Personal Computer

## 12. THERMAL INSULATION CALCULATION WITH A PERSONAL COMPUTER

### (1) Outline

With the personal computer calculation sheet treated here, the calculation of the heat emission amount from the surface of steam piping etc. is executed on the basis of the theories of heat transfer engineering. Heat transfer is divided into conduction, convection, and radiation, and in actual life, these appear individually or in combination.

The heat emission amount is calculated according to the following two methods.

- ① A method where the heat emission amount is obtained from the temperature of the inner surface and the thickness of the insulating material
- ② A method where the heat emission amount is obtained from the surface temperature.

The thickness of the insulating material is selected according to the philosophy of the economic insulation thickness.

These calculations are executed with a personal computer and Lotus 123 as a spreadsheet, using the calculation sheet developed by the Energy Conservation Center. Here, the way of thinking and the use of the personal computer calculation sheet will be explained.


### (2) Heat conduction

#### 2-1 Basic formula

As shown in Fig. 12.1, when there is a solid wall with a thickness of  $b$  (m) and the temperature at both sides of the wall is held at  $t_1$  ( $^{\circ}\text{C}$ ) and  $t_2$  ( $^{\circ}\text{C}$ ), the amount of heat passing through the wall per unit time is expressed by formula (1).

Figure 12.1 Heat Conduction

78




$$Q = \lambda A \frac{t_1 - t_2}{b} \quad [\text{kcal/h}] \quad \text{Equation (1)}$$

where A (m<sup>2</sup>) is the area of the wall.

In equation (1),  $\lambda$  is called the "heat conductivity", and this is a specific value for insulating material etc., and in many cases it changes according to the temperature of the material.

When the wall has a multilayer construction as shown in Figure 12.2, expression as shown in equation (2) is possible as the temperature gradient is consecutive for the various layers and the amount of heat passing through each layer is the same.

Figure 12.2 Heat Conduction of a Multilayer Wall




$$q = \frac{t_1 - t_{n+1}}{\frac{b_1}{\lambda_1} + \frac{b_2}{\lambda_2} + \dots + \frac{b_n}{\lambda_n}} \quad [\text{kcal}/(\text{m}^2 \cdot \text{h})] \quad \text{Equation (2)}$$

As can be seen from equation (2), it is not necessary to calculate the temperatures of the intermediate wall boundary, and the transfer amount can be calculated by giving the surface temperatures of the two outer wall surfaces and the thermal conductivity and the thickness of the material of each wall.

## 2-2 Heat Conduction of Cylindrical Walls

When the wall surface is a cylinder, as shown in Figure 12.3, the cross section area changes with increase of the distance in radial direction. Accordingly, even when the heat transfer amount at the position of each radius is constant, the heat transfer amount per unit area differs according to the radius position. The heat transfer amount per unit length for the case of cylindrical walls is expressed by equation (3).

Figure 12.3 Heat Conduction of a Cylindrical Wall




$$q_l = \frac{2\pi\lambda}{\ln \frac{r_2}{r_1}} (t_1 - t_2) \quad [\text{kcal/m}\cdot\text{h}] \quad \text{Equation (3)}$$

where  $\ln$  is the natural logarithm in equation (3).

The heat transfer amount for a multilayer cylindrical wall as shown in Figure 12.4 is given by equation (4).

Figure 12.4 Heat Conduction of a Multilayer Cylindrical Wall



$$q_1 = \frac{2\pi(t_1 - t_{n+1})}{\frac{1}{\lambda_1} \ln \frac{r_2}{r_1} + \frac{1}{\lambda_2} \ln \frac{r_3}{r_2} + \dots + \frac{1}{\lambda_n} \ln \frac{r_{n+1}}{r_n}} \quad [\text{kcal/m}\cdot\text{h}] \quad \text{Equation (4)}$$


In this case also, in the same way as for a flat surface, the temperatures at the boundaries of each cylinder are not required for calculation of the heat transfer amount, and it is sufficient when the temperatures at the inner and the outer surface of the multilayer cylinder are known.

(3) Heat transfer by convection

The heat exchange of a gas or a liquid at the surface of a solid body differs from the heat conduction in a solid body, and it is called "heat transfer by convection". In this case, the heat does not only move inside the fluid by means of heat conduction, but as it is also being transported by the moving fluid, the heat transfer amount becomes extremely large in comparison to heat conduction. The heat transfer amount also is influenced easily by the flow, and the heat transfer amount increases with increasing velocity of the fluid.

In the case of convection heat transfer as shown in Figure 12.5, the temperature difference and the heat transfer amount are proportional when the flow pattern of the fluid is the same, so that the heat transfer amount is expressed by equation (5).

Figure 12.5 Heat Transfer by Convection



$$q = \alpha (t_f - t_1) \quad [\text{kcal}/(\text{m}^2\cdot\text{h})] \quad \text{Equation (5)}$$

In equation (5),  $\alpha$  is a factor called the "heat transfer coefficient", which changes according to the fluid type and the flow conditions, and various calculation formulas have been proposed on the basis of experiments.

The dimensionless numbers defined in equation (6) are used to express the condition of flow and heat transfer.

$$\left. \begin{aligned} \text{Nu} &= \frac{\alpha L}{\lambda} && \text{(Nusselt number)} \\ \text{Re} &= \frac{wL}{\nu} && \text{(Reynolds number)} \\ \text{Pr} &= \frac{\nu}{a} && \text{(Prandtl number)} \end{aligned} \right\} \text{Equation (6)}$$

$\alpha$	: Heat transfer coefficient	[kcal/(m <sup>2</sup> ·h·°C)]
$L$	: Representative length	[m] (diameter for a tube, distance from the tip for a plate)
$\lambda$	: Heat conductivity of the fluid	[kcal/(m·h·°C)]
$w$	: Fluid velocity	[m/h] or [m/s]
$\nu$	: Kinetic viscosity	[m <sup>2</sup> /h] or [m <sup>2</sup> /s]
$a$	: Thermal diffusivity of the fluid	[m <sup>2</sup> /h] or [m <sup>2</sup> /s] (= $\frac{\lambda}{c\gamma}$ )
$c$	: Specific heat of the fluid	[kcal/(kg·°C)]
$\gamma$	: Specific gravity of the fluid	[kg/m <sup>3</sup> ]

### 3-1 Natural Convection

The flow of a fluid not caused by a fan or a pump, but by the density difference from temperature rise of the fluid in contact with a solid body is called "natural convection". The heat transfer coefficient with natural convection is expressed using the Grashof number, which is defined as follows.

$$\text{Gr} = \frac{L^3 g \beta (t_w - t_0)}{\nu^2} \quad \text{Equation (7)}$$

where

$g$	: Gravitational acceleration	[m/s <sup>2</sup> ]
$\beta$	: Coefficient of volume expansion of the fluid	[1/K]
$t_w$	: Surface temperature	[°C]
$t_0$	: Fluid temperature	[°C]

With these equations, the value of the heat transfer coefficient of the fluid, the dynamic coefficient of viscosity, and the Prandtl number change according to the type and the temperature of the fluid, and for each fluid, the temperature relation can be expressed according to the following equation. In other words, the fourth order temperature equation for water is expressed as

$$a + bt + ct^2 + dt^3 + et^4,$$

while the third order temperature equation for air is expressed as

$$a + bt + ct^2 + dt^3,$$

and the coefficients in the equations are given by the following table.

Substance	Property value	a	b	c	d	e
Water	Thermal conductivity kcal/(mh°C)	0.4465	3.172 $\times 10^{-3}$	-2.581 $\times 10^{-5}$	9.593 $\times 10^{-8}$	-1.549 $\times 10^{-10}$
	Dynamic viscosity coefficient (m <sup>2</sup> /s)	1.234 $\times 10^{-6}$	-2.021 $\times 10^{-8}$	1.619 $\times 10^{-10}$	-6.347 $\times 10^{-13}$	9.790 $\times 10^{-16}$
	Prandtl number	8.179	-0.1345	1.017 $\times 10^{-3}$	-3.663 $\times 10^{-6}$	5.148 $\times 10^{-9}$
Air	Thermal conductivity kcal/(mh°C)	0.02071	6.856 $\times 10^{-5}$	-3.414 $\times 10^{-8}$	1.567 $\times 10^{-11}$	
	Dynamic viscosity coefficient (m <sup>2</sup> /s)	1.378 $\times 10^{-5}$	8.916 $\times 10^{-8}$	1.355 $\times 10^{-10}$	-1.566 $\times 10^{-13}$	
	Prandtl number	0.7177	-1.705 $\times 10^{-4}$	-4.403 $\times 10^{-7}$	2.924 $\times 10^{-9}$	

With use of these dimensionless numbers, the Nusselt number can be expressed by the following empirical equations.

a) In case of a horizontal cylinder

$$Nu_m = 0.53(Gr \cdot Pr)^{1/4} \quad \text{Equation (8)}$$

b) In case of a vertical plate

$$Nu_m = 0.13(Gr \cdot Pr)^{1/3} \quad \text{Equation (9)}$$

c) In case of a horizontal plate facing up

$$Nu_m = 0.14(Gr \cdot Pr)^{1/3} \quad \text{Equation (10)}$$

d) In case of a horizontal plate facing down

$$Nu_m = 0.27(Gr \cdot Pr)^{1/4} \quad \text{Equation (11)}$$



### 3-2 Forced Convection

With forced convection, the Nusselt number is expressed as follows by using the Reynolds number instead of the Grashof number.

- a) When the fluid is flowing outside the tube (in case of a single circular tube and air as the fluid)

$$\text{Nu} = c\text{Re}^n \quad \text{Equation (12)}$$

with the values for  $c$  and  $n$  as shown in the following table.

Re	n	c
1 to 4	0.330	0.891
4 to 40	0.385	0.821
40 to 4,000	0.466	0.615
4,000 to 40,000	0.618	0.174
40,000 to 250,000	0.805	0.0239

- b) In case of a flat surface

$$\text{Nu} = 0.037 \text{Re}^{0.8} \text{Pr}^{1/3} \quad \text{Equation (13)}$$

In these equations, the value of the heat transfer coefficient, the dynamic coefficient of viscosity, and the Prandtl number are given by the temperature polynomial in the same way as for the case of natural convection.

Various empirical equations have been proposed for the heat transfer coefficient in case of convection heat transfer, and the following equation for calculation of the heat transfer coefficient in case of convection heat transfer has been quoted from a publication of assistant professor Takamura.

#### (4) Radiation

In addition to the above mentioned convection, heat transfer at the surface of a solid body also is executed by radiation. In the case of a small body being placed in a large space, as in the case of steam pipes etc. in a room, the heat transfer quantity by radiation from the body is expressed by equation (14).

$$q = 4.88 \varepsilon \left\{ \left( \frac{T_1}{100} \right)^4 - \left( \frac{T_2}{100} \right)^4 \right\} \quad [\text{kcal}/(\text{m}^2 \cdot \text{h})] \quad \text{Equation (14)}$$

Where  $T_1$  is the absolute temperature of the body and  $T_2$  is the absolute temperature of the ambient air. In equation (14),  $\varepsilon$  is a coefficient related to the body (the body and its surface condition) and the temperature of the body, and it is called the emissivity. As shown in equation (14), the heat transfer quantity by radiation is proportional to the difference between the fourth powers of the absolute temperatures. As radiation in many cases occurs simultaneously with convection and conduction, the heat transfer quantity by radiation for practical use also is expressed in the form of an equation proportional to the temperature difference. In other words, the heat transfer coefficient for radiation is expressed by equation (15).

$$h_r = \frac{4.88 \varepsilon \left\{ \left( \frac{T_1}{100} \right)^4 - \left( \frac{T_2}{100} \right)^4 \right\}}{t_1 - t_2} \quad [\text{kcal}/(\text{m}^2 \cdot \text{h} \cdot ^\circ\text{C})] \quad \text{Equation (15)}$$

When the heat transfer coefficient for radiation is defined in this way, the total heat emission quantity by convection and radiation is expressed by equation (16).

$$q = (h_r + h_c)(t_1 - t_2) \quad [\text{kcal}/(\text{m}^2 \cdot \text{h})] \quad \text{Equation (16)}$$


In equation (16),  $h_r$  is the heat transfer coefficient for radiation and  $h_c$  is the heat emission coefficient for convection.

## (5) Overall Heat Transfer

### 5-1 Philosophy

When two types of fluids flow along the two surfaces of a solid body between them as shown in Figure 12.6, the heat transfer quantity from the high-temperature side to the low-temperature side is expressed as follows by combining the above explained relation equations.

Figure 12.6 Overall Heat Transfer



$$q = \frac{t_{f1} - t_{f2}}{\frac{1}{\alpha_1} + \frac{b_1}{\lambda_1} + \frac{b_2}{\lambda_2} + \dots + \frac{b_n}{\lambda_n} + \frac{1}{\alpha_2}} \quad [\text{kcal}/(\text{m}^2 \cdot \text{h})] \quad \text{Equation (17)}$$

where  $\alpha_1$  and  $\alpha_2$  are the heat transfer coefficients between the solid wall and the fluids on the high-temperature side and the low-temperature side,  $b$  is the thickness of the solid wall, and  $\lambda$  is the thermal conductivity of the solid wall.

The surface temperatures of the solid wall are given by equations (18) and (19), using the calculated heat transfer quantity.

$$t_1 = t_{f1} - \frac{q}{\alpha_1} \quad \text{Equation (18)}$$

$$t_2 = t_{f2} + \frac{q}{\alpha_2} \quad \text{Equation (19)}$$

In the case of a circular wall, the heat transfer quantity and the surface temperatures are expressed as shown in equations (20), (21), and (22).

$$q_1 = \frac{2\pi(t_{f1} - t_{f2})}{\frac{1}{r_1 \cdot \alpha_1} + \frac{1}{\lambda_1} \ln \frac{r_2}{r_1} + \frac{1}{\lambda_2} \ln \frac{r_3}{r_2} + \dots + \frac{1}{\lambda_n} \ln \frac{r_{n+1}}{r_n} + \frac{1}{r_{n+1} \cdot \alpha_2}} \quad [\text{kcal}/\text{m} \cdot \text{h}] \quad \text{Equation (20)}$$

$$t_1 = t_{f1} - \frac{q_1}{2\pi r_1 \cdot \alpha_1} \quad \text{Equation (21)}$$

$$t_2 = \frac{q_1}{2\pi r_{n+1} \cdot \alpha_2} + t_{f2} \quad \text{Equation (22)}$$

## 5-2 Calculation Sheet for the Overall Heat Transfer

With actual calculation, the heat transfer quantity can not be obtained easily, as the thermal conductivity of materials and the heat transfer coefficient for convection and radiation change according to the temperature. For example, the heat transfer coefficient of the surface depends on the surface temperature, and the surface temperature is calculated by means of the heat transfer coefficient. With a calculation sheet for multilayer insulation, first the surface temperature is assumed, and the heat transfer coefficient and the thermal conductivity of the material are obtained. Next, thus heat transfer coefficient and this thermal conductivity are used to calculate the heat transfer, and the surface temperature is calculated. These calculations are repeated until the surface temperature obtained in this way has approached the assumed surface temperature within given limits.


This calculation procedure uses the Lotus 123 programming function called a macro, with notation on a work sheet and execution by specification from the keyboard. Accordingly, the work required by the user of the calculation sheet is only specification of calculation execution to the machine after the various preconditions have been set. The calculation sheet permits calculations for insulation with up to 3 layers.

(6) Economical Insulation Thickness

6-1 Philosophy

In the case of insulation of steam tubes etc., a most economical thickness exists for the thickness of the thermal insulation. In other words, when the insulation thickness is too large, this is economical from the point of view of thermal economy, but the work expense load increases. Reversely, when the insulation thickness is reduced, the work expense load is smaller, but the heat loss increases. Theoretically, there is an insulation thickness where the total of heat loss and work expense load becomes a minimum, and this is called the economical insulation thickness. Figure 12.7 shows an example for the change of the heat loss and the work expense load when the insulation thickness is changed.

Figure 12.7 Insulation Thickness and Yearly Expenses



As shown in this figure, there is an insulation thickness where the total of heat loss and work expense load becomes a minimum. The Japanese Industrial Standards (JIS) list calculation formulas for the economical insulation thickness, and the results for calculation of the economical insulation thickness are listed for several insulation materials on the basis of given preconditions. At the Energy Conservation Center Japan, a work sheet for calculation of the economical insulation thickness for various preconditions has been developed on the basis of the JIS philosophy. For these investigations, this calculation sheet has been used for the insulation calculations.

## 6-2 Explanation of the Calculation Sheet

### a) Calculation of the radiation loss value

The heat loss quantity by radiation is calculated using the heat transfer calculation formula. The thermal conductivity of the insulation material is expressed by a third-order equation, and the coefficients of this third-order equation are read in by selection of the material. The loss value is calculated as the product of the radiation quantity and the heat unit price.

The heat unit price is not the heat unit price of the fuel, but for example in the case of a steam tube, it is the steam heat unit price lost by emission.

### b) Calculation of the work expense load amount

The work expense load amount is obtained by multiplying the work expenses with the yearly amortization rate. The work expenses for insulation work are given by equation (23) according to the JIS.

$$P = 1.2 (12,000 X^{-k} + 100) \quad [1,000 \text{ ¥/m}^3] \quad \text{Equation (23)}$$

where X : Insulation material thickness (mm)

k : The value of the following table

Tube outer diameter (inch)	k
1/2 to 3/4	1.09
1 to 2	1.13
2½ to 6	1.17
8 to 12	1.21
14 to flat surface	1.28

### 6-3 Calculation Method

On the work sheet, the radiation loss value obtained by the above calculation and the formula for the total amount of the yearly work expense load amount are differentiated by the thickness of the insulation material. Then the insulation thickness where the value of the differential coefficient becomes zero is the economical insulation thickness to be obtained. However, as this value can not be obtained as the solution of a numerical equation, the work sheet calculates an approximate solution by repeated calculations.

#### a) Use of the calculation sheet

First, the various preconditions are set, and then the calculations are executed by the macro. The conditions to be set are the numerical values enclosed in a bold frame of the work sheet screen shown in Figure 12.8. The outer diameter of the tube and the insulation material are set by selection from the menu.

Figure 12.8 Setting Screen for the Economical Insulation Calculation

```

Economically optimum insulation SI(Wh unit)
<Premises---Pipe/Surface> <Pipe> (¥R:calc) 03/24 16:24
Eco thickness Xp 0.055 m
O.D of insulation do 0.275 m
I.D of insulation di 0.1652 m
Annual expense Fp 2439 ¥/year
Heat loss / hour Qp 78.4 /m/h
Surface temp th.pc 27.5 deg C
H. conduct'y (avg)ramda.p 0.0521
Insul'n work pric ap 233 th.¥/m^3
Insul'n material Calcium silicate 1-13
* : Be aware of unit

Macro command:
¥A Menu
¥U Unit select ¥P Print
¥G Graph call ¥X Line
¥L Protect Free


<Plane surface> (¥S:calc) 03/24 16:24
Eco thickness Xs 0.078 m
Annual expense Fs 3170 ¥/year
Heat loss / hour Qs 82.0 /m^2/h
Surface temp th.sc 26.8 deg C
H. conduct'y (avg)ramda.s 0.0520
Insul'n work pric as 174 th.¥/m^3
Insul'n material Calcium silicate 1-13

```

### 6-4 Calculation Method

The Lotus 123 function for easy parameter study - What-if study - is used, and various characteristic analysis tables have been prepared. One of the most interesting points with the characteristic analysis is the relation between the heat unit price and the economical insulation thickness, and an example for this calculation is shown in Figure 12.9.

Figure 12.9 Heat Unit Price and Economical Insulation Thickness



(7) Calculation of the Radiation Quantity from the Surface Temperature

When the surface temperature of a body is known, the emission amount can be calculated from equation (24).

$$q = \alpha(t_r - t_p) \quad [\text{kcal}/(\text{m}^2 \cdot \text{h})] \quad \text{Equation (24)}$$

As heat transfer from the surface of a body is executed by convection and by radiation, so the heat transfer coefficient of equation (24) is the sum of the heat transfer coefficients of convection and radiation. In the report, the above explained equations for the convection heat transfer coefficient and the radiation heat transfer coefficient are used to calculate the heat transfer quantity when the surface temperature is given.

(8) Appendix Table

The appendix table shows the length of a tube with the same diameter, which has the same surface area as a valve or a flange. For example, the surface area of a 2" globe valve for 20 bar is the same as that of a 2" tube with a length of 1.28 m.

**Equivalent Pipe Length to Valve or Flange (Unit: m)**

<b>Piping Parts</b>	$\frac{1}{2}$	$\frac{3}{4}$	1	$1\frac{1}{2}$	2	$2\frac{1}{2}$	3	4	5	6	8
Flanged Globe Valve (10bar)	1.15	1.06	1.22	1.11	1.11	1.23	1.25	1.27	1.40	1.50	1.68
Flanged Globe Valve (20bar)	1.24	–	1.21	1.20	1.28	1.50	1.56	1.58	–	1.78	1.87
Flanged Sluice Valve (10bar)	1.12	0.98	1.15	1.31	1.22	1.16	1.31	1.20	1.27	1.35	1.52
Flanged Sluice Valve (20bar)	1.29	1.13	1.32	1.23	1.53	–	1.63	1.50	–	1.92	–
Pressure Reducing Valve (10bar)	1.96	1.71	1.67	1.49	1.55	1.60	1.66	1.58	1.91	1.76	1.81
Control Valve (10bar)	–	1.72	1.84	1.56	1.60	–	1.54	–	–	1.48	–
Flange (10bar)	0.50	0.46	0.53	0.47	0.44	0.42	0.42	0.39	0.44	0.45	0.44
Flange (20bar)	0.51	0.46	0.54	0.47	0.49	0.46	0.50	0.46	–	0.56	0.51





