

AN UNFINISHED MANUSCRIPT!

EROSION CONTROL
AND
TORRENT IMPROVEMENT

March, 1980

Japan International Cooperation Agency

AN UNFINISHED MANUSCRIPT!

EROSION CONTROL
AND
TORRENT IMPROVEMENT

JICA LIBRARY



1015011[8]

March, 1980

Japan International Cooperation Agency

国際協力事業団	
輸入 月日 84.5.23	000
登録No. 07130	61.7
	FDD

マイクロ
フィルム作成

TABLE OF CONTENTS

CHAPTER 1	EROSIONS IN MOUNTAINOUS AREAS.....	1
Section 1	Erosions in Mountainous Areas and Wild Torrent	1
Section 2	Primary and Provocative Causes of Erosion	2
1	The Primary Causes and Their Dominant Factors	3
2	The Provocative Causes and Their Amount	7
Section 3	Sheet Erosion.....	8
1	Development of Sheet Erosions	8
2	Sheet Erosion Volume	10
Section 4	Landslide.....	11
1	Generation and Classification of Landslide	11
2	Surface Layer Landslide	12
3	Deep Layer Landslide	14
Section 5	Landcreep	15
1	Classification and Characteristics Landcreeps	19
2	Generation of Landcreeps	20
Section 6	Debris Flow	22
1	Generation of Debris Flow	23
2	Characteristics of Debris Flow	24
CHAPTER II	FOREST EFFECT ON DISASTER PREVENTION	27
Section 1	Forest Effect on Disaster Prevention and Its Characteristics	27
Section 2	Forest Effect on Windbreaks	29
1	Inland Windbreaks	29
2	Coastal Windbraks	32
Section 3	Forest Effect on Erosion Prevention	33
1	Forest Effect on Surface Erosion Prevention	34
2	Forest Effect on Landslide prevention.....	36
Section 4	Forest Effect on Runoff Regulation	38
1	Hydrologic Cycle and Rainfall Effluence	38
2	Forest Effect on Flood Control and Water Sources Conservation	40

CHAPTER III	DESIGN AND EXECUTION OF HILLSIDE WORK	46
Section 1	The Design of the Hillside Works	46
Section 2	Planning the Hillside Work	47
Section 3	Surveys for Planning the Hillside Works.....	47
Section 4	Types of Hillside Works.....	48
Section 5	Hillside Foundation Works	52
	1 Grading Work	52
	2 Hillside Retaining Work	53
	3 Buried Work	62
	4 Drainage Work	63
Section 6	Hillside Seeding and Planting Work	71
	1 Sodding Work.....	72
	2 Simple Terracing Work	74
	3 Covering Work.....	78
	4 Seeding Work.....	81
Section 7	Planting Work.....	87
	1 Planting Plan	88
	2 Planting and Management	91
CHAPTER IV	TORRENT IMPROVEMENT WORK	93
Section 1	Basic Hydrolics for Torrent Work	93
	1 Hydrostatic Pressure	93
	2 Stream Flow Velocity and Sand Pebble Movement	96
	3 Flow Velocity Measurement	107
Section 2	Objectives and Types of Torrent Improvement	111
	Work	
	1 Objectives of Torrent Improvement Work	111
	2 Types of Torrent Improvement Work	112
Section 3	Check Dam (Sand Check Dam or Sediment Control Dam)	113
	1 Objectives and Types of Check Dams	113
	2 Location and Direction of Check Dams	120
	3 Design Accumulating Gradient and dam Height	123
	4 Overflow Section and Wings.....	127
	5 Dam Sections and Conditions of Stability	135
	6 Drainage Hole	143
	7 Protection from Scour	145
	8 Volume Calculations of parts of a Dam.....	149
	9 Dam Construction.....	152

Section 4	Bed Still Work	165
Section 5	Revetment, Groyne, and Channel Works	168
1	Retaining Wall Works	168
2	Gloyne Works	171
3	Channel Works	174
CHAPTER V LANDCREEP PREVENTION		179
Section 1	Landcreep Investigation	179
1	Existing Data Collection	179
2	Weather Research	179
3	Topographic Survey	180
4	Geological Survey	181
5	Ground Surface Shift Survey	183
6	Sliding Surface Survey	185
7	Ground Water Survey	187
Section 2	Landslide Prevention Work	189
1	Slope Stabilization	189
2	Landcreep Prevention Work Plans	190
3	Landcreep Prevention Work	191

CHAPTER I EROSIONS IN MOUNTAINOUS AREAS.

Section 1 Erosions In Mountainous AREAS and Wild Torrent

Erosions in mountainous areas may be classified into the following in accordance with their types and generation sites.

Hillside Slopes

Sheet Erosions

Landslide, Landcreep

Stream Beds

Debris Flow

Tractive Transportation

Soil Production is generated by surface erosions, landslides, landcreeps, etc. from hillsides are transported over torrentbeds until the majority become accumulated in the alluvial cone down the torrent.

Additionally, soil accumulated on the torrentbed become eroded by debris flow as well as the flow of water (tractive force), and the transported downstream. Drainage basin where this type of earth and soil movements occur may be segregated into the production zone, the transportation zone, and the sedimentation zone as illustrated in diagram 2-1. Torrents are therefore often devastated by the aforementioned earthfall generated with the hillside erosions in the soil production zone. Such Streams are called wild torrents. The torrentbed sediment in torrents are vigorously agitated in the form of debris flow, and often cause disasters downstream by transporting immense volumes of sediment. The transportation zone is

the span of torrent between the production zone and the sedimentation zone where only sediment transport occurs. The sedimentation zone is in the form of alluvial cones by the deposited earth and sand from upstreams. These alluvial cone areas often become disaster sites since they are widely employed by mankind. In actual drainage basin, though, these aforementioned three zones are often not in order, and are connected with rivers downstream in orders such as the production zone to the sediment transport zone or in orders the production zone to the sedimentation zone.

Diagram Classification of Wild Torrent Drainage Basin

The Sedimentation	The Transportation	The Production
Zone	Zone	Zone

Section 2 Primary and Provocative Causes of Erosion

The ratio and volume of erosion may be thought to be determined by the relative amount of the erosion generation effect (the volume of the provoking cause, force of erosion and the erosion resistance of the ground or erodibility the volume of the primary cause). The main factor of erosions is precipitation, and the erosion resistance is determined by the condition of the ground surface.

1. The Primary Causes and Their Dominant Factors

Primary causes are elements such as geological structure, topography, soil, and forests which determined the erodibility of the land. The topography mainly effects through slopes, and the steeper the slope, the more erodible it is for both sheet erosion and landslides. Soil characteristics are mainly dominated by the parent rock since soil is a weathered form of the parent rock. In general, viscous soil with greater cohesion exhibit better erosion resistance than sandy soils. Forests greatly reduce erosions with its great functions to protect the soil surface and to secure surface soil with roots. Therefore, erosions are increased when landscapes become bare by timber drain. Smoke damaged lands and bare hills are some of the examples of the aforementioned phenomenon. Erosions are caused by rock in the final stage crumbling into pebbles and being washed away. Therefore, the geological structure of the land greatly effects erosion. The following two factors describe the potentialty of erodible land. The first is the land being comprised of highly erodible mediums, and the second is when rockes have been transformed into clay and granules. The latter is caused by rock alteration. Terrain comprised with volcanic clastic waterials is an example of naturally poor erosion resistance areas. Volcanic clastic materials are comprised

of volcanic ash, volcanic gravel, and pumice, etc. and are extremely erodible. Large scale volcanic gullies where valley walls have fallen and wild torrents with large volumes of earth transported in the form of debris flow over found in volcanoes and their vicinity. Furthermore, the Tertiary Green Tuff display poor cohesion characteristics being volcanic ejecta, and therefore are highly erodible. Landcreeps and landslides often occur in Green Tuff regions. The change of rocks in the lithosphere into granules and clay are called alteration. This alteration may be segregated into the cataclastic deformation and the hydrothermal alteration. On the other hand, the transformation of rocks into granule within the atmosphere is called weathering, and may be segregated into physical, chemical, and biological weathering processes. Cataclastic process among other forms of alterations, is always accompanied by weathering, and this combination greatly facilitates erosion of rocks.

1) Alteration of Rocks

(1) Cataclastic Process

This is the process where sub-surface rocks are destroyed by immense force under low temperature and pressure. Hereby, these rocks are transformed into so-called fractured rocks. For example, rocks such as shale are broken into small phyllite forms and become

black coloured clay. On the other hand, hard sandstones and granite are broken into block forms. Rocks which are broken physically by cataclastic process often weather chemically and become clay. The area which underwent cataclastic process generally have an expanse with a certain length and width. This expanse is called the fractured zone. This fractured zone appears in coincidence with the geological structure belt. Therefore, mountainous regions along the geological structure belt are highly erodible, and exhibit significance in large scale landslide and landcreep occurrences. Rocks along this geological structure belt are broken and weathered throughout the region, causing landslides and landscreeps as well as wild torrents.

(2) Hydrothermal Process

Rocks in volcanic regions are transformed at times by hydrothermal alteration. These phenomena may be observed in hot springs. Rocks in hydrothermal alteration zone are chemically transformed by high temperature gas mainly comprised of hydrogen sulfide, sulfur, and steam into clay named hydrothermal deposit or sulfataric clay, exclusive of this region. This clay at times become the cause of landslides.

2) Weathering of Rocks

(1) Physical Weathering

Physical weathering may be segregated into temperature variation as well as freezing and thawing. Rocks are destroyed by the repetition of contraction and expansion when excessive temperature variations occur since the individual minerals contained exhibit different thermal expansion rates. This phenomenon occurs in areas where the temperature varies greatly during the day and night. Additionally, rocks are also destroyed by the repetition of freezing and thawing of water seeped in cracks since congealed water generates cubic expansion. This phenomenon is the main cause for sub-surface rocks to become destroyed along joints.

(2) Chemical Weathering

Chemical weathering may be segregated into oxidation, hydrolysis, and resolution. Cubic volume become increased during alteration by oxidation, and destruction become facilitated since large amounts of iron are contained in rocks. This form of weathering is called oxidation. Hydrolysis is a phenomenon where minerals become structurally transformed by water. This phenomenon plays an important role in the weathering of granites. Rainwater contains large amounts of carbon dioxide which resolve the mineral ingredients

of rocks. This form of weathering is called resolution. This phenomenon is most significant in lime stone terrains, where karst topography exclusive of such areas are generated.

(3) Biological Weathering

Plant roots penetrate cracks and mechanically destroy rocks. Additionally, carbon dioxide produced by plant putrefaction and respiration are dissolved with rain water which facilitate chemical weathering.

2. The Provocative Causes and Their Amount

Sheet erosions and sediment are proportional to the intensity and amount of rainfall. On the other hand, erosions in the form of landslides as well as debris flows do not necessarily occur frequently in heavy rainfall regions, but is greatly ruled by the amount of rainfall beyond the extent of the region's normal rainfall intensity. From these points, the probable rainfall described by the return period exhibit great importance.

Snowfall, earthquake, and wind are some of the provoking causes other than rainfall. Snow deposits become avalanches which generate surface erosions and landslides. A side from the generation of avalanches, snow deposits carry away earth along with the flood of melted snow. Those countries in Circumpacific Volcanic Zone are noted for earthquakes,

and large magnitude earthquakes have been experienced. Earthquakes directly cause landslides as well as it is thought to be an indirect cause, by generating fissures in rocks. Drifting sand are caused by the wind in sandy regions and shifting of beach sand dunes occur.

Section 3 Sheet Erosion.

Bare-lands are eroded by rainfalls as though the individual top soil layers are peeled away independently from the surface layer in ward. This form of erosion is called sheet erosion, and is exclusive in that the individual soil particles are washed away independently by water. Sheet erosions are frequently found on bare mountains as well as observable in granite and Tertiary period Layer hills. Other than the aforementioned, excessive sheet erosions may be seen in bare lands around volcanoes and landslide sites. Furthermore, sheet erosions are becoming more evident in artificial bare-lands produced by developments in recent years.

1. Development of Sheet Erosion

Two regions may be observed from the top and bottom of slopes in sheet erosion generation areas. The first is the region where erosion takes the form of uniformed removal of top soil. The other is observable in the lower regions where erosions are concentrated in the highly evident concave water-paths. The first type is called sheet erosion region and the other

is called the rill erosion region (gully erosion region).

The volume of erosions caused by rill erosions are considerably larger than those of sheet erosions, and gullies are developed within a short period of time.

Sheet erosions are greater with larger surface run-offs on the ground surface. However, though, it is necessary to understand that raindrops play an important role in generation of ground surface flows. Raindrops clamp, mix up, and splash upon contacting the ground, clamping and splash are the important effects among the three. Narrow gaps between soil grains form paths for raindrops from the ground surface.

These two effects clog the aforementioned paths with soil grains forming a thin soil horizon which prohibits the infiltration of rain water. Hereby, surface run-offs become increased considerably.

Surface erosion volumes are relative to the water depth and the flow speed, and is considerably increased when the discharge becomes large. Therefore, uneven surface slopes emerge. Discharge larger in convex regions where the rate of erosion becomes immensely increased. These phenomena generate further concentration of rain water which accelerate erosions and gully generations.

2. Sheet Erosion Volume

Sheet erosions occur not only on bare-lands, but also on terrains with incomplete surface overlay. Therefore, top soil move slightly by sheet erosions even in woods and grass lands. Additionally, erosion volume differs greatly depending on the topography, soil, and climate even in terrains with similar surface cover. Chart 2-2 describes the approximate annual volume of erosion on a slope with is degree incline. Woods and grass lands exhibit the lowest figures. However, woods with incomplete overlay present poorer characteristics than well covered grass lands. Erosion volumes therefore are greater in prescribed burning lands and grazing forests than well conditioned grass lands.

Chart	Approximate Annual Erosion Volumes In Accordance With Surface Covering Types			
	Devastated Land	Bare Land	Farm Land	Grass Land Wood Land
Surface Covering Annual Soil Erosion Volume	10^2	10^1	10^0	10^{-1}
	10^1	10^0	10^{-1}	10^{-2}

Section 4 Landslide

1. Generation and Classification of Landslide

The phenomena where a part of the hillsides slopes lose stability resulting massive instantaneous downward movements of earth and sand is called landslide. Velocity of landslides vary greatly from small 10m^2 to large scale landslides in excess of 10ha. Additionally, the thickness of earth fallen by landslides vary from under one meter to over ten meters. Landslides which frequently occur in mountainous regions by heavy rainfalls are of minimal scale individually, but become a cause for disasters when the occurring plots become excessive. On the other hand, large scale landslides, occur at times in mountains at the final stage of rainstorms. Such landslides may cause excessive disasters individually. The predominant provocative cause of landslides may be said to be rainfalls, but it should not be forgotten that melting snow and earthquakees often also cause landslides. Landslides in this literature are simply segregated into surface and deep layer landslides although landslides are actually classified into various types. Surface layer landslides are when surface soil in the tree root penetration layer or slightly deeper depth collapse and fall, whereas deep layer landslides are when rocks including undering rocks in deep layers mountains collapse and fall. It is certain that landslides possessing intermediate type of the

two aforementioned types frequently occur, but it should also be noted that most of the two types of landfalls exhibit different characteristics. Surface landslides are mainly caused by the surface condition (form) of hillside sloped, and the earth causing landslides are mainly comprised with soil produced by rock bed surface weathering. These types of landslide are greatly effected by the intensity of rainfall. On the other hand, deep layer landslides often are deeply related to the geological structure of mountainous bodies, where cataclastic process as well as weathering in the depths of rock beds often relate to the formation of brittle zones in rock beds which become sources of landslides. Furthermore, generation of collapses are closely related to the total amount of rainfall.

Diagram (1) Surface Layer Landslide

Diagram (2) Deep Layer Landslide

2. Surface Layer Landslide

Diagram 2-6 describes an example of a rainstorm which generated a landslide. The graph indicates the danger of landslide generation when water saturated surface soil take on additional strong rainfall. Debris flows are often generated in the lower spurs to torrents when surface landslide occur on hillside slopes.

The following facts are known about the generation of surface landslides on hillside slopes.

- 1) Occurs in the wide range between gentle slopes of 20 degrees to steep slopes of 45 degrees regardless of the geological structure.

Diagram Relation Between Rainfall and Landslides
 In Kobe (Surface Landslides) (Hosono)

- (i) Total Rainfall
- (ii) Hourly Rainfall
- (iii) Number of Landslides
- (iv) 9 July 1967

- 2) Majority of landslides occur within sunken regions of hillsides, and the points of generation are mostly near the inflection points of slopes.

- 3) Landslide generations tend to increase considerably in cutover areas.

Surface landslides are when parts of the surface soil lose dynamic stability by the flow of rain water generated temporarily within the surface soil, and become fallen out. Almost all rainfall are absorbed into the ground in forests since permeability is great in such regions. Therefore, majority of rain water are transmitted into the depth of the earth during normal rainfall. However, when aquiclude

exist below ground surface, the increased amount of rain water during rain storms generate a flow of rain water toward the slope with this layer as a border. This rain water flow destroys the dynamic stability of the soil horizon, and generates catastrophe. Catastrophes are easily caused particularly in places where the water discharge appears out to the ground surface in mid-hillsides.

3. Deep Layer Landslide

Parts of the mountainous body at times may fall from areas with reduced strength of rocks such as fractured zones where rocks become altered as well as in the depth of rock beds where rocks become weathered. This type of landslide is larger in scale than surface landslides, and occur regardless of the topography. This type of landslides exhibit similar features with landslides described in the following section, in that slippage generation exist within the rock bed as well as the relation of the ground water movement with the generation of catastrophe. Deep Layer and falls generated in fractured zones which can not be clearly segregated from landcreeps are at times called landcreeps type landslides. Furthermore, landslides accompanying large amounts of ground water eruption at the point of catastrophe may be observed. In such case, one of the causes for catastrophe is thought to be the increased amount of ground water

from rain storms which destroy and seal the ground water routes, and therefore producing excessive hydraulic pressure within the mountainous body.

The following precautionary phenomena similar to landcreeps may be observed at the generation of this type of landslide:

- 1) Mud mixture and change in the discharge volume of ground water may be observed.
- 2) Minor falls may be observed in spurs and points of ground water discharge.
- 3) Cracks are generated in hill sides.

Section 5 Landcreeps

Landcreeps are when fairly large areas of the ground creep slowly downward by ground water effects, etc. Landcreeps are observable throughout Japan. Landcreeps may be considered as a form of deep layer landslide with a particular style of movement in the broad sense.

Chart 2-3 lists the differences between landcreeps and landslides.
falls

Chart Landcreep and Landslide Comparison Table

	Landcreep	Landslide
Geological structure	Frequently generated in particular geological structure areas.	Minimal relation with geological structures.
Soil Nature	Slides mainly with viscous soil as the sliding plane.	Frequently occurs in sandy soil such as <u>MASA</u> , <u>YONA</u> , and <u>SHIRASU</u> also.
Land Features	Occurs in gentle slopes with 5 to 20 degrees incline. Most frequently observed in areas with upland type terrain above.	Frequently generated in steep aloses with incline in excess of 20 degrees.
Activity Condition	Continuous Recurring	Sudden
Movement Speed	Generally slow. Mostly 0.01-10mm/day.	Fast. Over 10mm/day.
Clod	Minimal clod distortion. Usually moved while maintaining the original form.	Clod become deranged

	Landcreep	Landslide
Provocative Cause	Effected greatly by ground water.	Rain fall. Particularly effected by the intensity of rain fall.
Scale	Large. $10^4-10^6 m^2$.	Small
Precursory Signs	Generation of cracks, subsidence, Protuberance, and ground water differentiations	Minimal precursory signs. Generally occur suddenly.

Many of the landcreep generation areas are sites where previously occurred landcreeps and deep layer landslides have recurred. Therefore, entirely fresh landcreep generations are relatively minimal.

Landcreep regions usually exhibit exclusive topological features called landcreep terrain. (Creeping land).

Diagram	Individual Landcreep Terrain Names (Sankaido, Yamada, Watamasa, Kobashi, "Realities and Countermeasures of Landslides and Slope Disintegration")
(a) Sliding	(b) Secondary cliff;scrap
(c) Toe	(d) Crown
(e) Summit	(f) Top part

- | | |
|----------------------|-----------------------------|
| (g) Sliding Plane | (h) Spur |
| (i) Tip | (j) Toe Edge |
| (k) Tension Fracture | (l) Compression Fracture |
| (m) Sunken Ground | (n) Compression Fracture |
| (o) Side | (p) Original Ground Surface |

Sliding cliff or scrap are found in the TOHBU of landslides, with sunken and level terrain immediately below, followed by gentle slopes. This Sliding cliff and the sunken terrain below are exclusive of land slide terrains. Ground water eruptions are usually observed in the sunken terrain, and often comprise awamps, marshlands, and ponds. There Sliding cliff and ground water eruptions are clearly evident in the early stages of landcreeps, but become less noticeable over prolonged periods of time since Sliding cliff become disintegrated, and as ground water eruptions become covered with debris which fill the sunken land. Secondary and third land slides occur once a landslide terrain is formed, and the number of Sliding cliff and level planes become increased, resulting in the formation of scalariform terrain. Crevice are caused by tension in the vicinity of Top-sliding cliff and by compression in the end regions during the initial movement stages of landcreeps. Furthermore, a particular type clay called landcreep clay are found in the underground sliding plane.

1. Classification and Characteristics Landcreeps

Majority of landcreep cases are found in specific geological structure areas.

Diagram Creeping Land

Majority of landcreeps are distributed among the Tertiary period layers, fractured zones, and hydrothermal alteration regions since these areas feature natural diathesis for landcreep generation.

1) Tertiary period Layer Landcreeps

Since formation of Tertiary period Layer was relatively recent, and therefore, rocks of this layer are soft and exhibit poor coagulability. Additionally, tertiary period layers exhibit excessive weathering and are easily transformed into clay since diastrophism was excessive during this period. Therefore, this layer may be considered to possess ample diathesis for landcreep generations. 70% of landcreeps in Japan are concentrated in this tertiary period layer. On the contrary, landcreeps are not generated throughout the tertiary period layers, but tend to be concentrated in specific layers of the Miocene epoch.

2) Fractured Zone Landcreeps

This type of landcreeps are generated in fractured zones along the geological structure belt, and are also frequently

generated along minor geological structure belts.

Generally, mountains where this type of landcreeps are found exhibit steep inclines, and often cause catastrophic landcreeps during heavy rainfalls. Normal creepage is minimal, and is only few centimeters per year. Therefore the danger of landcreeps are often undetected in this type.

3) Hot Spring Region Landcreeps

This type of landcreeps are caused by hydrothermal alterations, and are generated in volcanic and hot spring areas. Landcreeps movements of this type tend to be vigorous, and exhibits great dangers of disasters once slippage occurs.

2. Generation of Landcreeps

Several provocative causes are inter linked when landcreeps are generated. Provocative causes are mostly natural, such as rainfall, but anthropic causes are increasing along with the progression of developments in recent years.

1) Natural Provocative Causes

Rainfall increase the moisture content of the sliding plane and greatly reduce the resistance as well as soften the landcreeps clod and facilitate vigourous flows.

Additionally, rainfall generates increased intra-

landcreeps clod ground water pressure which further increase the pore water pressure, and adds to the generation possibilities of landcreeps. On the other hand, the amount and strength of rainfall are not directly related to the creep speed and generation of landcreeps, and their relations between the cause and effects are complex. Fractured zone landcreeps are often caused by heavy rainfall, and landcreeps in high flow rate tertiary period layers are generally generated in conjunction with extended rainfalls. Melting snow exhibit identical effects to the aforementioned extended rainfall. Furthermore, earthquakes often generate landcreeps. Aside from the aforementioned, landcreeps are also generated by stream bank erosions where slope edges become washed away.

2) Anthropic Provocative Causes

Stability of the clod become disrupted, and commence creepage when anthropic factors effect slopes barely maintaining stability. For example, landcreeps are generated by the cutting of slopes and excavation of tunnels during road work. Additionally, landcreeps are also generated by addition of fresh loads caused by embankments and erection of structures. Other causes which are relatively frequently observed aside from the aforementioned are landcreeps generated by the change in ground water within surrounding hillsides due to submersion of

dams as well as by the up and down quakes of the dam water level.

Section 6 Debris Flow

Debris flow is a phenomenon where debris are washed down streambeds along with water. Large and small pebbles of various sized debris are intermixed with water and are washed downstream. Such form of sediment movement is called the massive transportation or mass movement. On the contrary to this phenomenon, in normal soil flow, the individual gravel on the streambed are transported by tractive force. This form of gravel movement is called the individual transportation. Massive boulder movements of boulders found on streambeds in water depths equivalent to, or shallower than the size of boulders cannot be explained with the general soil flow terms based on tractive force. Additionally, debris flows exhibit exclusive characteristics in their velocity of impact as well as movements in the bends of streams. With the aforementioned factors in consideration, debris flow are defined clearly apart from regular soil flow, and are exclusive in their unification with water. Furthermore, it should be noted that the intermixture ratio of debris against water vary among what are so-called debris flow.

1. Generation of Debris Flow

Generation of debris flow may be widely classified into the following:

- 1) Soil silted on steep incline streambeds are suddenly motivated with the current caused by heavy rainfall and become debris flow. Normally, water discharge are below the silted soil, but appear on the ground surface when the silt become water logged during heavy rainfall. Hereby, the silt become rapidly loosened, and debris flow are generated.
- 2) The fallen earth produced by washouts during heavy rainfall are combined with effusion water and are rushed downstream to become debris flow. Large scale catastrophes such as valley throat (YATOH/KOKUTOH) erosions often become rapidly washed down and transform into debris flow. Often in such cases, the devastation by debris flow are not only caused by the impact of the fallen earth, but by the combination with the loosened silt washout. Debris flows are also generated by the downstream silt washout caused by the impact of intercepting earth which are rushed downstream at the collapse of fallen earth temporarily clogging the stream.
- 4) Aside from the aforementioned, debris flows are known to be generated by the loosening of viscous landslides

as well as by volcanic activities.

2. Characteristics of Debris Flow

Debris flows exhibit the following characteristics:

- 1) Debris flow exhibit an exclusive form with large boulders at the head while being washed downstream as illustrated in diagram

Diagram Flow Condition in Mt. Yake
(Ministry of Construction Schematic)

- (a) Prior Generation
- (b) Forward End
- (c) Intermediate Zone
- (d) Rear End
- (e) After Passage
- (f) Ten Seconds
- (g) Ten Minutes
- (h) Ten Minutes

-
- 1) Debris flows have been generated by massive volcanic ash and pumice effused by volcanic activities being washed out by rainfall (Sakurajima), or by snow melted by volcanic activities effecting the terrain likewise heavy rainfall. This type is often called mud flow. (Mt. Tokachi/1925)

- 2) The speed of debris flows are determined by the mixture ratio between debris against water as well as the incline of streambeds, etc. Additionally, they vary in accordance with the positions of generation, progression, declination, and dissipation of debris flows. Flow speeds vary from slower 1 - 2 meters per second to faster flow with speeds in excess of 20 meters per second. Flow speeds of large scale mud and stone flows cannot be reduced with several check dams, but minor debris flows are simply brought to a stop on a single check dam.
- 3) Debris flows are mostly generated on streambeds with incline in excess of 15 degrees.

Diagram Debris Flow Silt

Debris flows come to a natural halt when the incline reduce to less than 10 degrees, and begin to form debris flow deposite. Large boulders are often found in the advancing end of these deposite (Diagram Additionally, debris flows including cobbles are hardly found in regions with less than 5 degree incline.

- 4) Debris flows exhibit strong strait-line movement characteristics, and therefore destroy and overcome

obstacles during advancement. This phenomena indicates that debris flow possess abundant inertia. Water level difference may reach 3 - 4 meters between the in and out sides of the flow in bends of streams. Therefore, large boulders are often left on the outer side hillsides.

- 5) U-formed valleys exclusive of streambeds after the passage of debris flows are formed.

Chapter II FOREST EFFECT ON DISASTER PREVENTION

Section 1 Forest Effect on Disaster Prevention and It's characteristics

Trees may be considered to be live green structures with foundations in the ground. On the other hand, trees improve and secure their base of living which is the soil. This phenomenon becomes greatly strengthened in a gathering of trees which is the forest. Therefore, environment of surroundings terrains and atmosphere become greatly effected. The following describes the disaster preventative factors among the various phenomena observed in forests.

Forests function likewise to large surface structures, and therefore, large atmospheric movements are precluded which in turn reduce the wind speed in the vicinity. This effect is called the windbreaking effect of the forest. Windbreaks, snowbreaks, and shifting sand control forests are made using this effect. Furthermore, fog prevention forests are made as well as increased rainfall functions are generated with the atmospheric movement preclusion effect as well as the function to hold intra-atmospheric moisture of the forest. On the other hand, tree trunks of forests are used somewhat like protection fence for coastal salty wind protection, flood prevention, and avalanche prevention forests. Furthermore, the obstacle effect of forest crowns are employed for firebreaks and sound shields.

Forests produce a silting layer on the ground surface comprised of organic substances, which protect the ground surface and soften the top soil, making it fertile. Additionally, the top soil become stabilized and secured with the penetration of roots in the sub-surface layers of the ground. Humus and defoliation on the ground surface prevent surface erosion generations by rainfalls and ground surface flows. Furthermore, surface soil stabilization by roots prevent land falls and falling rocks. Moreover, the soft and porous forest surface soil facilitate rain water infiltration which in turn decrease the flood discharge volume, and enhance water sources conservation. These phenomenon is called the water regulation effect of the forest.

Disaster prevention utilizing forests are considered to be highly useful as described in the following:

- 1) Large areas may be covered with forests. Erosion prevention in mountainous regions as well as water conservation and run off regulation may be accomplished with sand arresting structures or check dams, but abundant effects may be attained in large areas with forests although the individual forest effects may be small.
- 2) Forests may be produced at far less cost than architectural structures since they grow.
- 3) Forests planted for disaster prevention often are beneficial for environmental preservation as well as timber production.

4) The largest of the forest effects is the "OVERALL FOREST EFFECT". Forests provide multiple disaster prevention effects simultaneously as well as function as a source for timber production, environmental preservation, insurance and recuperation, etc. These effects may be individually accomplished by subsidiary measures, but the true importance of forests lie in this overall effect.

The aforementioned are the disaster prevention effects of the forest. On the contrary, though, it must be noted that these effects must not be overestimated. This precaution is due to the forest foundation lying in the sub-surface depth of 1 - 2 meters below the ground.

Section 2 Forest Effect on Windbreak

The utilization of forests as windbreaks may be segregated into inland (farmstead) and coastal windbreaks. Coastal windbreaks also function for shifting sand control, fog prevention, and salty wind prevention.

1. Inland Windbreaks

Tree belt width of inland windbreaks are generally narrow and the number of planting rows are less than seven. Additionally, the width is considered to be most efficient at 30 meters including renewal areas. Intra-forest ventilation effect become reduced when tree belt widths are excessive, resulting in decreased wind retardation areas.

The most ideal plantation of tree belts are in the right angle against the main wind, employing evergreen trees. Major windbreak effects of forests appear in the lee side, but are somewhat attained in the windward side also. The size of windbreaking zones are closely related to the check of forests.

When the forest density is large as illustrated in diagram 3-1 (b), ample wind retardation effects are attained.

Hereby, air eddies are formed in the lee side, and the wind blown over the tree belt become rapidly lowered. With this reason, the windbreaking effect distance become shortened.

On the other hand, in ideal density tree belts as illustrated in (a), portions of the wind are blown through with the rest blown over the tree belt. Air eddies therefore, are not generated in the lee side. Wind speeds may not be considerably decreased in such case, but the tree belt filters the wind, and therefore, windbreaking effects are attained over a large area.

Diagram

- (a) Ideal Density Tree Belt
- (b) Overcrowded Tree Belt
- (c) Wind Current In The Vicinity
- (d) (h) is the tree height

(by TOKUJI KASHIYAMA)

Ideal density is a condition where trees hold approximately 60% of the area when viewed from the front with averaged openings.

Diagram illustrates the windspeed measurements taken at about one meter off the ground which is the determination factor for the employment of windbreaks.

Diagram

- (a) Windspeed Rate (%)
 - (b) Wind
 - (c) Ideal Density Tree Belt
 - (d) Overcrowded Tree Belt
 - (e) Defoliated Tree Belt
 - (f) Tree Belt
 - (g) Distance From The Tree Belt
(Multiple of Tree Height)
 - (h) Windspeed Reduction Effects of Narrow Tree Belts
(Approximately 1 Meter Off The Ground)
- (TOKUJI KASHIYAMA)

The diagram illustrates the difference in the windspeed with and without tree belts in the form of ratio. Windspeeds are lowest in the ideal density tree belt, where the windspeed is reduced to about 30% at a distance equivalent to three to five times the height of the tree belt. Additionally, it may be observed that windbreak effects are recognized

in distant zones twenty times the height of the tree.

Furthermore, windbreak effects are also recognized in zones three to five times the height of the tree in the windward side of the tree belt.

This windspeed transition effect of windbreaks prevent near ground surface and ground surface temperatures from dropping as well as prevent atmospheric humidity reduction. Furthermore, effects such as reduction of water evaporation from the ground surface and weathering prevention are attained.

2. Coastal Windbreaks

Coastal windbreak tree belts tend to be wide since trees planted along the coast are hampered from growing by the crucial treeain conditions, and windbreak effects are therefore attained the growth of inland trees based on the sacrifice of the aforementionedes water front plantation.

The aeration rate and windspeed lowering distance are reduced in coastal windbreaks than inland windbreaks wince the tree belt width become increased. On the other hand, inland derection sand shifting prevention effects are considerable with coastal windbreaks due to wide tree belts.

Diagram Effect of Wide Coastal Windbreak Tree Belts
 (Approximately 1 meter off the ground)
 (TOKUJI KASHYAMA)

- (a) Windspeed
- (b) Salt Density Within Sea Breeze
- (c) Evaporation Volume
- (d) Sea Fog Density
- (e) Wind
- (f) Tree Belt
- (g) Distance from Tree Belt
(Multiple of Tree Height)

Additionally, coastal windbreaks exhibit superb entrapment effects of salt contained in sea-breeze. Heavy damages occur on agricultural products, power lines, and communication facilities, etc. During tyoons since salt with approximately 100 times the normal salinity density are known to have been blown inland. Diagram 3-3 illustrates an example of these effects of coastal windbreaks. The reduction of windspeeds, salt density, and sea fogs in the front and rear of the windbreak may be clearly observed in this graph. Species of coastal windbreak trees are mostly restricted to Japanese black Pine.

Section 3 Forest Effect on Erosion Prevention

Ground surface in forests are often covered with litter. Therefore, sheet erosion are rarely generated in wood lands. However, sheet erosion generations become increased when bare lands are produced by cutting of timber as well as by derange-

ment of wood lands since forest soils are soft and easily washed out.

Additionally, it must be noted that penetration exhibit ample surface soil stabilization effect, and therefore present abundant landslide prevention capability. On the contrary, though, it must also be noted that the landslide prevention capability of forest are said to be limited.

1. Forest Effect on Surface Erosion Prevention

The ground surface is covered with thick humus layer, defoliation, fallen branches when the crown is sealed in wood lands. Undergrass growth are observed when the humus layer, defoliation, and fallen branches are reduced in sparse density woods. In many cases, these surface covering matters function fully to absorb the impact from raindrops which is the cause of sheet erosions. It is by this function of covering matters that wood lands are free of surface runoff and exhibit high infiltration capacity. Even when partial surface runoff is generated, the flow becomes absorbed and dispersed by the surface overlay or soil grains are prevented from washing out by penetration, and therefore are precluded from developing into large scale erosion such as gullies. However formation of partial bare lands become facilitated, accompanied by increased erosion when trees are cut down as illustrated in diagram

Diagram Cutting Conditions and Annual Eroded Soil
 Volumes of Natural Japanese Red Pine
 (Pinus densiflora)

- (a) Position of the Cutting Area and the Proportion with
the Area
- (b) Overall Cutting and Stump Removal
- (c) Overall Cutting
- (d) 3/4 Cutting on Slopes
- (e) 1/2 Cutting on Slopes
- (f) 1/4 Cutting on Slopes
- (g) Uncut
- (h) Annual Eroded Soil Volume
- (i) Comparison of Annual Eroded Soil Volumes
(Uncut : 1)
- (j) Stand Age 30 years, 30 degree incline test ground
(40 x 20m), Okayama Prefecture.
- (k) (TAKESHI KAWAGUCHI)

Errosion volumes are greatly increased when ground surface
are deranged upon felling.

Aside from the aforementioned, forests reduce the stand
temperature change with the crown and surface overlay as
well as prevent frost lifting generated by the repetition of
soil congelation and fusion. Additionally, tree roots
secure rocks and gravel in regions where rock beds and
gravel appear on the ground surface, and therefore

functioning greatly to prevent rocks and gravel from falling.

2. Forest Effect on Landslide Prevention

Landslides tend to be generated more often in unstocked areas such as grasslands and cut-over areas than stocked areas. It is thought that this is due to the surface soil being secured by the penetration in the sub-surface ground. This relation between the surface soil securing effect of root systems and generation of landslides may be explained as described in the following:

Landslides Generation Prevention Effect (A): The root system spread throughout the sub-surface stabilize the surface soil and prevent generation of landslides.

Landslides Generation Effect (B): Large volumes of rainwater are infiltrated into the surface soil during heavy rainfall, facilitating the generation of surface layer landslides.

Surface soil in forested hillside slopes are normally stabilized with the aforementioned root system effect (A). The effect (A) is stronger than effect (B) during normal rainfall ($A > B$), and therefore the terrain stability is maintained. However, landslides become generated depending on the area during heavy rainfall when the effect (B) exceeds effect (A) ($A < B$).

Conditions where the effect (B) exceeds effect (A) are most often generated when heavy rainfalls are encountered after

trees have been cut down, and therefore enhancing the effect (B).

Diagram Forest Age and Landslide Generations (NAMBA)

(a) Landslide Area Rate (%)

(b) Forest Age (Year)

Diagram 3-5 The Change In Cedar Stump Removal Resistance Over The Years (KITAMURA, etc./Original Schematic)

(a) Single Tree Stump Removal Resistance (Ton)

(Surface Soil Securing Force of the Root System)

(b) Years Passed

This phenomenon is clearly observable that landslides are frequently generated in thicket lands 10 to 15 years after felling as illustrated in diagram 3-4.

Diagram 3-5 illustrates the mechanism of this phenomenon. The surface soil securing effect of the root system become rapidly reduced over the years when the roots become rotten after fell. On the other hand, the surface soil securing effect of polo sized trees become increased over the years. The surface soil securing effect of root systems in general cut-over lands are described by the total of the two, and therefore is as illustrated with the true line in the diagram. It is hereby observed that the effect (A) effect (A) becomes most reduced around 10 years after felling, facilitating

the generation where the effect (B) exceeds effect (A) (A < B). It is therefore necessary to pay close attention when cutting, trees down in landfall generation regions. It is important from these factors to plan the cutting to prevent reduction of the surface soil securing effect of the root system by avoiding clear cutting and employing measures such as selective cutting as well as regeneration by sprouts. Naturally, landfalls effected by tree cutting are surface layer landfalls, and therefore, generation of deep layer landfalls are considered to be from this phenomenon.

Section 4 Forest Effect on Runoff Regulation

Forests reduce the discharge volume of floods as well as prevent the discharge from decreasing during dearth of water periods. The former phenomenon is called the flood control effect and the latter is called the water resource cultivation effect of the forest.

1. Hydrologic Cycle and Rainfall Effluence.

Water on the earth are constantly circulated. Rainfall on mountains and level lands are stored on the ground surface or within the earth, with a portion later returning into the atmosphere through evaporation or transpiration. The remaining water flow into rivers. The form of these rain water storage, evaporation, transpiration, and river effluence vary greatly according to the condition of the ground surface.

For example, conditions of rain water storage or river runoff greatly depend on the urbanity of the subject area, etc. The water regulation effect of forests so to say, is to consider what function among the aforementioned hydrologic cycle forests share in contrast to other ground surfaces. Rainfall on hillside vegetation drop on the ground surface and become effluded into rivers after travelling through various routes. Graphs indicating the continuous measurement of river discharge is called a discharge curve (Hydrograph). The hydrograph (Diagram 3-6) is comprised of various rain water named ground surface, intermediate (*1), and ground water effluence, travelling through the various sections of the hillsides. Effluence into rivers tend to be delayed with the depth of rain water infiltration into the ground. The increased water during rainfall mainly consist of surface runoff, interflow, and river runoff during no rain periods are comprised with ground water effluence.

Diagram Rain Water Runoff on the Hillside
 and Discharge Curve

- (a) Rainfall
- (b) Interflow
- (c) Ground Water Runoff
- (d) Ground Surface Runoff
- (e) River
- (f) Precipitation

(g) Time

(h) River Runoff

(*1)

Rain water flows down the slope along the boundary layer of the surface and subsoil when the surface soil are more porous than subsoil as in forests.

This phenomenon is called the interflow or sub-surface.

2. Forest Effect on Flood Control and Water Sources Conservation

Flood discharge is increased along with the increase of the volume of surface runoff during rainfalls. On the contrary, flood discharge are decreased with the increase of rain water infiltration into the ground to become ground water, and instead, the river discharge increase during dearof water periods.

The effects of the forest on rainwater discharge are explained in the following.

- 1) Forest soil are porous, and infiltrate most of the rainfall. Therefore, ground surface flows are hardly generated. Infiltration capacity is the measurement of the ground surface ability to infiltrate rainwater. Diagram 3-2 describes the change in the infiltration capacity according to condition of the ground surface in the form of final infiltration capacities. It is

obvious from this chart that forests exhibit superb infiltration capacities.

- 2) Surface soil in forests tend to maintain porosity into greater depth than other vegetative land, and therefore exhibit better rain water storage as well as infiltration to the depth of the earth compared to other ground surface conditions.
- 3) Large amounts of rain water are stored in the surface soil in forests to supplement water shortage caused by transpiration. Therefore the amount of rain water becoming river discharge tend to be slightly less than other ground surface conditions.

The change in the flood discharge based on the aforementioned features of forests, when lands become bare or when trees are cut down are explained in the following:

- i) The infiltration capacity of the grounds surface become considerably reduced when the aforementioned features(1) and (2) of the forest eliminated due to increased bare lands caused by loss of forests by fire or by excessive ground surface devastation. In such case, most of the rain water become surface runoff, and the flood discharge increase considerably. An example of this phenomenon is illustrated in diagram 3-7. The diagram explains the forest

restoration by planting on bare lands with the accompanying flood discharge reduction.

Diagram Variations and Infiltration Capacities
 of Vegetations

- (a) Type of Vegetation
- (b) Coniferous Forest
- (c) Broad Leaved Forest
- (d) Cut-over Area
- (e) Grass Culture Area
- (f) Newly Slipped Land
- (g) Forest Utilization Road

(1) The infiltration capacity where the infiltration capacity become constant when the ground become water logged by rainfall, is called the final infiltration capacity.

ii) The aforementioned features (1) and (2) are maintained, and the feature (3) become changed when proper soil preservation are performed after cutting. The rain water volume become reduced in order to supplement the water shortage of the soil due to decreased transpiration caused by forest cutting. Therefore, flood discharge are somewhat slightly increased in contrast with forests.

Increase in the ground water storage volume results increased river discharge during famine periods since river discharge during this period are comprised mainly with effluence from ground water storage in mountainous regions. Forests exhibit better infiltration capacity than any other types of vegetation or ground surface, and therefore, the greatest volume of rain water are infiltrated underground. Viewing from this point, it could be said that forests play an important role in increasing the river discharge during famine periods.

Forests dissipate moisture stored in the soil into the atmosphere through transpiration. This dissipation through transpiration reduces the volume of rainwater infiltration to the ground water storage. Therefore, it is desirable to reduce the volume of dissipation through transpiration in order to increase the discharge during dearth of water periods. However, forest cutting aimed at the reduction of transpiration expose the forest to the danger of ground surface devastation, resulting in generation of surface run off and increased erosion volumes. For example in Japan, transpiration volumes in most parts are relatively less than rainfall, and therefore it is more important from the viewpoint of water resource conservation to enhance rain water infiltration underground than reducing the transpiration volume. Transpiration volumes generally

tend to become reduced and rainfall increased with the elevation in altitude at identical points. With these factors in consideration, it may be concluded that it is important to develop well conditioned forests in high elevation far up areas of water source which can infiltrate abundant volumes of rain water underground, while reducing dissipation through transpiration in order to increase the ground water storage.

Chapter III DESIGN AND EXECUTION OF HILLSIDE WORK

Section 1 The Design of the Hillside Works

Hillside collapsed by heavy rain or earthquakes lacks vegetation overlay, and the surface is swept away. Therefore, the surface layer soil is washed down the slope with each succeeded rainfall, and devastation become further progressed. Additionally, the swept down soil and gravel accumulate on streambeds, and become potential cause of large scale disasters such as floods.

Soil inadequate for the growth of vegetation appears on such devastated hillsides, precluding the early stage entry of plants. Devastated subject requiring restoration, such as where the vegetation overlay had been artificially removed by forest development, subject frequently found and subject potential danger for disasters. We hereby must study effective hillside work methods in order to prevent disasters through restoration of denuded lands for enhancement of the disaster prevention effects of forests, which in turn stabilize the terrain and assure water resources.

Hillside devastation are generally accompanied by wild torrents. Therefore hillside works explained in this chapter are usually designed and executed in combination with torrent works explained in the following chapter.

Section 2 Planning the Hillside Works

Designing stages of hillside works may be segregated into the following two procedures. The first is by planting vegetation upon careful accomplishment of foundation work, and the other is to plant vegetation with minimal alteration to the topography. The former method exhibits high rates of success, but is time consuming and costly. The latter method is economical, but risks the generation of partial erosions. Therefore, it is important to apply the most adequate type of work method and procedure in accordance with the conditions of the subject topography upon surveying the work execution area, since either method exhibit the aforementioned benefits as well as shortcomings.

Section 3 Surveys for Planning the Hillside Works

Topographic survey results of areas in the vicinity of scheduled work execution site are used as the basic data for designing hillside works.

Topographic surveys are accomplished by traverse, using equipments such as transit and pocket compass, etc., in order to obtain information on the topographic conditions of the devastated land and vicinity for the production of a plane schematic. Major surveying points during this survey must be on immovable points, since they will be used as control points for future surveys and execution of works. The scale

should be between 1/500 to 1/1000 with a contour interval of 5 to 10 meters.

Profile leveling or Longitudinal leveling determines the type, layout, and extent of the work, and is performed to estimate the soil volume of grading works explained in the following Section 4, during hillside foundation works. This form of survey is accomplished with a level or a pocket compass.

Directions of surveys and survey lines are to be determined upon studying the change in landscape changing points, proposed structure erection sites, and land classification 1).

Cross leveling is performed in order to estimate the basic figures for various foundation works, and selection points of this survey are in accordance with these of the Profile leveling.

Close attention must be paid to the directions of survey lines in order to attain accurate figures. Levels or pocket compasses are employed for this survey depending on the accuracy desired.

Section 4 Types of Hillside Works

Restoration of devastated hillsides by replanting is accomplished by applying hillside foundation work first in order to clear and stabilize the uneven hillside surface. This is then followed by the application of hillside replanting work in order to permanently stabilize the hillside surface with vegetation overlay.

The types of hillsides works are mainly segregated by the material employed, and the commonly utilized materials are as listed in the following.

Although various types of work methods and procedures are available as listed in the table, determination among foundation or planting works should be only made upon studying the actual topography as well as the survey data, for the employment of the most appropriate method in compliance with the topography, soil, and climate of the proposed work site area with the ease of material procurement and transportation in consideration. Furthermore, designs must be processed separately even within the same job for well vegetated areas such as the sedimentation zone and poor soil condition regions where soil dressing is required.

1. Land classification is a term for classifying lands into current bed area and landslide area, with further classification of landslide area into denuded hillside area and sedimentation area.
 - (a) Hillside Work
 - (b) Foundation Work
 - (c) Replanting Work
 - (d) Grading Work
 - (e) Retaining Work
 - (f) Buried Work
 - (g) Drainage Work

- (h) Sodding Work
- (i) Simple Terracing Work
- (j) Convering Work
- (k) Seeding Work
- (l) Planting Work
- (m) Water way Work
- (n) Closed Conduit Work
 - (i) Wet Masonry
 - (ii) Dry Masonry
 - (iii) Concrete
 - (iv) Square Crib
 - (v) Concrete Panel
 - (vi) Bamboo (or Wire) Cyoinder
 - (vii) Fascine Masonry
 - (viii) Fence Work, etc.
 - (ix) In accordance with the work types of the Retaining work
 - (x) Wet Masonry
 - (xi) Dry Masonry
 - (xii) Concrete
 - (xiii) Concrete Piping
 - (xiv) Line Sod
 - (xv) Stone Concolidataion
 - (xvi) Bamboo (or Wire) Cylinder
 - (xvii) Corrugated Piping, etc.
 - (xviii) Bamboo (or Wire) Cylinder

- (xix) Gravel
- (xx) Fascine
- (xxi) Concrete Piping
- (xxii) Vinyl Chloride Piping, etc.
- (xxiii) Triple sheet sodding
- (xxiv) Quintuple Sheet sodding
- (xxv) Sodding Step, etc.
- (xxvi) Stone
- (xxvii) Japanese Cogongrass
- (xxviii) Concrete Panel
- (xxix) Sod
- (xxx) Fascine bundle
- (xxxi) Straw
- (xxxii) Log
- (xxxiii) Replanting Material, etc.
- (xxxiv) Straw
- (xxxv) Straw Mat
- (xxxvi) Fascine
- (xxxvii) Replanting Material, etc.
- (xxxviii) Manual Sowing
- (xxxix) Seed Spraying
- (xxxx) Strip Sowing
- (xxxxi) Overall Sowing
- (xxxxii) Aerial Spreading, etc.
(Helicopter Spreading)

Section 5 Hillside Foundation Work

1. Grading Work

Hilldides devastated by landslides exposes uneven surface as well as steep inclines, and are highly unstable. This surface unevenness become further dissected with each rainfall due to the sheet flow concentrating in the sunken sections of the hillside.

Inclines must be reduced as necessary and the surface must be smoothed on such hillsides since the applied measures are easily destroyed. Works performed for the improvement of such conditions are called grading works.

The most ideal state of the grading work is when the overall uneven surfaced slopes are graded with the angle of repose of the particular soil quality as illustrated in diagram 4-1.

However, it is highly important to plan and execute this work in conformance with form of the topography, since removal of large soil volumes are not only costly, but risks the danger of silt deposited in the sunken sections to shift and coause unexpected disasters by rainfalls.

Diagram

Execution of Grading Work

Table Soil Variations and Angles of Repose

- (a) Type of soil
- (b) Clay
- (c) Sand
- (d) Ballast
- (e) Regular Soil
- (f) Condition
- (g) Dry
- (h) Low Moisture Content
- (i) High Moisture Content
- (j) Forestry Agency Mountain Conservation Technical Standards

The works are started from the top of the slope downward to the valley. Soil are removed from protruded sections, and are used to fill the sunken areas. Retaining structures must be erected prior to the execution of this work since secondary disasters may be generated by rain or snow falls when these filling silts are excessive although these soil have been sufficiently compacted.

Grading works are normally performed with tools such as picks, shovels, and mattocks.

2. Hillside Retaining Work

This work is performed to erect structures on necessary points of hillsides in order to reduce the slope incline, support collapsible slopes, prevent washout of grading

soil, and to preserve water ways. Therefore, these structures must be erected on sturdy foundations where they are safe against the earth pressure from the top as well as free of slippage generation in the bottom, since such structures are required to maintain the hillside soil rigidly and stably under any condition. Furthermore, measures such as step formation are necessary to reduced the top and bottom clearance in order to decrease the generated pressure.

Moreover, it is necessary to prevent from damaging the tops of retaining structures by grading soil fillings and rock falls since retaining structures are often erected prior to grading work.

1) Wet and Dry Masonry

This method was previously employed commonly when natural rocks and stones which are materials for masonry are readily available on the job site. However, employment of this method has reduced in recent years due to decreased numbers of masons.

Artificially produced materials such as concrete blocks to have superseded natural stones. Concrete block retaining work vary in types such as employment of conventional stone material formed blocks with conventional execution procedure, assembly and erection employing square rigging likewise architectural technology using

plaster and steel reinforcement, and others with intermediate process of the aforementioned two. However, it must be further noted that the determination of the type of work process must be made in compliance with the condition of the work site.

Diagram Dry masonry Retaining Work

- (a) Grading Soil
- (b) Back Fill Stone
- (c) Under 2.0 meters
- (d) Over 0.2 - 0.3 meter

This work must be executed on rigid foundations with surface incline of 20 to 30 percent gradient since the own wiehgt is excessive. Additionally, the height must be kept below 3 meters to maintain safety against the earth pressure. Furthermore, Joing lines should be provided every 10 - 15 meters when the overall span exceeds 20 meters to preclude expansion of the damage in case of catastrophe, along with the basic principle to install weeping holes.

2) Concrete Retaining Work

Concrete retaining works are applied when absolute slope stability and rigidity are required in hillsides with potential of slippage generation where other methods cannot be executed due to excessive earth pressure as

well as on hillsides with the ease of concrete application. The height should be kept below 4 meters to maintain safety even when foundation works have been accomplished to a considerable extent, since the supportability of foundation layers in collapse sites are uneven, and often accompanied with steep inclines.

The sectional forms are designed in accordance with the back earth pressure. The back grading, therefore, should be determined in conformance with the condition of the work site based on the crown thickness at 30 centimetres and the front grading at 30 percent gradient.

The rear grading should be right angled or minus ten percent gradient when the earth pressure is low.

Diagram Concrete Retaining Work

The back filling is provided to uniform and relax the earth pressure on structures as well as to rapidly drain the water infiltrated from the back, and its thickness should be over 30 centimetres. Additionally, vinyl chloride pipings, etc. are laid in order to drain the water in the back to the front to reduce the pressure. Flexible Joint provided for the prevention of destruction by temperature change and are executed in the identical manner with those for the masonry work. Additionally, these flexible joints should be halving joints instead

of straight joints. Asphalts and Elastites are mainly used for sealing mediums.

3) Square Crib Retaining Work

Structures may be easily broken with masonry and concrete works by ununiformed settlement, as well as soil horizon shifts in soft terrains with uneven supportability.

The square crib retaining work is the method employed in the aforementioned case.

Square cribs are square reinforced concrete bars assembled on the work site into a square and filled with gravel and rubbles.

Diagram 4-5 Square Crib Retaining Work

Concrete work on collapsed hillsides with disproportioned ground bearing power often presents difficulties of material transportation and onsite mixing. Therefore, the square concrete bars employed in this method are considered to be beneficial with the ease of transportation as well as the simplicity of execution, requiring only assembly due to being factory products. The sectional dimensions of the square bars are to be considered in accordance with the size of the earth pressure in this method, since the earth pressure is resisted with the weight of the gravel and boulders filled within the cribs.

However, individual heights must be kept below 3 meters since the strength of a single square bar is limited. Additionally, retaining effects are known to have been enhanced by providing two rows with clearance in between. Furthermore, protective works are performed at times to prevent the top from becoming damaged by falling rocks.

4) Concrete Panel Retaining Work

The two types of this work method are as explained in the following. The first is by mounting two or three sheets of 1.0 x 0.3 x 0.03 meter concrete panels in the back of concrete piles and refilling this rear side to attain retaining effects upon completion. The latter is by linking 1.0 x 0.3 x 0.03 meter surface panels to 0.25 x 0.2 x 0.03 meter supplementary panels with 0.5 meter concrete poles and filling with soil and gravel as illustrated in diagram

Diagram Supplementary Panel Type Concrete Retaining
Work

- (a) Stone filling
- (b) Surface Panel
- (c) Mulching
- (d) Supplementary Panel

Additionally, this method exhibit features such as the ease of transportation as well as on-site assembly.

However, it is important to verify the safety when employing this method since the earth pressure resistance is small compared to other retaining works. The height must be kept below 1.2 meter with 4 sheet even with the supplementary panel system, and below 0.9 meter with 3 sheets with the standard type. Stability may be further increased by replacing the filling gravel with concrete.

5) Bamboo (or Wire) Cylinder Retaining Work

This method is employed on grounds which may be destroyed with retaining work employing concrete and masonry, etc. due to slippage and uneven settlement of the ground.

The height must be kept below two meters in order to minimize the damage when the cylinder comprising wires break, since the durability of wires are limited, regardless of diameter or corrosion resistant treatments. Securing piles are placed every 2 meters to unite the individual cylinder steps in order to prevent slippage. Select rot retarding timber or apply rot proofing coating on these piles in order to extend their effect over a prolonged period of time.

Additionally, stone filling with mixed diameter stones larger than the size of the wire mesh in order to reduce the porosity and increase the resistance against the settling and shifting of the ground. Furthermore, at job sites where good quality boulders are readily

available, filling materials are easily obtained, with a secondary effect to clear the work site.

Diagram Bamboo (or Wire) cylinder Retaining Work

(a) Square (Quilt) Cylinder

(b) Mulching

(c) Securing Pile

(d) Cylindrical Cylinder

(e) Securing Pile

6) Fascine and Mulching Retaining Work

This is a pile of 40 - 50cm long 10cm diameter faggot wood bundles piled alternatively with 10cm thick layer of mulching. This method exhibits increased moisture storage of the slope resulting in early stage growth of vegetation. However, although this method is ideal for execution during the winter in excessive congelation areas, the height must be kept below 1 - 1.2 meter due to the easy rotting of fascine bundles and low earth pressure resistance. Furthermore, execution in surface run-off concentration areas should be avoided since covering soil are easily washed out by surface run-off. The surface incline should be under 30 percent gradient, with twigs such as willow, which has good reproductive power from stools, intermixed in the fascine bundle. Moreover, it is important to plant the soil covering with weeds such as Japanese Cogongrass for early stage

growth of vegetative overlay in order to increase the retaining effect with vegetation.

7) Fence Retaining Work

Fence retaining work is performed in order to prevent the filling soil from becoming washed out as well as improve the environment of the planting by producing fences filled with soil in the back in the horizontal direction along the hillside. Logs and fascine are used as materials for this fencing. Logs and fascine, though, are only used for temporary measures or when early stage restoration of stability is anticipated due to the poor durability. Piles securing the fence must have a top end diameter over 9cm with a length of 1.5 - 2m. These piles are driven into the hillside in the bisecting direction of the vertical and perpendicular directions as illustrated in diagram 4-9. Piles are driven in this angle since they may be removed or fractured by falling rocks when placed vertically, or reduced in resistance against earth pressure when placed perpendicularly. The standard pile driving depth is over $1/2$ - $2/3$ the length of the pile with one meter clearance. Early stage vegetation growth may be attained resulting in improved ground securing effects, by intermixing species with storing sprouting characteristics into the fascine.

Diagram Fascine Retaining Work

- (a) Fascine Bundle
- (b) Mulching
- (c) Weed Stubble

Diagram Driving Direction of Securing Pile

- (a) Vertical direction
- (b) Hillside
- (c) Perpendicular Direction
- (d) Pile Driving Direction

3. Buried Work

This method is employed when hillside restoration is difficult unless the waste soil is deposited deeply into the sunken sections due to excessive grading soil volume.

This work is applied underground in areas where surface structures may be destroyed when the aforementioned soil become shifted with water. Structures are in accordance with retaining works. Additionally, concrete, stone masonry, bamboo (or wire) cylinder, fence, and square cribs are designed.

The layout with buried work must be designed where the silt become lower than the angle of repose. Furthermore they must be built on safe and sound foundation.

4. Drainage Work

Drainage work may be segregated into the water way work, performed for the collection and drainage of surface water in order to prevent hillside erosions caused by the surface runoffs produced by rain and springs as well as to protect surface structures, and the closed conduit work placed underground in order to drain ground water which soften the soil horizon and cause clod slippage.

1) Waterway Work

Layouts vary depending on the form of the work-site/topography, but are placed along the concave slopes on the collapsed surface. The tracheary section is determined with the catchment area. Calculations to obtain the sectional area, are explained in following Chapter. The safety factor in hillside channels should be 5, considering the soil, gravel, and stump deposition. Additionally, there are arc, trapezoid, and quadrangle formed sections.

The incline of a waterway must be made constant since soil may deposit in the changing point of gradient resulting in decreased tracheary sections. The waterway must be split in conjunction with hillside piling work at changing points of gradient. Additionally, gradient must be reduces with hillside piling work similar to

the aforementioned changing points of gradient, for the tracheary surface become eroded with run-offs when the angles of incline are excessive. The length of a single span should be basically less than 20 meters considering the risks of uneven settlement caused by the self load of the waterway and by friction damages. Bed Gindie 1) are to be provided in places where the overall length exceeds 20 meters.

Waterway works may be segregated into stone paved channel with wet and dry masonry, sodded channels covered with sod, concrete waterway, concrete piping, corrugated pipe channel, and cylinder channel in accordance with their structural material.

(1) Stone Paved Channel

This type of waterway have been employed by mankind since ancient times with tracheary sections in the form of an arc or trapezoid. The two types of this channel are the wet masonry method where the stone consolidation secured with concrete, and the dry masonry method where concrete is not employed.

Wet masonry are performed with DOHGOME concrete as the securing agent for the stone consolidation on a foundation with over 20cm back fill in regions where water concentration on hillsides are abundant, resulting in excessive soil washout by run-offs by rainfall,

as well as in unstable ground caused by landcreeps, etc.

Dry masonry are performed on back-fills at times in places where normal water volume is minimum, such as on the top of relatively steep gradient hillsides or in low water concentration hard soil regions.

Run-off resistance become increased by supporting the stone consolidation by securing piles into the DOHGOMEREKI packed carefully into the brace.

Diagram Stone Paved Channel Work

- (a) Dry Masonry Arc Formed Channel
- (b) Japanese Cogongrass
- (c) Stone consolidation
- (d) Cut Sod
- (e) Wet Masonry Trapezoid Formed Channel
- (f) Cut Sod
- (g) Japanese Cogongrass
- (h) Stone Consolidation
- (i) Concrete
- (j) Back fill Stone
- (k) Soil Filling
- (l) Backfill Stone

1) The Bed Gindle is also called a supporting line, and is a dam formed structure with the top in the bottom of the waterway. This structure rectifies the waterway gradient to enhance safety as well as prevents damages by precluding the water from flowing beyond the waterway.

2) Sodded channel

Sodded channels are employed for tributary waterway in large scale denuded lands as well as in minor denuded areas with small discharge.

Application of this work is not only simple, but is economical as well when good quality sods are available in the vicinity of the work site. Additionally, this is one of safer methods against ununiformed ground settlements.

Diagram Sodded Channel

Furthermore, execution must be planned for the season where the growth of the cut sod are rapidly attained. The MEGUSHI or pin stick employed should be comprised with strong reproductive power plants in order to attain stability through vegetation. The standard sodded channel form and dimensions should be an arc with 1.2m arc span with 0.3m depth considering the ease of construction and waterway safety.

The employed sods are to be prepared upon calculation

of the area with the equation below.

- (a) A: Sod Planting Area
- (b) C: Sectional Arc Length
- (c) l: Waterway Length
- (e) s: Waterway Width (Arc Span)
- (f) _{hw} h: Waterway Depth

3) Concrete Waterway Work

This type of waterway is located with anticipation for efficiency equivalent to wet masonry stone paved channel work, and are employed for trunk channels. The sectional form of waterways produced with this method are either trapezoid, or quadrangle. Bed girdles are added in order to reduce the incline for speed control when abrasion are expected to be generated on the inner surface due to fast run-off speeds.

Standard bottom thickness is over 0.3m with the thickness at the top of the sides at 0.15 - 0.2m. Additionally, standard side wall front gradient is to be 30 to 50 percent with the rear side gradient perpendicular or minus 1 minute. 10 to 20 percent gradient it to be placed on side walls when earth pressure is expected to be excessive. Construction of this type of waterway must be made on rigid foundations since the self load is excessive, with all loads applied to the bottom, and therefore, may become destroyed by ununiformed ground

settlement.

4) Concrete and Corrugated Pipe Waterways

This method is employed in places where execution of other methods are difficult because of water, or in areas where concrete cannot be laid on the work site due to excessive run-offs during rainfall, as well as where materials cannot be transported resulting in prohibition of onsite concrete application due to the topography.

This method is become to be employed more widely due to efficient execution. Close attention must be paid for securing these waterway when executing this method since conditions are different from level topography.

Additional, the major sources for destruction are un-uniformed ground settlement and erosion of the refilled soil caused by run-offs outside the side walls. Therefore, care should be taken when executing protective works for the foundation in the bottom as well as for the outer sides of the side walls.

Diagram Concrete Pipe Waterway Sectional View

(a) U Shaped Steel Reinforced Concrete

(b) Sand Cushion

(c) Crushed Stone

5) Bamboo (or Wire) Cylinder Waterway

The flexibility of this method is employed in soft soiled

areas and in work sited where ununiformed shifting of partial soil may occur. Additionally, this method is highly economical in work sites where boulders and gravel employable for fillings are readily available. There two types of bamboo (or wire) cylinder waterways are the rectangular waterway employing square cylinders, and the arc formed waterway employing the round cylinder. The cylinders in this method control the channel. Therefore, cylinders are secured with securing piles in steep gradient areas, to prevent cylinders from being destroyed by the movement of cylinders themselves caused with the discharge. Furthermore, close attention should be paid to the execution of the waterway bed, so as the collected water become rapidly drained without infiltration.

Diagram Bamboo (or Wire) Waterway Work

2. Closed Conduit Work

This is an underground waterway provided to guide the ground water which is a cause of landslide generations rapidly out of the area or to surface drainage channels.

Designing and method of execution should be determined in accordance with the conditions of spring, sub-surface water and ground water flow. Segregations of this work are made with the materials employed, such as gravel, bamboo (or wire) cylinders, fascine, and vinyl chloride pipes.

Gravel covered conduits are widely, used in areas with large volumes of ground water. 5-15cm of gravels are packed as illustrated in the sectional view diagram 4-14, and are then covered with sod or fascine overlay which are topped with soil filling in order to prevent the closed conduit from becoming clogged by soil entry.

Drainage effects may be performed over extended periods of time by laying impermeable materials such as vinyl chloride sheets in the bottom to prevent erosions.

Extended effects cannot be expected with the employment of fascine which exhibit poor durability and water catchment, but used when transportation or acquisition of gravel are difficult.

Diagram Closed Conduit Sectional View

- (a) Refilled Soil
- (b) Boulders
- (c) Waterway

Bamboo (or wire) cylinder closed conduits are similarly structured to gravel closed conduits, but exhibit superb preservation effect of a single, stable underground waterway in steep gradient as well as stratum change regions sue piles being driven in approximately every 2 meters to preclude movement.

Closed conduits made of drains comprised with vinyl chloride

pipes, etc. maintain effects over extended periods of time even in relaxed waterway gradient regions. However, selection of types and sizes must be made in accordance with the ground water volumes, soil conditions, and the degree of gradient.

Section 6 Hillside Seeding and Planting Work

Soil movements on devastated hillsides may be temporarily stopped with the various aforementioned foundation works. However, though, soil structure which is the base of vegetation growth of such surfaces are poor, and are inadequate for rapid vegetative overlay due to delayed natural entry of vegetation. Structures erected for hillsides foundation works may be destroyed with hillsides reverting back to the original devastated condition when heavy rainfalls or avalanches are encountered prior to the development of the stabilization effect of vegetative overlay.

Following the execution of hillside foundation works, overall replanting should be performed to prevent generation and increase of erosion. Additionally, restoration of the water regulation and conservation effects of forests should be simultaneously considered. Therefore, vegetation methods such as planting on horizontally cut-away steps on hillsides as well as overall replanting are performed. In either case, continued stabilization of the slope with full-grown forests must be

considered, starting with grass overlay initially, followed with induction of trees.

1. Sodding Work

This method is applied on denuded collapsed hillside with poor surface soil as well as dry hillsides. The purpose of this work is to improve the environment of trees as well as to disperse and infiltrate surface run-offs in order to delay the run-off speed and facilitate the growth of the vegetation.

Depending on the volume of sods employed, this method may be segregated into triple sheet, quintuple, and step sodding work, etc.

Vegetation, growth may be facilitated by applying fertilizers as well as by laying rice straw as the primary fertilization agent, and moisture preservation. Anthropic vegetation blocks and vegetation sacks work are applied in work sites where transportation and acquisition of natural sod are difficult. 1).

Diagram Sodding Work Sectional View

- (a) Triple Sheet Sodding Work
- (b) Crown Sod
- (c) Straw Bundle
- (d) Cover Bed
- (e) Grading

- (f) Patch or Upright Sod
- (g) Lineal Height 0.7 - 1.0m
- (h) Bench Cut
- (i) Quintuple Sheet Sodding Work
- (j) Crown Sod
- (k) Straw Bundle
- (l) Cover Bed
- (m) Bracing Sod
- (n) Lineal Height 1.5 - 2.0m
- (o) Grading Height 0.5m

The standard lineal height of sodding works should be 1m up to approximately 20 degrees incline hillsides, and 1.5 - 2m for steeper slopes. In other words erosions on slopes may be decreased by blocking sandy soil low, and mixed soil such as clayish viscous soil high.

Terraced sodding work is a term given to sodding works applied continuously with multiple steps on hillsides, which are employed for securing deposited silts in the sunken sections of hillsides as well as spurs.

Diagram Terraced Sodding Work

- 1) Vegetation blocks are compressed and formed mixtures of soil, fertilizers, and cut straw planted with plant seeds. Vegetation sacks are meshed sacks filled with soil, fertilizers, and plant seeds. Either of the two may be

intermixed with the most appropriate combination of the aforementioned ingredients in accordance with the soil at the work site. Furthermore, masonry or concrete foundations as well as closed conduits are often used in combination with this work for safety.

2. Simple Terracing Work

This is a form of terracing work which is simpler than sodding work, and is used on work sites with relatively abundant surface soil.

As with sodding work, the objective of this work is to prevent surface erosions by dispersing the surface run-offs on the slope surface as well as to enhance early stage growth of vegetation with the improvement of the environment by increasing the water infiltration underground.

Simple terracing works are applied by simply cutting steps out on hillsides to plant weed stubs or to apply secondary replanting products in strips, or by filling the terraces made of fascine or masonry with soil, as well as by applying secondary replanting products directly on the slope in strips.

Vegetation growth may be enhanced by employing straws for the primary fertilizing agent.

1) Japanese Cogongrass or Miscanthus Step Work

This work is used in work sites with good soil condition

where sodding works are not needed, and are often executed in combination with other treatments. This work is employed in work sites such as on the top of retaining works at the bottom of hillsides as well as where terracing is difficult due to steep incline, with soil adequate for the growth of Japanese Cogongrass.

On hard soiled terrain, the Japanese Cogongrass is planted in the berm of the terrace with a lineal height of 1.0 - 2m and a width of 0.3 - 0.4m cut out from the slope. Additionally, on soft soiled terrain, Japanese Cogongrass growth may be expected by planting in horizontal strips with a lineal height clearance of 0.5 - 1.0m without cutting steps out from hillsides.

Diagram Japanese Cogongrass or Miscanthus Step Work

However, the aforementioned standard figures need not be adhered when converging works explained in the following part is to be performed on the slope in between the miscanthus step work.

2) Sodded Step Work

This work is identical to the aforementioned Japanese Cogongrass (miscanthus) step work with the subsidation of miscanthus with sod. This work is highly economical in work sites where sods are readily available in the vicinity.

Gradient between terraces are increased when terracing works are applied on hillsides. Therefore, these steep gradient must be mitigated with covering works to protect the slope. On the other hand, replanting effects may be satisfactorily achieved in deep soil, good soil quality, gentle gradient sites by planting sod directly without terracing.

3) Stone Step Work

This work may not only be facilitated in work sites where boulders, gravel, and rubbles are readily available, but also aid in clearance of the terrain. However, this work is not suggestable for employment in severe frost lifting or heavy snowfall regions.

0.5 - 0.6m width steps are cut out every 1.0 - 1.5m lineal height. Stones are then piled for less than 0.5m height, followed by filling the back with soil. The grading should be less than 30 percent gradient for these stone piles considering the safety, with weeds such as Japanese Cogongrass planted on the crown and base for protection. Stones should be piled in the longitudinal direction considering stability since stability is increased with longer brace length, using hard, weather resistant stones.

4) Fascine Step Work

As illustrated in diagram 4-19, this work is performed to enhance the planted vegetation growth by cutting to

form so to speak a pot with the soil filling in the back of the fascine bundle. This method is employed in places where rapid stabilization of the soil by the early stage growth of weed stubs and Japanese Cogongrass stubs may be expected since fascine rot rapidly. In other words, the applicable topography is where the rainfall is relatively minimal, with the soil being viscous and the gradient gentle, as well as free of surface run-off concentration.

1.5m lineal height, 0.8m width steps are cut on hillsides, piled with several layers of 0.1m diameter, 0.4m length fascine bundles until a height between 0.3 - 0.5m is attained, and are then finally covered with soil.

- 5) Simple Terracing Work with Secondary Replanting Products
- These factory manufactured secondary products for replanting work are becoming to be used widely in recent years due to their efficiency for reducing transportation costs as well as cost effectiveness. These products may be segregated into those with soil dressing effects and those without.

Those with soil dressing effects are employed in places where bed rock is exposed as well as poor soil conditioned areas. They are mainly comprised with soil intermixed with peat and fertilizers, or organic fibers as the parent medium which are then blended with highly re-

productive plant seeds with expectations for early stage slope stabilization by the rapid growth of vegetation upon execution.

Products which do not exhibit soil dressing effects are mainly cloth and straws applied with plant seeds and fertilizing agents, and are used in areas where the silt layer is deep, exhibiting adequate vegetation growth conditions. The actual execution of this work is nothing more than cutting horizontal 0.5m lineal height ditches on hillsides in order to bury the products followed with earth covering upon completion.

3. Covering Work

Steep gradient slopes may fall or become washed out by rainfall, congelation, heaving, and wind when left untreated. Works performed in order to prevent the washout of vegetation as well as to preserve the moisture catchment for the sprouting and growth of vegetation with overlays are called covering work.

Covering works have been executed with fascine, straw, straw mats, and nets conventionally, but are becoming to be superseded with secondary replanting products possessing effects of both covering and seeding works.

Diagram Fascine Cover Work

1) Fascine Covering Work

As illustrated in diagram 4-20, fascine covering work is to lay fascine closely horizontally on the slope with piles driven in to secure.

This method is employed in work sites where fascine is readily procurable as well as where piles may be rigidly driven.

The clearance between the OSAEGI or retain stick should be 1m, and piles are to be driven into the center and sides of it.

2) Straw Covering Work

This method is employed in places where the slope gradient is relatively gentle with good drying features as well as minimal surface run-offs.

Diagram 4-21 Straw Covering Work

- (a) Straw
- (b) Beam
- (c) MEGUSHI or pin stick
- (d) Herbs are planted beneath the straw

Straws should be secured with ropes, beams, and MEGUSHI in order to prevent from littering by winds and rainfall. Straws may be subsidized with Japanese Cogongrass in places where they are readily available.

3) Straw Mat Covering Work

Erosions on light soiled slopes may be enhanced with each succeeded rainfall finally resulting in the collapse of the slope. Additionally, such topography is highly erodible by frost lifting and ice columns in cold regions. It is therefore beneficial in such regions to cover the soil with straw after seeding to prevent the aforementioned phenomena. This method is often partially executed with the dried condition of the slope in consideration along with other forms of covering work. It is necessary to secure the mats with ropes and MEGUSHI.

4) Net Covering Work

This method is employed in places where the gradient is excessive and when materials cannot be maintained and secured with other forms of covering work. This work may be segregated into those which are executed in replantable areas and those which are executed in areas where replanting is difficult.

The method employed in replantable areas are accomplished by securing nets applied with seeds, fertilizers, and other organic mediums in order to achieve both seeding and covering work effects simultaneously.

The method in areas where replanting is difficult is accomplished simply by covering the overall ground with nets to physically prevent rocks and surface soil from

falling. Although surface soil is produced over a prolonged period of time on such surfaces allowing entry of vegetation upon stabilization, plant seeds must be sowed to enhance this effect.

4. Seeding Work

Overall vegetative covering is necessary in order to permanently stabilize the hillsides. The hillside is left bare between the steps for some time after completion with methods other than the covering work. Early stage replanting must therefore be considered since these bare surfaces are highly erodible during this period. Seeding works therefore, is a method to sow seeds throughout the slope directly individually or in combination with other works to vegetate the ground with the sprouting and growth of vegetation. Methods such as sowing seed and fertilizer mixture into ditches and covering with overlay, or by overall sowing on hillsides which are then covered with straw and straw mats are currently employed. Additionally, seed and fertilizer mixture are being sprayed on slopes with adhesives such as asphalt solvents sprayed over in order to prevent washouts of planted vegetation. Furthermore, seeding is accomplished by helicopters in rural areas where material transportation is hampered, as well as when large devastated areas must be replanted in a short period of time.

The seed mixture is comprised of seeds with different characteristics, and the blending proportions are adjusted in accordance with the germination periods as well as initial growth conditions. Additionally, the seed quantity is increased or decreased in accordance with the number of individual growth per area unit.

1) Characteristics of Weeds for Seeding Work

(1) Sprouting and Initial Growth

Weeds employed for seeding work must sprout simultaneously within a short period of time from seeding and exhibit rapid initial growth in order to cover the unstable surface soon after the completion of hillside work.

Diagram Seeding Work with Pump
(Spraying Work)

Diagram

Germination Conditions of Weeds for Replanting

- (a) Weeping Grass
- (b) Muguort
- (c) Robina Pseudaccia
- (d) YASHIBUSHI or Japanese alder
- (e) Pine
- (f) Kariyasu
- (g) Days

Conditions of germination are highly dependent on the environmental conditions of the particular time.

Under normal conditions, plants such as Weeping Grass, Kentucky 31 Fesk, clover, and Muguort sprout after 2 - 3 days from seeding, and Creeping Red Fesk, as well as Bermuda Grass sprout within a few days.

Conventional perenrial herbs which exhibit superb continuosity and applicability devastated lands exhibit delayed and ununiformed germination periods.

Many leguminous plants such as Acacia among ligneous trees sprout within a few days and exhibit improved initial growth when germination inprovemen treated.

(2) Ease of Breeding

Good quality seeds with strong reproductiveness must be promptly obtained in large volumes, since abundant vegetation are desired to sprout and grow within a short period of time from seeding during replanting of devastated land. Imported pasture generally exhibit these features among weeds. Additionally, Japanese Cogongrass, Muguort, and Giant Knotweed exhibit good features among perennial herbs, as well as Robina Pseudaccia, YASHABUSHI or alder, AKISUMI, and pine also exhibit identical features among ligneous plants.

(3) Forms of Growth

Jupes, periods, and heights of growth are one of the essential conditions to be considered for the selection of the plant to be employed for replanting.

Diagram 4-25 Initial Growth of Plants for Replanting

- (a) Robina Pseudaccia
- (b) YAMAHAGI
- (c) Muguort
- (d) Weeping
- (e) Rub Grass
- (f) YASHABUSHI
- (g) Japanese Red Pine
- (h) Subject Year/September/Second Year

Growth forms may be segregated into plants which grow in BUNKETSU form such as vegetative plants (e.g. rice and KAYATSURIGUSA), procumbeats (e.g. sod), upright type (e.g. muguort), and subterranean stem plants (e.g. Kentucky 31 Fesk). Procumbeats and subterranean stem plants exhibit the greatest slope stabilization among the aforementioned. Additionally, there are winter weeds which grow during the colder spring and fall seasons as well as summer weeds which grows well during the hotter summer seasons as characteristics for growth periods. Seed mixtures are blended mainly

with the former of the two when planting in the spring or fall or in colder areas, and the latter during the summer or in warmer areas.

There are perennial and therophyte herbs among plants. Therophyte plants not only hamper the growth of other plants with its rapid growth, but also exhibit rapid decrease in surface stability when they die. Therefore, replanting works must be performed employing perennial herbs.

As far as the height of growth is concerned, wild grass such as Japanese Cogongrass and Muguort grow tall, and oppress other vegetation when they begin to grow densely. Kentucky 31 Fesk and Weeping Grass among imported species grow relatively tall and produce vegetative overlay in a short period of time. However, close attention should be paid the seed quantity and mixture of these plants per area unit since they may overgrow and oppress other vegetation.

Procumbeats such as Bermuda Grass, Clovers, and sods grow low on the ground and do not oppress or hamper the growth of other vegetation.

(4) Other Features

Desirable features aside from the aforementioned are good growth on infertile and barren land, improvement of soil fertility through root module bacteria

function and disease resistance.

2) Strip Seeding Work

This is a method applicable for relatively gentle gradient topography where a mixture of seed and fertile soil are manually sown or ditches cut away on hillsides or steps. However, this method may also be applied on hillsides with fairly steep gradient seeds sown are secured in the ditches.

Diagram 4-26 Strip Seeding Work

Procedures most applicable and economical should be selected with the ditch depth and width in consideration, since the amount of soil investment differ depending on the soil structure of the work site.

3) Slope Seeding Work

This is a method applicable for relatively gentle incline slopes with good soil structure. However, this method may also be applied on steep gradient hillsides when protective measures such as covering work are executed immediately seeding for the prevention of seed washouts as well as for the preservation of moisture for germination.

This work may be performed efficiently by spraying with pumps when the work site can be reached with vehicles.

In such case, there are methods where the seeds, fertilizers, and adhesives are sprayed simultaneously, and where they are sprayed individually.

The seeding quantity varies depending on the condition of the ground as well as the type of seeding mixture, and therefore, should be determined with the anticipated numbers of sprouts of 3,000 to 10,000 per square meter and the rate of germination in consideration.

Section 7 Planting Work

Planting works are executed for the early stage restoration of the disaster prevention effects of the forest which are lost on devastated lands with the growth of trees by planting seedlings.

The conditions for the growth of trees may be prepared to a certain extent with the various aforementioned hillside works. However, though, soil structures of such topography normally exhibit far poorer soil structure compared to normal plantation even after the execution of hillside works. Therefore, the geological structure, topography, and climate of the work site as well as the vegetation in the vicinity should be closely studied when making determinations for the planting plan. Improvement measures such as soil improvement and fertilization must be applied in order to be able to expect positive early stage growth and maturity of the vegetation.

1. Planting Plan

1) Land Classification

Lands are classified in accordance with the conditions at the work site in order to select the most applicable species and planting quantity of vegetation.

Planting plans for the individual regions are as described in the following.

Timer trees may be planted when risks for flooding as well as silt wash outs are not evident since such lands exhibit good soil conditions comprised with silt deposited during the formation of the stream.

Silt deposit part within collapse are formed with silt produced by surface fall-offs from above as well as by soil generated withgrading works. Therefore, soil conditions in such ground are relatively good, and superb tree growth may be expected.

Denuded zones within bevastated lands lack surface soil and have bad conditions such as steep gradient, dryness, and frost lifting. Therefore, hillside planting plans must be designed carefully with these matters in consideration. Additionally, improvement measures such as fertilizing, soil derssing, and mixed planting of soil improving trees must be taken progressively in order to facilitate the development of vegetation.

2) Tree Species for Planting

Tree species are selected in accordance with the aforementioned land classification, based on the "appropriate tree for the appropriate soil" principle. However, though, it is required that the planted species fulfill the following conditions:

- 1) Abundant growth and thrift.
- 2) Broad and deep rooting with large soil securing ability.
- 3) Sterile soil tolerance
- 4) Resistance against negative factors such as dessication, frost, and insect damage.
- 5) Those which soil improvement effects may be expected

Generally broad leaved trees such as alders, leguminous plants, and willows exhibit the aforementioned features. However, though, pine tree which is coniferous is also widely employed. Pine trees have been conventionally used widely as the principal forest crop.

(1) Principala Forest Crop

Japanese Red Pine, Japanese Black Pine, RIKIDAMATSU,
Yezo Spruce, White Fir, Japanese Cupress, Zelkova

(2) Soil Improving Tree

Japanese alder, Mountain Aldes, HIMEYASHABUSHI,
YAMAMOMO, willow, Acacia, ITACHIHAGI, Oleaster, UTSUGI.

Furthermore, trees differing in characteristics should be mix-planted in order to reduce various hazards for the development of a highly resistant forestas described in the following.

- 1) shallow and deep rooted trees.
- 2) principal forest crops and soil improving trees.
- 3) coniferous and broad leaved trees.
- 4) tall and short growing trees.

(3) Planting Quantity

Planting quantity varies depending on the species, planting method, gradient of the planting site, and the soil conditions, but should be limited to the standard of 3,000 - 5,000 trees per ha. in good soil condition areas such as silt deposit part within land collapse as well as in watersheds, and to 8,000 - 10,000 trees per ha. in poor soil condition areas such as denuded part within land collapse. Planting quantity of soil planting trees does not vary with the principal forest crop, but is required to pay close attention to the layout and number of mix-planting, since soil improving trees exhibit rapid initial growth, and therefore, may be oppress the principal forest crop.

2. Planting and Management

1) Planting

Healthy seedlings with good surface and sub-face balance should be selected for erosion control planting due to the poor soil conditions of the terrain. Additionally, close attention should be paid to prevent from damaging the seedlings during digging out, temporary planting, and transportation.

Planting seasons somewhat vary depending on the region, but should be basically performed in the spring.

Seedlings should be planted somewhat deeply in a largely dug out planting hole with the application of soil dressing and fertilizer as deemed appropriate. On the contrary, seedlings must be planted high in low damp ground or in high ground water areas to prevent rainwater accumulation in the planting holes.

2) Management

Planted trees must be protected with straw litter around the bottom of the trunk in order to prevent desiccation along with weeding until they survive and commence to grow. Additionally, close attention must be paid to the competition against the principal forest crops when mix-planted with soil improving trees. This is particularly important when light demanding trees such as pines are used for the principal forest crop. In such case,

the number of salvage cutting frequencies needs to be increased for frequent removal. Furthermore, additional fertilization should be performed to facilitate growth when found to be poor. Supplementary planting should be performed rapidly when bare ground surface caused by dead standing trees are found since devastation may expand again from such ground. Moreover, partial foundation work damages must be immediately restored since such conditions may result in excessive disasters.

Chapter IV TORRENT IMPROVEMENT WORK

Section 1 Basic Hydrolics for Torrent Work

1. Hydrostatic Pressure

Rest water which is not flowing is called static water. The pressure of the weight of the water under the static condition is called the hydrostatic or hydraulic pressure. This force is uniform on the surface, and the total resultant of force effecting the entire plane is called the overall hydraulic pressure.

1) Intensity of Hydrostatic Pressure

Hydrostatic pressure is expressed per unit areas since the force is distributed on the plane. The following equation is derived when the hydraulic pressure is uniform at any points on plane A, with the overall hydraulic pressure is P and the force of the water is P:

$$p = \frac{P}{A} \quad (5-1)$$

Total hydraulic pressure is expressed in kg, and other hydraulic pressures are expressed with unit kg/cm^2 and t/m^2 , etc. The overall hydraulic pressure effecting a certain plane may be considered as a concentrated force equivalent to the hydraulic pressure effecting the plane. Therefore, it is necessary to define the effecting point of the overall hydraulic pressure as well as its side.

2) Hydrostatic Pressure Characteristics

Hydrostatic pressures effect the plane vertically. Furthermore, the hydrostatic pressure p is proportional to the depth of the water h . Therefore, with the unit weight⁽¹⁾ of the water as w ; it may be expressed by the following equation.

* (1) Weight per cubic unit.

$$p = wh \quad (5-2)$$

Additionally, the hydraulic pressure on a certain point in the water acts constant force in all directions.

(Diagram 5-1)

Diagram 5-1 Hydraulic Pressure On A Certain Point

3) Hydraulic Pressure Effecting A Level Plane

(1) Hydraulic Pressure On A Horizontal Plane

The intensity hydraulic pressure acting on horizontal plane such as the bottom of a container is uniform at any point on this plane. Therefore, the overall hydraulic pressure P may be derive from the following equation where the depth of the water is h , whereas $p = wh$, and the area as A :

equation (5-3)

*The point where the overall hydraulic pressure effects this surface is at the center of gravity.

Diagram 5-2 Hydraulic Pressure on A Horizontal Plane

(2) Hydraulic Pressure on A Vertical Plane

Hydraulic pressure effects a plane perpendicularly and is proportional to the depth. Therefore, the distribution of the hydraulic pressure effecting the rectangular zone of the perpendicular height L becomes ΔABC as illustrated in diagram 5-3. Therefore, the overall hydraulic pressure P is described by the following equation with the width of this zone as b .

equation (5-4)

*Open spaces and in scribe the equations, Δ , Z manually after completion!!!

Diagram 5-3 Hydraulic Pressure on A Vertical Plane

The effecting line of this overall hydraulic pressure P . The water depth at the effecting point D is $\frac{2}{3} L$ since the effecting line of the overall hydraulic pressure P works its way vertically towards the plane AB through the center of the ΔABC .

1) Center of gravity on a plane schematic.

(F) Hydraulic Pressure on A Sloped Plane

The distribution of the hydraulic pressure strength effecting a sloped plane AB with gradient incline 1: n as illustrated in diagram 5-4 becomes ΔABC with LB as a right angle. Since $AB = L \cdot \sqrt{1+n^2}$, $B = WL$ at this point, the overall hydraulic pressure P may be derived from the following equation with the width of the area as 6.

equation (5-5)

The water depth at the D is $\frac{2}{3} h$ since the effecting line of the overall hydraulic pressure P works its way vertically towards the sloped plane AB through the center of the ΔABC .

Diagram Hydraulic Pressure on A sloped Plane

2. Stream Flow Velocity and The Sand Pebble Movement

1) Basic Discharge Characteristics

(1) RYUSEKI, Wetted Perimeter, and Hydraulic Padius

The movement of water is called flow.

The cross section of the channel perpendicular to the direction of the flow is called the transverse channel section, and the area or the portion of the

transverse channel section with water is called the RYUSEKI. Additionally, the length of the transverse channel section contacting the water is called the wetted perimeter.

Furthermore, the result derived by dividing the RYUSEKI A by the wetted perimeter P is called the hydraulic radius R . The following equation is the formula for the aforementioned:

equation In Diagram 5-5(b), it is (equation) equation (5-6) .

Diagram

RYUSEKI is expressed in units of m^2 or cm^2 , whereas the wetted perimeter and hydraulic radius are expressed in units of m or cm .

(2) Velocity and Discharge

The water in an open channel (1) flows from a higher elevation to a lower elevation. The speed of this flow is called the flow velocity. This flow velocity is expressed as the flow distance within a specified. The flow velocity v flowing the distance L within the time t may be derived from the following equation, and is expressed in units such as m/s and cm/s .

equation (5-7)

Generally, this flow velocity differs at every point of the RYUSEKI. Therefore, the average flow velocity for the overall RYUSEKI is considered, and is used as the average flow velocity of that particular RYUSEKI. Additionally, the volume of water flowing through the RYUSEKI within that time is called the flow rate. The following equation may be derived with the average flow velocity as v , the RYUSEKI as A , and the flow rate as Q .

equation (5-8)

The flow rate units are expressed in m^3/s and l/s , but also may be expressed in t/s since the volumetric weight of water is in units of $1t/m^3$.

Open channels are water ways such as streams rivers, and artificial canals possessing free water surface contact with the stmosphere.

2) Flow Velocity Measurement

(1) Velocity of Flow Distribution in an Open Waterway

The flow velocity at various points of transverse channel sections is not constant. This inconsistency is due to effects of the SODO which express is the coarseness of the waterway walls, the shape of the transverse channel section, channel sinuosity, and the depth of the water. Diagram illustrates the distribution of the flow velocity at the transverse channel section as a flow velocity contour curve.

The flow velocity of flow generally become greater further away from the channel sides and bottom.

*This phenomenon is the resultant of the reduced effects of friction with the aforementioned sides and bottom. Therefore, the maximum velocity v_{max} is generated at a point slightly below the surface in the vicinity of the center of flow. Additionally, the surface flow velocity of is smallest along the coasts as illustrated in diagram , and increases further distance away from the coasts until it becomes greatest in the vicinity of the center of flow. Furthermore, the curve which describes the flow velocity distribution on a perpendicular line through a certain point of the transverse channel section is called the vertical flow velocity curve. The vertical curve in the vicinity of the center of flow generally becomes similar to that illustrated in diagram Hereby, the maximum flow velocity v_{max} is generated $0.1h - 0.4h$ beneath the surface of the water, and the average flow velocity v is generated at a depth of $0.5 - 0.65h$.

Diagram Flow Velocity Distribution

- (a) Flow Velocity Contour Curve
- (b) Flow Velocity Curve
- (c) Vertical Flow Velocity Curve
- (v) Flow Velocity

(h) Water Depth

(2) Flow Velocity with a Current Meter

A current meter is a device used to measure the flow velocity. The measurement is accomplished by lowering a propeller into the desired depth of the water current in order to count the number of revolutions within a specified time. The flow velocity may be derived from the following equation since this equation is generally applicable to express the relation between the number of revolutions and the flow velocity of flow.

equation (5-9)

Note: v : flow velocity (m/s), a/b : constants, and
 N : number of propeller revolutions per second.

* a and b values are the exclusive constants of the current meter and should be primarily derived through experimentation. Current meters are available with cap form propellers with rotating shafts perpendicular to the flow, and those illustrated in diagram have with shafts parallel to the flow.

Diagram Current Meter

Transverse channel sections are segregated with perpendicular lines for transverse survey in fairly large waterways with large flow rates as illustrated in Diagram 5-8, in order to derive the average flow velocity

in the individual segregated sections through in equation with the velocity measurements taken at several points on the perpendicular line running through the center of these sectors. The following equations are available for deriving the average flow velocity of the segregated sectors when the flow velocity in depths $0.2h$, $0.6h$ and $0.8h$ are $v_{0.2}$, $v_{0.6}$ and $v_{0.8}$, respectively, with the depths of the perpendicular line running through the center of the segregated sectors at h . The following are the applicable equations:

- 1) Point Method (equation)
- 2) Point Method (equation) (5-10)
- 3) Point Method (equation)

Generally, the 2 Point Method which is relatively simple with high accuracy is used. When particularly accurate values are required, cross sectional flow velocity curves are drawn for the individual section to derive the area surrounded by these curves and the vertical axis and to divide this with the depth to derive the average flow velocity of each section. *The average flow velocity of the overall channel section is derived by dividing the flow rate obtained with the "Laws of Flow Velocity" explained in the following "Flow Rate Measurement" by the overall flow area.

(3) Flow Velocity Measurement with Floats

This is a method where the flow velocity is derived by equation (5-7) based on the time measured for a float to float downstream for a certain distance.

*Among the various floats available, there is the surface float which floats on the water surface and the pole float provided with a weight to maintain an upright position in order to measure the average flow velocity of the surface and sub*surface currents.

3) Average Flow Velocity Formula

Although various formulas are available to derive the average flow velocity, it is best represented by the SHEZY formula described below:

$$v = C R I \quad (5-11)$$

Where; v: average flow velocity within the flow area (m/s), C: flow Velocity coefficient,
R: hydraulic radius(m), I: water surface slope.

Various empirical formulas are available for deriving the flow velocity coefficient C:

(1) Bazan Old Method:

equation (5-12)

Where; C: flow velocity coefficient, R: hydraulic radius (m), a, B: porosity coefficient
Generally, $\alpha = 0.0004$ and $B = 0.0007$ are applied for wildstreams. Details of the porosity coefficient are described in Chart 5-1.

Chart 5-1 Porosity Coefficients for the BAZAN Old Method

1. Classification

2. Channel

Cement coated or plane finished wood channels.

Smooth surfaced quarry, brick, or unfinished wood channels.

Rough quarry work or stone work channels.

Natural earth and stone channels.

Channels washing down rubbles and rough gravel.

(2) BAZAN New Method

equation (5-13)

Where; r: porosity coefficient

Generally, $r = 1.75$ is used for wildstreams.

Details of the porosity coefficient are described in Chart 5-2.

Chart 5-2 Porosity Coefficient for the BAZAN New
Method Type of Channel

Smooth cement coated or plane finished wood channels.

Concrete, brick, or rough wood channels.

Rubble masonry or rough brickwork channels.

Uniformed soil channels.

Normal soil channels.

Rough soil channels.

4) The Flow Velocity Limit and the Stable Slope of Gravel

(1) The Flow Velocity Limit of Gravel

The current tends to impact and wash off the gravel on the streambed.

In turn, the gravel tends to resist this force by the friction with the streambed. The larger the friction at this point, the longer gravel remains, but gravel is washed off when this friction is small.

The magnitude of this impact force to washout the gravel is proportional to the square (v^2) of the flow velocity. Therefore, the movement of the gravel is wholly contingent on the flow velocity. This is why the maximum flow maximum velocity for the gravel to remain on the streambed is called the Flow Velocity Limit of the gravel. The following is the simplified

formula to derive the aforementioned:

equation (5-14)

Where; v_g : Flow Velocity Limit of the Gravel (m/s),

K: Constant 3.7 - 5.3/average 4.5

b. The length of gravel in the direction of the flow.

Assuming that the streambed is comprised of layers of packed gravel, the discharge tends to wash these gravel layers with a somewhat leveling force. This force is called the tractive force and becomes larger with an increased hydraulic radius and water surface slope. The flow velocity of becomes larger in accordance with equation (5-11) when the hydraulic radius and the water surface slope are large. Therefore, the tractive force too, is closely related to the magnitude of the flow velocity.

(2) Stable Slope

The flow velocity of flow decreases when gravel is mixed in the current.

Therefore, when the containing gravels of various sizes reaches a certain point, gravel on the streambed with a flow velocity limit smaller than the speed of the current is washed away.

Since the flow velocity becomes smaller at this point, washed down gravel with a flow velocity limit larger than the speed of the current settle down on the streambed. As previously described, the discharge current not only washes away gravel, but settles gravel also. The streambed becomes eroded when the volume of the washed out gravel is larger than the settlement, and sitting occurs when the washout is smaller. Furthermore, the streambed slope remains the same although the gravel may be changed when the aforementioned factors are equal.

This unchanging slope is called the stable slope.

In order to derive this, it becomes;

$$C Rl = vg = K b$$

when considering equations (5-14) and (5-15) to be equal. With both sides squared, it becomes;

equation (5-15)

Therefore, the slope l where the gravel with the diameter b becomes stabilized is described by the following equation:

equation (5-16)

Where; $K' = \frac{K^2}{C^2}$

Generally, the flow rate is less and the volume of the gravel on the streambed is longer in the upstream compared to the downstream. Therefore, the stable slope is steep in the upstream and relaxed in the downstream as described in Equation (5-16). But when observed on separate points, the stable slope varies due to the states of gravel intermixture and flow rate variation.

3. Flow Velocity Measurement

When executing or designing stream work, it is necessary to know the flow rate of the stream both for normal and particularly for flood conditions. The following are the often practiced methods among the various flow rate measurement or approximation methods:

1) Flow Velocity Method

This is a method where the flow velocity is derived with the product of the measurement taken of the average flow velocity and the flow area. The desirable measurement point is where the channel is straight and the channel width and depth are constant. The flow velocity is measured with the most compatible method for the condition of the stream and the purpose of the measurement.

The flow area is to be derived by cross sectional survey of the channel.

For streams with broad streambeds and large flow rates, the cross section of the stream is segregated into several sections in order to derive the cross sectional area and the average flow velocity individually. Then, the flow rate for the individual sections are derived with the product of the cross sectional area and the average flow velocity.

These are then summed to obtain the total flow rate of the stream.

The following equation describes the above as a formula:

equation (5-17)

Where; Q: total flow rate,

An: Gross Sectional Area, V1, v2, v3

Sectional average flow velocity

2). Method with the Spillway of A Check Dam

When the water is held in the upstream of the dam without silting, the flow rate is derived by the measurement of the depth of water overflowing from the spillway. When the cross section of the spillway is a trapezoid with 10% side grading, the flow rate may be derived by the following equation:

equation (5-18)

where: Q: flow rate, B: length of the crown of the spillway, h: overflow water depth

When silt is deposited up to the crown of the dam from the upstream, the flow rate is derived from the product of the flow area and average flow velocity measurements taken on the overflow from the spillway.

3) Flood Level Marking Method

This is a method where the maximum flow rate during floods are estimated from the flood markings.

Although the method is simple to use, the result also tends to be inaccurate. The flood level is estimated by surveying the channel immediately after the flood as well as by checking the water coverage states of the vegetation in the vicinity, surface soil washout, contamination by muddy water, and washed down soil locations, etc. Following these, the channel is cross sectionally surveyed to obtain the flow volume.

Additionally, the water surface slope or the streambed slope is derived from the flood level in order to derive the average flow velocity by the average flow velocity formula. Then, the maximum flow rate during the flood is derived by the product of the flow area and the average flow velocity.

4) Method by Rational Formula

This is a method used for determining the cross section of the dam spillway and estimating the maximum flow flood rate, and the flow rate is derived by the following equation:

equation (5-19)

Where: Q: maximum flood flow rate, f: run-off factor
r: maximum hourly rainfall, A: watershed area

5) Method by the Proportional Flow Rate

The value of the flow rate at a certain point on the stream or river divided by the watershed area is called the proportional flow rate. Therefore, the flood flow rate may be approximated when the proportional flow rate during the flood and the watershed area are known. The formula for the this is described below:

equation (5-20)

Where; Q: Flood flow rate, q: proportional flow rate of the flood, A: watershed area.

Although the proportional flow rate should be derived for the individual points, the proportional flow rate for wildstreams during floods are generally as listed in Chart 5-3.

Chart 5-3 Proportional Flow Rate of Wildstreams During Floods

1. Water shed Area

2. Proportional Flow Rate

*Run-off factor: the run-off volume is the total volume of water run-off from the watershed divided by the area of the watershed. This figure divided by the rainfall volume is called the run-off factor.

Section 2 Objectives and Types of Torrent Improvement Work

1. Objectives of Torrent Improvement Work

Large volumes of gravel, soil, and sand are transported downstream during floods of wildstreams, and therefore, sedimentation zone tends to cause disasters. Therefore, torrent work has the following objectives.

- 1) To secure the foot of devastated hillside and to enhance natural restoration of the landslide area.
- 2) To prevent the erosion of streambeds and banks as well as to prevent hillside collapse.
- 3) Form a sound and stable stream by preventing the washout of unstable soil as well as stabilizing the stream by sedimenting the run-off soil from the devastated land upstream and by controlling the run-off downstream.

2. Types of Torrent Improvement Work

The flow velocity must be reduced to decrease the erodibility of the discharge of the torrent. The streambed gradient and the water depth must be reduced. This is why check dams are erected. They reduce the gradient of the torrent bed by sediment in their backwater area.

Additionally, the streambed width increases and the water depth reduces along with the sedimentation (diagrams 5-9 and 10 refer).

Among structures erected mainly for prevention of such longitudinal erosions are sediment control dams, bed sill work⁽¹⁾, and check dams⁽²⁾. Since these structures are erected across the stream, they are generally called lateral works.

* (1) Explained in details later

(2) Small dam-like structures erected in the upstream regions of the torrent.

In the other hand, when the turbulent flow in the stream becomes excessive, the channel discharges and erodes the bank, risking the danger of hillside failure. Among the structures erected for prevention of this cross erosion are retaining walls and spur jetties. These structures are erected on the banks along the stream, and therefore are called longitudinal works.

*Both lateral and longitudinal work should be done in conjunction with each other in order to stabilize the torrent since lateral and longitudinal erosion generally take place simultaneously in torrents. Stone paved channel work and concrete channel work are done at times to increase the resistance of the streambed against the erosion by the discharge. Furthermore, in the downstream of the torrent, channel work⁽³⁾ is also done at times to protect the bank and to secure the streambed.

Section 3 Check Dam (Sand Check Dam or Sediment Control Dam)

1. Objectives and Types of Check Dams

1) Purpose

Sediment Control dams are structures built across the stream with the following objectives.

- (1) To reduce the streambed gradient to prevent longitudinal erosion. This is accomplished by erecting a tall independent dam or with multiple stepped dams as illustrated in Diagram

*1), 2), and 3) are explained in detail later.

Diagram Reduction of the Streambed Gradient

1. Tall Dam
 2. New Streambed by the Tall Dam
 3. Original Streambed
 4. Stepped Dams
 5. New Streambed by Stepped Dams
- (2) To prevent the hillside from collapse by securing the hillfoot. As illustrated in Diagram , the streambed is elevated to secure the unstable hillfoot in order to prevent the hillside from collapse as well as to preclude collapse from expanding.

Diagram Securing the Spurs

1. Original hillfoot
 2. New hillfoot
 3. Sedimentation
 4. Dam
 5. Original Streambed
 6. Falls and debris without the erection of a dam.
- (3) Store the gravel washed down from the upstream and controls the runoff to the downstream.
- Dams for such purpose are called sand sedimentation dams and can restrict as well as reduce the force of debris flows. The embankments are generally constructed high as illustrated in Diagram

Diagram Soil Sedimentation

1. Dam
2. Soil Sedimentation

(4) Turbulent flows are prevented and streambeds are secured in sedimentation zone. Low stepped dams are erected as illustrated in Diagram 5-12 in order to prevent side erosion by restricting the channel.

Diagram Securing the Streambed

1. Dam
- 2) Variations

The types of sediment control dams are generally classified in accordance with their structural material, form, and type of resistance against external force.

(1) Classification in accordance with the structural material:

Wet masonry, Dry masonry, Mixed masonry, concrete, boulder concrete, steel reinforced concrete, concrete frame, steel, cylinder, wood, and soil, etc.

(2) Classification by the form:

Line, arch, and buttress or counterfort, etc.

(3) Classification by the resistance against external force:

Gravity and arch system, etc.

3) Individual Sediment Control Dam Section Nomenclatures

1. (a) Front View
2. (b) Side View
3. (c) Plane View
4. 1 Spillway and overflow section
5. 2 Spillway Crown and Embankment Crown
6. 3 Wing
7. 4 Wing Crown
8. 5 Drain Opening
9. 6 Upstream Grading, Water Surface Grading
10. 7 Downstream Grading, Water Back Grading
11. 8 Embankment Bottom
12. 9 Apron
13. 10 Side Wall
14. 11 Vertical Wall
15. 12 Overflow Section Side

Diagram Individual Dam Section Nomenclatures

4) Major Sediment Control Dams & Their Features

(1) Concrete Dam

This is a dam constructed by forming the shape of the dam with wood or steel frames and pouring concrete within the forms. The embankment may be made into an uniformed structure with this method.

Additionally, dams made with this method exhibit superb durability, and therefore, tall dams can be made. This is why this method is most widely used lately. Gravity type concrete dams are most representative of this method. This dam resists external force with its own weight and is generally and may be constructed on gravel layers or soft rockbeds upon treatment of the ground.

*Arch type concrete dams relate the external force to the rockbeds in the sides with the arch effect to resist external force. The embankment may be constructed thinner than the above gravity dams with this method, but the design and execution become more complicated. Therefore, arch dams are constructed when the foundation as well as the side rockbeds are rigid and the valley is narrow compared to the height of the embankment.

(2) Steel Dams

The foundation and wings of this type of dam are constructed with concrete. In top of this foundation, buttress frames comprised of H framed steel assembled into inverted V shapes are placed every 2 meters. The embankment is then formed by placing V frame steel in screen form onto the front of these frames. The material quality is uniformed since the structural members are factory produced. Additionally, execution of this work requires no exclusive technology since the work is accomplished by simply assembling the materials. Therefore, the work may be performed efficiently in a short time period and may be used in undeveloped areas using existing transportation systems. Furthermore, harmless sand is sifted and run-off with the screen structure and only large gravel and boulders washed down by floods are intercepted. Therefore, the hydraulic pressure may be reduced with this large filfration. Due to these reasons, many construction examples are seen despite the short period since its development. However, this method is not suitable for high acidity water due to the corrosiveness of the steel members and securing joints. Moreover, this dam is fragile against impacts as well

as force from the diagonal direction. Therefore, this method cannot be done in areas prone to large scale debris flows as well as in curved flow areas.

Diagram Steel Dam

(3) Other Dams

Concrete crib dams are constructed on concrete foundations with square, concrete columnar blocks assembled into a well crib shaped frame filled with boulders. This has improved durability over the wood crib dam and exhibits features identical to the steel dam for execution. However, blocks in the vicinity tend to become damaged in this method.

This method is generally done in minor streams with minimal blow rate and abundant gravel or in minor streams within the land creeping area.

Check dams employing cylinders have been long used in bare mountain areas. This work is accomplished by piling one or more cylinders and stopping them with piles. Since this method exhibits superb flexibility as well as compatibility with the scour of the foundation and earth settlement, it is done in minor streams on unstable earth.

However, it should only be used for temporary

structure due to corrosion of the steel wire resulting in low durability.

Diagram Concrete Frame Dam

*Dry masonry dams are constructed simply by piling stone materials and were previously employed for check dams in undeveloped areas. Wet masonry dams are constructed of masonry coated with concrete as an adhesive and internally filled with boulders. Although this type of dam was often constructed in areas where satisfactory stone materials were available, they have been rarely constructed in recent years.

2. Location and Direction of Check Dams

1) Erection Location

The following conditions must be satisfied for the erection of a dam:

- (1) The dam must be erected in a spot with rigid bedrock in the streambed or banks. This condition must be satisfied since the dam may collapse if the discharge over-flowing the dam washes out the grading edge or erodes the banks when the foundation is soft.

- (2) The dam must be erected in a location where the banks are narrow and the streambed gradient upstream is gentle as well as where the streambed is broad. The length of the dam may be shortened and the costs are reduced when the valley width is narrow. Additionally, large amounts of soil, sand, gravel, and rocks may be sedimented when the streambed gradient upstream is gentle and when the streambed is broad.
- (3) The dam must be erected in the downstream of a junction when erecting a dam in the vicinity of the stream junction. Dams should be located when one of the streams is devastated and should be located in at a point where the joint current becomes stabilized when both streams are devastated.
- (4) The point where the estimated sand sedimentation line intercepts the existing streambed is the site for the upstream dam when planning dams in steps as illustrated in Diagram
Based on these principles, the dam location is determined in accordance with the objective of the dam.
Furthermore, when the objective is to prevent streambed and bank erosion as well as hillside

collapse and expansions, the dam is to be erected downstream in the vicinity of these possible catastrophe areas. Additionally, the dam is to be stepped when this section is long. Moreover, the dam is to be planned downstream of the sedimentation zone when the objective is to store sediment the transported soil.

2) Direction of the Dam

The water overflowing the dam generally runs-off in a perpendicular direction to the dam. Therefore, when the stream is straight, the dam is to be constructed perpendicularly to the stream.

Dams should not be located in curved flow section, however, when other sites are not available, it is to be designed in a perpendicular direction to the tangent line of the center of the flow line during floods at the center of the overflow section. Additionally, when the existing streambed width is narrow and the stream is bent as illustrated in Diagram the new streambed after the soil sedimentation in the dam often tends to become straight. Therefore, the direction of the dam must be determined with considerations for the estimated new center of the flow line.

Furthermore, when designing stepped dams in curved flow

areas, the dams are to be planned in a perpendicular direction to the line connecting the center of the overflow section of the upstream and downstream dams as illustrated in Diagram

Diagram Direction of the Dam

1. Original Streambed
2. New Streambed
3. Correct Dam Direction
4. Incorrect Dam Direction

3. Design Accumulating Gradient and Dam Height

1) Design Accumulating Gradient

One of the objective of soil conservation dams is to sediment soil upstream in order to make the streambed gradient gentle to produce a longitudinal and side erosion free stable stream. It is important to estimate the new streambed gradient. This is called the planned streambed gradient, and the height and location of the dam is determined with this figure.

*The sedimentation of dams generally are steep when the gravel discharge from the upstream is excessive or when the gravel sizes are large, and are gentle when the flow rate is large. Sedimentation occurs on steep gradient during large floods, but this

gradient gradually becomes relaxed with succeeding intermediate and minor floods. The gradient of the streambed is therefore changing constantly with the repetition of the this phenomena.

*The planned streambed gradient for designing dams is determined with examples in the vicinity as references based on the standard $1/2 - 1/3$ of the existing streambed gradient with the streambed comprising gravel and the flow rate, etc. taken in consideration.

2) Dam Height

The height from the base of the dam to the crown of the overflow section is called the dam height, and the height from the streambed prior to construction to the crown of the overflow section is called the effective height. The height of the dam is determined upon considering the objective of the dam construction, ground condition, and the planned streambed gradient, etc. Therefore, the objective must be clearly distinguished as well as the foundation ground of the projected dam construction site must also be thoroughly surveyed when determining the height of the dam. The dam height in accordance with these objectives is described below.

- (1) Whether to construct a relatively tall dam or several low stepped dams is determined in accordance with the conditions of the project site when the objective is to prevent the erosion of hill foot in large scale land creep areas. In this case, it is often more effective to construct several low dams in place of a single tall dam. This is because lower dams are smaller in volume and more economical as well as receive less scour on the downstream slope. However, taller dams are superior to the lower versions as far as the soil sedimentation volume is concerned.
- (2) Low dams are constructed in steps generally when the objective is to prevent the erosion of the hillfoot of the streambank land creeping area.
- (3) The dam height must be sufficient for the protection of the foundation when the objective is to protect the foundation of structures from scour.
- (4) The dam height must be as high as possible for the foundation ground and the topological conditions when the objective is sedimentation.

3) Sand Sedimentation Volume Calculation

Cross sectional and longitudinal sectional methods are available for derivation of the sand sedimentation

volume. The longitudinal section method is explained below.

*Behind the dam AB as illustrated in Diagram it is assumed that the longitudinal section becomes ABC. This longitudinal section area is multiplied by the average width of the sedimentation to derive the sedimentation volume.

Where V: sand sedimentation volume

h: effective height of the dam

$\tan \alpha$: original streambed gradient

$\tan \beta$: new streambed gradient

z: average length of the sedimentation

b: average width of the sedimentation as

equation

it becomes:

equation

Therefore, it becomes:

equation (5-21)

Because:

equation

It becomes:

equation (5-22)

Diagram 5-19 Sedimentation Cross Sectional View

1. New Streambed
 2. Original Streambed
 3. Soil Sedimentation
 4. Dam
4. Overflow Section and Wings

The part of the dam through which the overflow passes is called the overflow section and its form, size, and sleeve structure is important for the preservation of dams.

1) Location

The location of the overflow is to be determined with the soil structure and topological conditions of the banks and the apron of the projected construction site taken into consideration.

- (1) The overflow section may be provided anywhere when the banks and the streambed at the foot of the downstream slope is comprised of rigid bedrock.

- (2) The overflow section is located in the center of the stream when the bank are not comprised of rockbeds and fragile.
- (3) The overflow section is located closer to the bank with the rockbed when the rockbed exists only on one side.
- (4) The overflow section is located in a position where it will not cause erosions when structures such as housing, agricultural cultivation, and factories exist along the streambank downstream.
- (5) The overflow section is to be located in a position where the banks are free from the effects by the discharge when land creep areas exist in the banks and hillsides upstream the dam.

2) Shape

Trapezoidal, arch, and rectangular shapes are seen in overflow section. However, trapezoidal shaped overflow section are most commonly seen. The width of the overflow section should be increased as much as possible to reduce the stream depth in order to decrease the head to minimize the washout of the downstream slope of the dam. Furthermore, in streams with wide streambeds and large gravel discharge volumes, composite sectional shapes are

employed at times as illustrated in Diagram since gravel may sediment in the overflow section and increase turbulent flows.

Diagram Location and Shape of Spillways

1. Gravel
2. Rock
3. Overflow Section
4. Land creep ground

3) Gross Section

The dimensions of overflow section generally should be sufficient enough for running off the maximum flow rate during floods safely with room for debris and driftwood taken in consideration. The maximum flood flow rate is determined by the watershed area, rainfall volume, hillside gradient, forest conditions, and the hillside devastation conditions.

A sample method for the selection of the open overflow section is explained as follows:

- (1) The maximum flood flow rate Q is by rationalization (equation 5-19).
- (2) The maximum diameter of the intra-streambed gravel is selected. Additionally, the average

diameter of the largest sized intra-streambed gravel thought to have been washed down is derived.

- (3) The limit flow rate v_g of the gravel with maximum diameter is derived. $v_g = K b$ (Equation 5-14) is to be used.
- (4) The designed streambed gradient I is estimated. It should be about one half of the existing streambed gradient.
- (5) A hypothetical overflow section is determined. The following calculations are to be performed using the values of 1) through 4).

- a) The cross section area F is derived by the following equation:

equation (5-23)

- b) The hydraulic radius R is derived by the following equation:

equation (5-24)

However, α and β are the coefficient of roughness of the BAZAN old method. This formula uses the BAZAN old method in Equation (5-15) C to consolidate the quadratic equation

of R for derivation by the root formula of the quadratic equation:

equation

- c) The wetted perimeter P is derived by the following equation:

equation (5-25)

Based on the cross section area F, hydraulic radius R, and wetted perimeter P derived, the cross section is approximated with extra room for the local conditions taken in consideration.

(6) Selection of the Overflow Section

The following values at the estimated section are to be derived.

- a) The cross section area F', Wetted Perimeter P', and hydraulic radius R' are to be derived by Equation (5-6).

- b) The safety factor n of the cross section area is derived by the following equation:

equation (5-26)

- c) The average flow velocity v' is derived by Equations (5-11/12) and the flow rate Q'

is derived by Equation (5-8).

- d) The safety factor of the flow rate n' is derived by the following equation:

equation (5-26)

- e) The estimated overflow section is selected for use when the safety factors n and n' are about two to five.

Reestimate and recalculate the selection of the overflow section when the derived safety factor is insufficient.

4) Overflow Section

The overflow section is degenerated by the run-off gravel and may become destroyed by the impact of boulders or by the pressure from the discharge. Protection structures are therefore executed as required.

The following describes the various protection work methods available.

(1) Stone Consolidation

Closely consolidated rigid stone is used not only in wet masonry dams but also for the overflow section crown of concrete dams.

(2) Rich Concrete Mixture

The crown is separately constructed by using rich mix concrete.

(3) Other Methods

Other methods which use steel plates, old rails, and fibre glass boards on the spillway crown are also available.

2) Wing

The overflow section is sufficiently to pass the maximum flood flow rate. However, it must be solidly constructed since debris and driftwood may be generated more than expected and overflow the sleeve. Furthermore, the crown of the dam wing in locations described in the following is to be provided with an upward gradient towards the bank. (An upward gradient must be provided:)

(i) immediately below landcreep areas, (ii) at debris generated areas, (iii) at driftwood discharge areas, and (iv) at curved areas of the stream.

The gradient in these cases is generally about the same as the designed streambed gradient of the dam. The required penetration depth of the wing into the banks is about 1 to 2 meters for bedrock and about 2 to 3 meters for soil. Additionally, the connecting member

of the wing to the banks often is damaged, resulting in the destruction of the dam, and therefore must be reinforced by protection works.

5. Dam Sections and Conditions of Stability

1) Selection of the Dam Section

The selection of the dam section for linear gravity dams is generally accomplished by selecting the height, crown width, downstream gradient, as well as the upstream gradient to attain a cross section satisfying the safety requirements.

The dam base is determined along with these items.

(1) Height

The determination of the dam height is made based on Section 3-2 "Dam Height" described earlier.

(2) Crown Width

The crown width is determined by the discharged gravel dimensions, overflowing water depth, and the designed upstream streambed slope. The crown width is about 1.5 meters in ordinary devastated streams, over 2 meters in locations where large boulders and excessive debris are expected, and about 1 meter in small streams with smaller sized gravel discharge such as SHIRASU or ash.

(3) Downstream Slope Gradient

The downstream slope (gradient) must be steep in order to protect the slope (gradient) surface by the discharge and gravel, etc. overflowing the dam directly on the apron. The gradient (slope) is about ^{*}20% generally, and

about* 30% for lower dams under 6 meter embankment
(direct something better pls) height.

(4) Upstream Slope Gradient

The upstream slope gradient is determined in accordance with the dam height, crown width, and downstream slope determined earlier, satisfying the stability conditions for gravity dams.

(5) Dam Base Width

The dam base width may be derived by the following equation when the height, crown width, upstream and downstream slopes are determined.

$$B = b + (n+m)h \quad (5-28)$$

2) Stability Conditions

The gravity dam resists various external forces with the weight of the dam body. These external forces may be segregated into the components of hydraulic pressure and debris flow impact, sedimented sand pressure, and earthquake force. However, only the hydraulic pressure is often considered with the unit weight of the water estimated between 1.2 to 1.8 t/m³. The following conditions must be satisfied in order to ensure the safety of the dam against these external forces.

- 1) Not topple
- 2) The dam body has not failed
- 3) The foundation has not failed
- 4) Not slideable

These conditions are considered satisfactory when they are applicable for a unit length of the dam.

(1) Toppling Stability Inspection Against

The effecting line of the composite external force and the dead weight of the dam body must be through the dam base to prevent the dam from toppling by external forces. Only the hydraulic pressure is to be considered as the external force (overflowing water depth is to be disregarded). The stability inspection method is described in the diagram illustrated in the following paragraph.

The cross section of the dam is taken as ABCD as illustrated in Diagram 5-22. With the length of the top AD as b , the length of the base BC as B , the height as h , the slope gradient of the DC plane as $1:n$, and the unit weight of the discharge as γ_w , the overall hydraulic pressure P effecting the DC plane may be derived by the following equation from the Equation (5-5).

(equation) (5-29)

Diagram Stability Inspection Hydraulic
Pressure Effecting Line

This overall hydraulic pressure effects the DC plane vertically, and its acting point is at point E, $1/3h$ above the dam base.

- * With the unit weight of the dam body as γ_m , the dam length unit dead weight becomes:

(equation) (5-30)

and acts in a perpendicular direction through the center of section G.

Assume A' and C' are connected from the extensions of top AD and base BC so that it becomes $AA' = BC$ and $CC' = AD$ in order to derive the center G of the trapezoidal section ABCD. Furthermore, assume that M and N lie on the median of top AD and base BC. Therefore, the intersecting point G of the segments A'C' and MN is the center of the trapezoidal section.

- * Draw the effecting line of the overall hydraulic pressure effecting the DC plane vertically through point E and the effecting line of the dead weight of the dam perpendicularly from G.

They intersect at point O in order to derive composite force of the overall hydraulic pressure P and the dead weight of the dam W. Establish point P on the extension from O to EO and point W on the extension of GO.

Furthermore, by drawing a parallelogram OP'R'W' with

these sides, the length of the diagonal line OR' is the size of the composite force R of the overall hydraulic pressure P and the dead weight of the dam W . Therefore, it is safe from toppling when the effect line of the composite force R crosses the base BC .

(2) Stability Inspection of the Dam Body Against Destruction

The dam body is destroyed either by tension on the dam body or by the dam body giving way to pressure.

* In order for the dam body to be free from tension, the composite force of the dead weight and the hydraulic pressure must be through two points which bisect the dam base. This trisecting point is called the core point and the area between the two points is called the span within the core kernel. Now, assuming that the perpendicular force V effects point F which is distance α away from β on the dam base BC as illustrated in Diagram 5-23, the pressure distribution on the dam base here becomes the maximum pressure force P_B at point B and minimum pressure force P_C at point C . The pressure force varies linearly between these points. P_B and P_C are described by the following equations:

(equation) (5-31)
(equation)

* In order for the tension to be ineffective, $P_B > 0$ and $P_C > 0$. By analyzing this $\frac{3}{2}\beta > \alpha > \frac{1}{3}\beta$ appears, and therefore, it is proved that it is satisfactory when the perpendicular force V is through the kernel of the dam base.

* In order for the dam body to be safe from destruction by pressure, the allowable pressure resistance K of the material must be greater than the maximum pressure P_B on the dam body. Therefore, it is satisfied by the following equation:

equation (5-32)

Diagram Pressure Distribution
 on the Dam Base

Table 5-4 Allowable Concrete Strength

Allowable Stress Variations

Allowable Strength

Summary

Allowable Compressive Strength

Allowable Bending Tension

Allowable Bearing Stress

Material Age 28 days/1/4 of Compressive Strength

Material Age 28 days/1/7 of Tension Strength

Material Age 28 days/3/10 of Compressive Strength

(Standard Concrete Specifications/Civil Engineering Society)

(3) Stability Inspection for Foundation Failure

It is satisfactory when the safe supportability of the foundation is greater than the effective maximum pressure. Earth settlement and devastation occur when the foundation supportability is insufficient. Additionally, since the maximum pressure on the dam base effects the ground directly, K may be substituted in Equation (5-32) as the safe supportability of the foundation.

* Table 5-5 lists the safe supportability of the individual types of foundations.

Table 5-5 Safe Bearing Value of the Individual Foundations

Type of Foundation

Hard Rock

Granite (Single Horizontal Bed Thicker Than 3m)

Porphyrite (Single Horizontal Bed Thicker Than 3m)

Graywacke (Single Horizontal Bed Thicker Than 3m)

Lime Stone (Single Horizontal Bed Thicker Than 3m)

Soft Rocks (Tuff, Sandstone, Shale)

Sedimentary Rocks (Low Concretion)

Gravel (High Concretion)

Sand (High Concretion)

Viscous Soil

Type of Foundation

Normal

Clay
Ballast Mixed Clay
Ballast
Normal Sand
Hard Clay
Mud

Table 5-6 Friction Factors of the Individual Materials

Type of Material	Friction Factor
Masonry and Masonry	
Good Quality Stone and Masonry	
Ballast and Masonry	
Sand and Masonry	
Dry Clay and Masonry	
Wet Clay and Masonry	

(4) Stability Inspection Against Sliding

The force acting to slide the dam body is the horizontal component P_H of the external force P . The force resisting the aforementioned is the friction generated between the dam base and the foundation. The magnitude of the friction may be derived by multiplying the dead weight of the dam body W and the perpendicular component P_V of the external force by the friction factor f of the friction between the dam body and the foundation. Therefore,

the friction must be greater than the force acting to slide the dam body in order to maintain the safe conditions. The following describes this as an equation.

(equation) (5-33)

It may also be derived from the diagram since $P_V = \frac{m}{1+m^2} P$ and $P_H = \frac{m}{1+m^2} P$ on Diagram 5-22. Additionally, Table 5-6 lists the friction factors between the dam body and the foundation.

6. Drainage Hole

1) Objective

The purpose of drainage hole is to shift the drainage and discharge during the construction of the dam and to reduce the hydraulic pressure on the dam body upon completion as well as upon the seepage pressure after sand sedimentation.

2) Location, Quantity and Dimensions of Drainage Hole

The location and quantity of drainage holes vary in accordance with the purpose of the drainage hole and the dam design.

* A single drainage hole above the streambed line is sufficient for dam construction on narrow streambeds. Several weeping holes must be provided when the streambed is wide since the mainstream shifts with every flood.

- * Several small drainage holes must be provided when the objective is to minimize the hydraulic and seepage pressure. In such a case, the bottom row of drainage holes are to be provided on the streambed line with the higher holes arranged in lattice form. The drainage holes here must be provided with adequate clearance with the neighboring hole and must be perpendicular. Additionally, drainage holes in the top row must be located 1.5 to 2.0 meters below the overflow section crown since they may become the cause of the dam destruction by the impact of the flowing debris.
- * The drainage hole of the dam down stream is to be designed below the foundation of the dam upstream when constructing stepped dams.
- * The dimensions of the drainage hole are to be sufficient enough for surviving several floods annually, since it becomes the weakest point of the dam body when the dimensions are excessive. Generally, drainage holes are square or rectangular with 0.2 to 0.4 meter sides but are also substituted with circular versions with similar sectional areas. Square or rectangular drainage holes with 0.5 to 1.0 meter sides are provided for tall dams executed for sand sedimentation.

7. Protection from Scour

It is desirable for the dam foundation to be comprised of solid bedrock. However, dams often must be constructed on gravel layers due to the objective of the dam. In such a case, the apron is washed-out by the discharge and gravel overflowing the dam. It becomes a cause for the destruction of the dam when left in such condition for extended periods of time since the foundation also becomes scoured. Therefore, apron work, counter dams, and riprap work are performed to prevent the scour. The selection of these works must be made in accordance with the composition of the gravel, flow rate, and the dam height.

1) Apron Work

This work is used to prevent the scour by securing the apron with concrete in direct connection with the downstream part of the dam. This work is used in the downstream part of the stream when the diameters of the discharged and streambed gravel are small with large flow rate.

(1) Length

Apron works are executed in the part where the discharge and gravel fall. Therefore, the distance from the downstream gradient slope of the discharge overflowing the dam overflow section down to the dam foundation level is derived by the following equation and is

extended marginally in order to logically derive the length of the apron.

(Diagram 5-35 refers. The apron work height is to be at a level identical to the counter dam crown).

equation (5-34)

However: l : The length of the apron from the downstream slope edge

h : The effective head of the dam

1) The height from the apron to the overflow section crown

u : The surface flow velocity of the discharge leaving the dam

t : Overflow water depth

g : Acceleration of gravity

$(1:n)$: down stream slope gradient

(2) Thickness

The thickness of the apron work has not yet been logically and actually analyzed. It is generally executed with a thickness of 0.5 to 1.0 meter by experience.

(3) Apron Work is Generally Concrete Structured

Additionally, bamboo (or wire) cylinders and wooden mattress are also used where the flow rate is minimal and only when soil is discharged. However, these lack

durability and are only considered as temporary measures. Additionally, the gradient of the apron is generally level, but is also sloped at times when the streambed slope is excessive.

(4) Vertical and Side Walls

A vertical wall is provided at the tip of the apron for rooting since the downstream slope of the apron on gravel layers becomes scoured.

- * The ground in the sides of the apron becomes eroded since the discharge falling from the dam generates turbulent flows on the apron. Therefore, side walls are provided to protect the banks. The height of the side walls must be determined so that the channel section of the apron becomes larger than the overflow section. Additionally, the crown of the side wall must be provided with an upward gradient toward the upstream. The lower part of the part connecting the side wall to the dam must be 0.5 to 1.0 meter from the shoulder of the dam overflow section. This is done to prevent the side wall from destruction by the discharge and gravel overflowing the overflow section.

2) Counter Dam Work (Secondary Dam)

Low dams provided in the downstream of the dam to prevent the apron from becoming scoured are called counter dams

and the protected dam is called the main dam.

- * Frame constructed with logs and filled with boulders for burial into the streambed.

A water cushion is provided between these dams to minimize the impact of the falling discharge and gravel in order to prevent scouring. This work is executed in the upstream of torrents when the streambed is packed closely with boulders or when the diameter of the run-off gravel is large.

(1) The Overlap Height of the Main and Counter Dams

The main and counter dam heights must be overlapped. To increase this overlapping height unnecessarily is not only uneconomical because of the increased height of the counter dam but also causes increased scour in the downstream of the counter dam. The overlap generally must be about 1/3 to 1/4 the height of the main dam. (Diagram 5-25).

Diagram Main and Counter Dams
Main dam Counter Dam

(2) The Clearance between the Main and Counter Dams

The clearance is determined in accordance with the calculated length of the apron.

(Diagram)

3. Joint Execution of the Apron and the Counter Dam

The apron work and counter dam work are executed together when constructing a fairly tall dam in a stream with a large flow rate and large sized gravel discharge.

This is done in order to protect the apron from abrasion and destruction by the boulders overflowing and falling from the dam by the water cushion of the counter dam.

4. Riprap Work

This is construction where concrete blocks and large boulders are dropped into the scouring part of the apron in lieu of apron works and counter dams to secure the point. However, the dropped materials often become washed away and therefore, this method should only be considered as a temporary measure.

8. Volume Calculations of Part of a Dam

1) Frame and Cubic Volume Calculation

Calculations are made in the following order:

- (1) Draw the front and level view diagrams of the dam with side views drawn at the sides and segregate the dam with horizontal lines intersecting the points where the shape of the dam changes on the front and level view diagrams.

- (2) Derive the top length l , bottom length L , and the height h of each section on the front view diagram. Additionally, derive the top width b and the bottom width of each section on the side view diagram.
- (3) Derive the area A of each section with the following equation:

(equation) (5-35)

When these are summed, it becomes the area of the surface of the dam when the dam slope is perpendicular. Additionally, the area when the slope gradient is $1:n$ is derived by multiplying $1+n^2$ to the area in the perpendicular case. This area must be derived for both the up and downstream. Moreover, the areas of the frames for the overflow section side and the drainage hole must be derived. The total sum of the aforementioned is the area necessary for the frame.

- (4) The individual dam section volumes generally derived by the following equation:

(equation) (5-36)

However, when the shape of the segregated section is rectangular in either one of the front or side view diagrams, the volume is derived by the following equation:

(equation) (5-37)

Additionally, when the shape is rectangular in both diagrams, the volume is derived by the following equation:

(equation) (5-38)

The volume of the dam is the total of the above volumes minus the weeping hole volume.

2) Foundation Excavation Volume Calculation

Calculations are made in the following order:

- 1) Draw the front view diagram of the designed dam into the cross sectional diagram of the stream at the center line of the dam overflow section crown. Additionally, draw a side view diagram at the side.
- 2) Segregate the front view diagram with perpendicular lines. These lines are to be drawn where the shape of the dam base and the ground surface gradient change.
- 3) The following values must be derived for the individual blocks on the front view diagram.
 - a) Height h' : The height from the dam base to the ground surface at the center of each block.
 - b) Extension l' : The length of each block.
- 4) The following values are to be derived on the side view diagram in the center of each block.

- a) Add extra excavation space of the sides of the dam base width for bottom width B' .
- b) The top width b' may be derived by the following equation assuming that the slope gradient of the foundation is 1:n.

(equation) (5-39)

- 5) Derive the sectional area of each block by the following equation:

(equation) (5-40)

- 6) Derive the floor digging volume V' of the individual blocks by the following equation to sum them to derive the total foundation volume.

(equation) (5-41)

9. Dam Construction

Lately, concrete dams are most widely constructed. The following explains the basic execution methods:

1) Construction Survey

The most important item for the construction of a dam is to expedite how efficiently, economically, and safely the work can be executed in the limited construction period. Therefore, it is highly important to establish an effective project schedule based on the survey data. The following

listed surveys should be completed prior to designing the dam. However, further detailed surveys are necessary when constructing relatively large scale dams.

(1) Topographic Survey

1/100 to 1/200 scale cross sectional diagram at the center of the dam is already completed at the design stage of the dam. Therefore, detailed surveys of the area in the vicinity of the projected dam construction site must be performed prior to the execution of the work. Exposed bedrock, spur line, discharge level position, and large boulders, etc. are then inscribed onto the 1/500 to 1/1000 scale topographical chart of the projected dam construction site. Additionally, the temporary drainage area, soil dumping area, and material storage area are to be indicated on the 1/500 to 1/1000 scale topographic chart of the surrounding area.

(2) Geological Structure Survey

Detailed surveys are required when constructing tall or arch type dams. Not only the supportability of a gravel layer or the type of rock in bedrock is required to be identified but faults and fracture zones must also be thoroughly surveyed.

(3) Weather and Current Flow Survey

Thoroughly survey the weather and current flow since they effect the work period most critically. Flood conditions and low water periods in particular are to be surveyed over with data for long periods of time. These data are highly beneficial for determining the execution period as well as desighing the temporary coffer and temporary drainage.

(4) Material Transportation Facility Survey

Most of the dam construction sites are located in areas where transportation is difficult. Therefore, the quality of the material transportation faeility greatly effects the execution of the work. The best transportation facility is a road. Survey the width, gradient, curvature, and bridges as well as necessary improvements and repairs when an existing road exists.

2) Temporary Coffe and Drainage

The stream or river is blocked and is drained through the temporary drainage during the execution of the work in order to facilitate the work attain certain dam execution results.

The best blocking and temporary drainage methods are selected in accordance with general judgement of the topographic, soil structural, thickness of the streambed

sedimentation, and the size of the dam of the projected execution site. It is satisfactory with soil bag blockade in streams with minimal rate of flow. However, rigid soil and stone blockade, sheet pile blockade, and concrete blockade are employed in streams with large rate of flow.

Diagram Temporary Drainage

* The overall stream current is blocked in the up and downstream of the execution site and the water is drained with steel or wooden conduits or by a pump when the rate of flow is minimal in a narrow valley. Additionally, half of the stream is blocked at a time to execute the work when the rate of flow and the width of the stream is large. Furthermore, drainage tunnels are provided at times when the streambed width is narrow in contrast to the rate of flow and the size of the dam is large as well as the bed excavation is deep.

* The trackeary volume of the temporary drainage is to be large enough to run off the flood rate of flow during the execution period based on the execution survey data.

3) Bed Excavation

The streambed is excavated down to expose the bedrock or the gravel layer is excavated to an adequate depth to

secure the bed for the foundation when constructing the dam. This work is called the bed excavation.

(1) Gravel Excavation

The floating soil layer is removed to excavate the thick gravel layer for 2 to 3 meters when the streambed is comprised of a gravel layer. The bed excavation width is to be dug with 0.2 to 0.4m room than the dam base width for the execution of the frame. Additionally, the bed excavation gradient is to be safe enough against falling by rainfall and river bed water. The slope gradient is to be between 40 to 80% in case of soil. Mechanical excavation is recently more employed recently although manual excavation is also possible. However, excessive excavation phenomenon occurs when the entire excavation is accomplished by machinery. Furthermore, TEMODORI occurs in the streambed when it is left unattended for a prolonged period of time after the excavation. Therefore, the bed excavation work is to be executed in combination with the concrete UCHIKOMI (laying) work.

(2) Bedrock Excavation (Digging)

Explosives are generally used to excavate bedrock. It is important at this point to pay close attention to prevent from loosening (G any better term?) the

bedrock in the vicinity of the dam foundation at this point. Therefore, the bedrock is to be excavated manually or with a jackhammer instead of explosives upon excavating down to the designed foundation height. The bed excavation depth is to be determined in accordance with the structural quality of the bedrock and weathering conditions as well as the existence of faults and fractured zones. The depth generally is between 1.0 to 1.5 meter. The excavation slope gradient is to be perpendicular or about one minute. Supplementary excavation is not performed at times in case of a hard bedrock. Moreover, safety should be thoroughly maintained when employing explosives.

(3) Residual Soil

The residual soil is to be primarily transported to the upstream of the dam sleeve with consideration given to preclude this soil from becoming washed out(?) during floods.

4) Foundation

(1) Gravel Foundation

The bottom is to be covered and packed with boulders, ballast and gravel prior to the dam construction when the dam supporting foundation is comprised of gravel.

(2) Bedrock Foundation

The rockbed surface is to be thoroughly cleaned with wire brush to make it porous, and is to be washed with water. Approximately 2cm thick mortar is to be applied on top in order to erect the dam above this foundation.

(3) Ground improvement treatment is to be applied in order to prevent ground settlement and devastation when the foundation ground is fragile (soft?). Piles are to be driven in case of a gravel foundation.

Additionally, the grout method where mortar, etc. are pressure inserted is used in case of a bedrock.

5)

(1) Required Concrete Characteristics

The following characteristics are required for the concrete used for dam construction:

(a) Compression Strength and Water/Cement Ratio

The compression strength required for concrete dams is generally said to be about 10kg/cm^2 . The necessary water cement ratio derived from this compression ratio is considerably greater than that based on durability. Therefore, the water/cement ratio is generally derived from durability.

(b) Durability and Watertightness

Durability is highly important for dams constructed in drastic climatic variation areas due to the excessive surface weathering and erosion generations. The watertightness and durability are generally improved with greater cement unit volume and lower water unit volume. AE agent is used for improving the durability and watertightness with approximately 3% air volume expected to be adequate.

(c) Abrasion and Impact Resistance

The spillway crown, downstream slope, and apron, etc. which receive abrasion and impact are applied with rich mixture concrete, special concrete mixture, or special treatment at times.

(2) Mixture Design

Ready mixed concrete is often used lately. In such case, the mixture design conditions are to be specified when ordering upon selecting the ready mixed concrete factory. It is normal then for the concrete manufacturers to blend the concrete in accordance with the specified conditions. The following are the conditions of the mixture design:

(a) Type of Cement:

Normal Portland Cement, Intermediate Heat Cement, Furnace Cement, etc.

(b) Maximum Dimensions of the Gravel?

Larger maximum dimensions is better in the case of a viscous gravel. It is generally said that 150 mm is most suitable for the dam concrete. However, 40 to 80 mm is the limit for ready mixed concrete.

(c) Slump

Excessive breathing occurs when large slump concrete is used although the workability may be facilitated.

Therefore, minimum slump concrete with the workability still maintained is employed. It generally is about 5 cm at the concrete placing site.

(d) Basic Designed Strength

It is said that the maximum compression strength of a gravity dam with a height of 15 meters is about 10 kg/cm^2 and about 40 to 55 kg/cm^2 for an arch dam. The basic designed strength therefore is the compression strength determined in accordance with the dam height and the stream condition added with the relative safety factors.

(e) Water/Cement Ratio

The water/cement ratio must be altered in accordance with the dam construction location and the weather condition, etc. it generally is about 58 to 62%.

(3) Placing the Concrete

Wooden frames must be thoroughly spewed with water and steel frames must be coated with oil prior to the placement of concrete. Additionally, the part where the concrete is to be placed must be spread with mortar.

One hour may have passed at times from the mixing when employing ready mixed concrete for placement. In such case, close attention must be paid to prevent the material from separating since the slump and air volume

become reduced during transportation.

Cable buckets and portable vertical shutes are employed for placing the concrete. Although the slant shute is frequently employed due to its ease of employment.

However, it should only be employed when other methods are unemployable since the material tends to become separated with this method. In such case, the concrete should not be dropped freely from heights in excess of 1.5 meters.

Diagram 5-29 Placing the Concrete

Additionally, the concrete should be only placed in the placement site and should be prevented from unnecessary movements. A layer of concrete placement should be about 30 to 50 cm in order to be able to be compacted as necessary, and the daily lift height should be between 0.75 to 2.0 meters.

The joint where the concrete is joined by the placement of fresh concrete over the hardened concrete is called the horizontal placement joint. These horizontal placement joints should be prevented from being placed in points effected by excessive force as well as near the water level where excessive weathering occurs since it tends to become the weakpoint of the concrete. The necessary material age for placing additional concrete is at least three days for lift heights under 1m and five

days for heights between 1.5 to 2.0 meters.

The concrete surface should be scrubbed with wire brush within 24 hours from hardening while applying water in order to thoroughly remove foreign objects and to make the surface porous. The concrete is then placed after laying mortar on this prepared surface.

Diagram 5-3 Flexible Joints

Fissures may become generated in long concrete structures by the expansion and contraction occurring during the hardening or the following temperature changing period or by the foundation settlement. Flexible joints are therefore provided in order to preclude this fissure generation. It is safer to provide these flexible joints every 15 meters for gravity dams with embankment lengths in excess of 30 meters.

The length of the joints are to be between 1 to 3 meters and is to be filled with sealing materials such as asphalt.

(4) Compacting

The concrete is to be compacted immediately after placing. When compacting with vibrators, they are to be perpendicularly inserted with less than 60 cm clearances. The concrete becomes free of cubic volume reduction when

the compacting is sufficient, and water appears on the mortar surface as well as the concrete exhibits a uniformed blend appearance.

(5) Maturing

Although it is felt as though the work is completed when the concrete placement is finished. However, maturing after the placement is also highly important since the quality of the maturing during the hardening process greatly effects the characteristics of the concrete.

The adequate maturing temperature is between 10 to 20° Celsius. Negative effects occur to the long term strength and the strength may become reduced when matured at temperatures in excess of 35° Celsius. Additionally, concrete becomes safe against congelation once a strength of about 35 kg/cm² is attained although the concrete freezes at about -3° Celsius.

The concrete does not harden and the rigidity remains low as well as the durability and the water tightness become negatively effected when the concrete surface dries. Straw mats, etc. are therefore applied as well as water is spewed to maintain the surface damp in order to prevent the surface from desiccating. Water spewing in this case should be accomplished from above the straw mats.

The wooden frames should also be thoroughly spewed at this point. Moreover, water should be spewed as well as straw mats should be applied as deemed appropriate even after the frame is removed. The maturing time for normal Portland cement is about 14 days and about 21 days for KOHRO cement or when flyash is employed.

(6) Gap-filling

This is an important work to fill the gaps generated during the excavation of the foundation and the banks. Both the foundation and the KANNYUBU of the banks are filled with concrete in case of a rockbed foundation. The foundation is filled with boulders and the KANNYUBU of the banks are filled along the original ground line with wet masonry retaining walls in case of gravel.

Diagram Gap Filling

Section 4 Bed Sill Work

1. Objective

Gravel discharge from the upstream is minimal and the streambed may become lowered or the foundations of retaining walls or other structures may become washed out in the downstream regions of streams where the upstream region is stable or where the restoration of devastation is progressed.

Therefore, structures constructed across the stream to maintain the existing streambed from lowering as well as to prevent turbulent flows and to secure the streambed siltdeposit regions are called bed sill works.

2. Cross Section

The bed sill work is structurally almost identical to a soil conservation dam. Therefore, the bed sill work section is determined in accordance with the dam section calculation. The height generally is 2 to 3 meters, and is not to be excessively protruded on the streambed. The crown width is to be about 1.0 to 1.5 meter. Additionally, the upstream gradient is to be perpendicular and the downstream gradient is to be about 2 minutes.

3. Spillway and Sleeve

The position, shape, and section of the spillway are determined in accordance with those of the dam. (in the case of the dam text?) The sleeves (SODE?) are to be thoroughly inserted into the banks in accordance with the hardness of the ground and the strength of the retaining wall since the bed sill work is often executed in the downstream (lower?) regions of the stream.

Diagram Bed Sill Work

4. Foundation

The rooting of the bed sill work foundation is to be more than 1.0 meter when the streambed is comprised of a gravel layer, and about 1.0 meter when a rockbed or large boulders exist.

5. Wash-out Prevention

Aprons are to be provided when the streambed to be applied with bed sill work is comprised of a gravel layer. The length of the apron is to be two to three times the length of the head between the overflow and the apron surface. Additionally, the thickness of the apron is to be about 0.7 to 1.0 meter. Furthermore, the downstream edge is to be provided with a vertical wall as well as side walls are to be provided on the banks of the apron when rockbeds are not exposed.

6. Clearance

The streambed length that can be secured with a single bed sill work is minimal since the bed sill work is generally low. Therefore, bed sill works are often designed in steps. In such case, the clearance is to be designed appropriately in combination with the height and the designed streambed gradient. When assuming the height of the bed sill work to be constant, the clearance may be derived by substituting the 2 of equation (5-21) as the distance.

Section 5 Revetment, Groyne, and Channel Works

1. Retaining Wall

1) Objective

Not only is the streambed but also the banks are eroded in streams. Therefore, structures constructed along the stream on the banks in order to prevent the banks from side erosion are called retaining walls.

Retaining walls are constructed in the concave sections of the banks where the discharge impact, land-creep, hillsides or possible land-creep hillsides, and the fragile sections of the banks where the dam sleeves are inserted. Additionally, retaining walls constructed in the downstream are executed in combination with the bed sill work and SUISEIKOH as the main body of the channel work in order to prevent the banks from devastation.

2) Variations

Retaining walls may be classified into concrete, concrete block, concrete frame, stone filled concrete, wet masonry, stone consolidation, cylinder, and AMISAKU depending on the structural material employed. Concrete, concrete block, and wet masonry retaining walls among the aforementioned are most commonly executed. Additionally, cylinder and AMISAKU retaining walls are executed at times in smaller streams with

minimal gravel discharge.

Diagram Concrete Retaining Wall

Concrete retaining walls are executed in areas where the soil on the hillside may move (shift?) due to the excessive dorsal pressure and when ample (positive?) safety is required. The slope gradient is generally sufficient between 3 to 5 minutes. Furthermore, although the thickness is determined in accordance with the soil pressure, slope gradient, and height, the average height is generally to be between 0.3 to 0.5 meter with the foundation broad and the crown narrow. Moreover, back filling gravel and weeping are necessary in order to minimize (relax?) the dorsal water and soil pressure.

3) Gradient Line

Curvatures are to be relaxed as much as the topography allows when determining the gradient line of reventment. Additionally, the gradient line is to be isolated away from the land creeping hillfoot to provide sedimentation areas for the fallen earth when soil falling from the hillside is expected after the execution of reventment. Both ends in the up and down stream of the reventments are to be well wrapped into the banks to preclude the discharge entry to the rear from the edges.

4) Height

The height of the reventment crown is to be 0.5 to 1.0 meter above the designed water level⁽¹⁾ so that the crown does not become overflowed by the discharge during floods. The height in the convex parts of curved flow areas are to be sufficiently high for safety since the water level elevates considerably higher than the facing bank. When designing reventment in the upstream of dams and bed sill works, they are to be erected in the same or higher heights as the crown of the wing of these structures. Additionally, the upstream parts are to be raised along the designed streambed gradient.

5) Foundation

The flow velocity increases in the vicinity of the reventment, causing the foundation to become eroded when reventment are constructed. Therefore, the reventment foundations are buried at least one meter deeper than the designated streambed height. The foundation of the reventment at the upstream junction to the side work is to be about one meter below the overflow section crown and have the same height as the sidework foundation in the downstream, and it is to be retreated from immediately below the overflow section shoulder according to the side wall.

Additionally, foundation procedures such as pile driving, GOGI?, and stepped foundation, etc. are used when the foundation is soft.

6) Scour Prevention

Rooting as well as hardening work are executed in areas in which reventment foundations are prone to become scoured by the discharge. Side works are most desirable for root hardening construction, however, rubble, wood work mattress, and various concrete blocks are used for partial scour prevention as well as for scour prevention in gentle streambed gradient areas.

2. Groyne Work

1) Objective

Groynes are structures protruding towards the center of the flow from the banks and are constructed along with reventments, etc. Objectives of this work are to:

- 1) Reduce the flow velocity in order to sediment soil.
- 2) Isolate the current from the banks to prevent erosion of the banks.
- 3) Restrict the channel width to suppress turbulent flows and drifts to prevent side erosion.

This work is generally done in places with wide streambeds

and gentle streambed gradient.

2) Variations

Groynes are segregated into perpendicular upward, and downward groyne depending on their direction of protrusion towards the center of the flow as illustrated in Diagram 5-34. These three types each possess exclusive features. Soil sedimentation occurs between the groyne, and the scour of the head is minimal with perpendicular groyne. Soil sedimentation along the banks and the groyne as well as the scour at the head of the groyne is larger for the upward groyne.

Soil sedimentation between the groyne and the scour of the head are minimal with the downward groyne. Additionally, these are further segregated into overflowing and non-overflowing groynes depending if the discharge overflows the groynes. They may also be segregated in accordance with their structural material into concrete, concrete block, wet masonry, cylinder, and wood frame types, etc.

Diagram	Groyne
1.	Perpendicular Groyne
2.	Groyne Current
3.	Upward Groyne
4.	Downward Groyne
5.	Erosion
	6. Sedimentation

3) Type Selection

The type selection is generally performed as described next. In short streambank sliding areas in the upstream, downward and non-overflowing groynes are planned in the edge of the upstream of the land creeping area in order to isolate the current from the hillfoot to prevent the land creepage from expanding. Additionally, multiple perpendicular and non-overflowing groynes are planned when land creep areas exist for an extended length along the streambank. The erosion of the facing bank should also be considered since the planning is usually performed for one of the banks in land creeping areas.

Perpendicular and non-overflowing groynes are planned for the facing banks to face each other in soil sedimentation areas with wide streambeds where the movement of gravel and erosion of the bank are excessive by the turbulent flow and drift.

4) Height

The height is generally designed so that the crown of the groyne does not become overflowed during floods. Additionally, the crown is to be provided with 1/10 to 1/15 gradient from the bank towards the center of the flow. Furthermore, the foundation of the tips are to be buried deep into the streambank in order to prevent erosion of the head.

5) Length & Clearance

The length of the groyne is to be determined upon through investigation of the channel and discharge conditions. Generally, it is designed short for wildstreams. Groynes are often provided continuously, and the clearance is to be determined with the length and direction of the groyne, the current velocity, and the streambed gradient taken into consideration. The clearance may be extended using the length of the groyne. The clearance is generally 1.5 to 2 times the length of the groyne. The clearance is reduced in the subsided bank of the curvature and is widened in the protruded bank.

3. Channel Work

1) Objective

Turbulent flows become generated during floods causing excessive side and longitudinal erosion and may cause disasters in the soil sedimentation area downstream. Therefore, the work to erect structures to protect the bank and to secure the streambed by providing a constant flow channel to such streams in order to prevent these disasters is called channel work.

2) Design

The channel work may become buried or destroyed when the work is executed in the upstream in the devastated condition. Therefore, soil conservation works are executed upstream to reduce the gravel run-off and restore the devastated land prior to the execution of this work. Furthermore, when extensive time is needed for the restoration of the devastated land or when urgency is required for the restoration of disasters, the channel work is planned by erecting a dam for soil conservation immediately upstream.

3.) Gradient

Maintain the gradient line as linear as possible when determining the gradient line of channel work. Attain the largest curvature radius possible in the event that it must be curved.

Diagram Channel Work

Additionally, refrain from connecting curves with opposing directions and provide straight sections in between.

These factors must be thoroughly followed when the gradient is increased. Furthermore, in the junction point of the main and tributary streams, the center line of these streams must be intercepted at a small angle since turbulent flows may be generated by the impact of the adjoining

currents resulting in the devastation of the banks when this angle is large.

4) Streambed Design

Stable gradient are used for the planned streambed gradient to prevent soil sedimentation as well as erosion of the streambed upon completion of the channel work. This planned streambed gradient is designed generally at about $1/2$ the original streambed gradient. The gradient may be constant from the beginning to the end of the channel work when the execution distance is short. However, the gradient must be varied where the upstream gradient is steep and becomes gentle towards the downstream when the construction distance is long. The difference between the existing and the planned streambed gradient is to be corrected with the head of the sill bed work. Multiple sill bed works with smaller heads should be designed in place of a few large headed sill bed works at this point.

5) Work Types

Sill bed work as well as triple side channel work, etc. are done as required by the condition of the stream along with the erection of reventment during channel work.

(1) Stone Removal & Excavation

Large boulders on devastated streambeds are to be removed

to determine the channel when executing channel work in accordance with the designed grading line. Additionally, the streambed soil must be excavated at times to form the designed channel section. This is done because it is safer to lower the riverbed than to erect embankments in channel work.

(2) Bed Sill Work and Bed Gindle

Bed sill works are executed (along with bed gindles at times) for the protection of the reventment as well as to prevent streambed erosion when executing channel work.

The wing of the bed sill work is to be sufficiently inserted into the ground in order to border the channel works.

This is done in order to prevent the damage to the downstream of the bed sill work in the event that a part of the channel work is destroyed. Additionally, in areas prove to large volume of sub-surface water drainage closed conduits are provided in addition to the bed sill work.

Diagram Channel Work
 (Concrete Block)

1. Concrete Overlay
2. Concrete Block

3. Back Filling
4. Front Intermediate Filling
5. Foundation Work

Bed Girdles are done with objectives identical to the aforementioned when the distance of the bed sill work is long, and may be thought of as headless bed sill work. Therefore, the crown of this work is to be aligned with the streambed during design.

(3) Triple Side Pave Channel Work

The scouring advances when the streambed starts to settle and there is a danger of reventment destruction in narrow channel streams where the reventment foundations are almost in contact with each other. In such torrents, the streambed is secured with stone and concrete along with the construction of reventments. This is called the triple side paved channel work.

CHAPTER 5 LANDCREEP PREVENTION

SECTION 1 Landcreep Investigation

Actual landslide conditions cannot be readily observed from the ground surface visually due to the cause being the generation of the sliding surface underground. Therefore, in order to achieve efficient landcreep prevention, the cause, extent, and movement conditions must be studied with the methods described in the following.

Landcreep investigations may be segregated into collection of existing data, weather research, topographic survey, geological survey, ground surface shift survey, sliding surface survey, and ground water survey.

1. Existing Data Collection

Landslide occurrence areas often have a history of land movement, since the land in such areas are moved continuously or intermittently over extended periods of time. Therefore, it is necessary to primarily study the generation dates, extent, cause, and movement speeds through local tales, etc. in order to clarify the overall landslide.

2. Weather Research

Rainfall, melting snow, earthquakes, and removal of slope bottoms are some of the known causes of landslides.

However, it is also known that landslides frequently occur

after rainfalls. Therefore, investigation of the precipitation is considered to be most important of all weather research aspects.

3. Topographic Survey

The extent and range of the landcreep may be observed on 1/25,000 or 1/50,000 scale topographical maps with exclusive creeping land features such as ununiformed contour lines, as well as increased numbers of SENMAIDA or thousand terraced fields as illustrated in diagram 6-1, swamps, and ponds. These features are also helpful in location and detection of landcreep areas where potential landcreep phenomena are not yet evident. Following to the study of the map, the following area to be investigated in the actual landcreep area.

- 1) Positions of sunken and protruded topography.
- 2) Positions, directions, length, and width of cracks.
- 3) Movement direction of the creeping land. "J.L."
- 4) Directions and positions of faults, if any.
- 5) Positions of ponds, swamps, marshland, and spring.
- 6) Positions of abnormal phenomena such as heeled houses trees as well as cracked roads, etc.

These investigation results are then inscribed into a 1/5000 scale topographical map which is to be utilized for the planning of landcreep prevention works.

4. Geological Survey

Cause and scope of the landcreep may also be estimated from detailed geological structure in vestigation since landcreep exhibit close relations with the geological structure of the topography, such as frequent generation in areas with particular types of geological structure. The following methods of survey are generally performed.

1) On - Site Survey

The overall geological structure of the subject are may be reviewed by studying the geological structure chart. However, it is further necessary to survey the run, incline, thickness, and existence of faults, etc. of the undering rock at the site of the landcreep.

2) Seismic Prospecting

This method of investigation employ the elasticity wave (earthquake wave) feature to change the transmittal speed while transmitted through the ground depending on the hardness of the geological structure.

Therefore, the geological structure is determined with the measurement of the elasticity wave transmittal speed. Furthermore, the thickness of the stratum may also be ditermined by measuring the difference in the transmittal time, for the elasticity wave transmittal time varies depending on the direct, reflected, and refracted waves

as illustrated in diagram

Diagram Elasticity Waves

- (a) Direct Wave
- (b) Reflected Wave
- (c) Refracted Wave

Survey points are to be placed in lattice form throughout the subject area when performing the investigation.

3) Electrical Prospecting

Geological structure may also be determined with this method which employs the electrical characteristic where the resistance varies in accordance with the geological structure. Actual investigations are accomplished by taking measurements of the electrical resistance (relative resistance) between two points.

This electrical resistance investigation may be segregated into horizontal investigation where the two measurement points are established horizontally, and vertical investigation where the two points are vertically established. The former of the two is suitable for the location of the distribution of ground water.

Furthermore, boring holes are used for the vertical investigation.

As with the elasticity wave investigation, survey points are to be placed in lattice form throughout the subject

area when performing the investigation.

4) Natural Radiation Measurement

Vaporized Radon and Thoron are often found to be released from through the crust faults and fractured zones when such conditions are existent. Therefore, existence of such faults and fractured zones may be determined by measuring these natural radiations.

5) Boring

This is a method where vertical holes are bored into the landcreep ground in order to obtain core samples for visual determination of the geological structure as illustrated in diagram

Accurate results may be obtained with this method.

However, though, it is necessary to employ this method in conjunction with other methods since it is highly costly, and therefore prohibitive to bore throughout the subject area.

Diagram Boring Core Samples

5. Ground Surface Shift Survey

To investigate and analyze the timing, volume, direction, and speed of the landcreep are highly useful for the prediction of landcreep generations as well as are essential data for the planning of landcreep prevention measures.

Following methods are available for the landslide movement volume investigation.

1) Surveying with Level Post

Landcreep volume may be measured with the placement of level post in the subject area and the measurements taken from them. Diagram 6-4 illustrates the placement of level post in rows and diagram 6-5 illustrates lattice form placement. Level post are to be placed throughout the subject area with the control point on immovable ground.

Diagram Row Formed Level Post Placement

(a) Immovable Point

Diagram Lattice Formed Level Post Placement

2) Expansion Meters

Landcreep volumes may be determined by measuring the survey line expansion caused by the movement of the land, with expansion meters placed in the vicinity of the landcreep area border. The expansion meter is placed on immovable ground with poles driven in the subject landcreep area, normally in the stress cracked sections of the Crown of the landcreep area with tension cracks along the movement direction.

Diagram 6-6 Expansion Meter

3) Clinometers

Methods employing level posts and expansion meters are methods where the landcreep volume is measured directly, where as the method employing the clinometer is used for estimating the landcreep volume indirectly with the change in the incline of the topography.

A pair of pneumatotubes are placed perpendicularly within the clinometer as illustrated in diagram . The movement of the bubbles within these pneumatotubes are measurable with the adjustment volume of the employing the clinometer is suitable for measuring the minimal movements of the earth caused by the landcreep.

Diagram Clinometer

6. Sliding Surface Survey

The following methods are available for accurate minet of the position of the sliding surface.

1) Investigation by Boring

This is a method where the sliding surface is determined from the boring log obtained by boring landcreep caly are generally found in the sliding surface. Boring survey lines are established in the deepest estimated

sliding surface, but is also desirable to be established beyond the landcreep area for both ends of the boring line, in order to detect the existence of the sliding surface as illustrated in diagram

Diagram Boring

- (a) Boring
- (b) Sliding Plane
- (c) Boring

2) Investigation Using Strain Meters

This is the method where the volume of strain is measured with electrical resistance strain meter placed in the vicinity of the sliding surface using the boring hole. This method is suitable for measuring slight movements, and the measurement results may be evidently observed in the form of the sliding surface position as landcreep volume methods is accumulated strain as seen in diagram

Diagram Accumulated Strain Graph

- (a) Boring Log
- (b) Depth (m)
- (c) Gauge
- (d) Cord Length
- (e) Gauge Depth
- (f) Colluvium

- (g) Weathered Sandstone/Mudstone Layer
- (h) Tuff
- (i) Sandstone/Mudstone Layer
- (j) Tuff
- (k) Debris/Tuff
- (l) Tuff
- (m) Sandstone/Mudstone Layer
- (n) Gravel/Tuff
- (o) Tuff
- (p) Data

7. Ground Water Survey

Landcreeps are often caused with ground water. This is due to the increase of sliding surface pore water pressure caused by the elevation of the ground water level resulting in the reduction of the sliding plane resistance.

The following methods are available for ground water level survey.

1) Ground Water Level Survey

Ground water levels and landslides exhibit close relations in accordance with various landcreep data. Existing wells and boring holes are used for ground water level observation.

Additionally, the water level must be observed after every rainfall. Observations are made by lowering ropes

or with the installation of a self-recording water level gauge.

2) Pore Water Pressure Gauge

Direct pore water pressure measurements may be taken with the installation of a pore water pressure gauge on the sliding surface. On the contrary, accurate pore water pressure measurements are, scarce, since accurate installation of this equipment is difficult due to the thickness of the sliding plane being generally thin, as well as by the necessity to remove the earth pressure from the top. Therefore, pore water pressure are usually described with the ground water level.

Diagram Pore Water Pressure Gauge

3) Conditions of Ground Water Flow

The following methods are available to determine the entry routes and distribution of ground water.

(1) Ground Water Level Method

The flow conditions of ground water may be investigated by drawing contour lines as illustrated in diagram with water level measurements taken from existing wells and boring holes.

Diagram Ground Water Level Countour Line Schematic

(a) → are the directions of ground water flow.

(2) Chemical Substance Application Method

Ground water routes may be determined with the application of chemical substances in the upstream for detection downstream, when ground water routes may be guessed from the topographical and geological structure conditions, etc. in the vicinity of the landslide area.

Pigment, lon, and radiation detection methods are available depending on the employed.

Section 2 Landcreep Prevention Work

1. Slope Stabilization

Slipping and sliding surfaces of slopes are generally in the form of a curve.

Therefore, these slipping and sliding surfaces are often assumed to be in the form of an arc during calculations for landcreep stabilization.

The following are the considerations for a single block taken from the landslide clod segregated into width units.

Now, with;

ABC: Sliding Surface

O : Center of the arc ABC

R : Radius

- W : Soil weight per width unit
- L : Sliding plane length width unit
- U : Pore water pressure
- θ : Angle where the B point tangent becomes horizontal
- C : Sliding surface soil cohesion
- ϕ : Internal friction angle of soil on the sliding surface

The moment of the slippage generative force becomes:

(equation)

and the slippage resistance moment become:

(equation)

Since the factor of safety is applicable for all of the blocks when the overall landcreep safety rate is F.S., it becomes:

(equation)

Therefore, the slope is stabilized when FS 1.0 and landcreep occurs when FS 1.0. W, l, and θ here are obtained on the graph, and U thru ground water investigation, as well as c and ϕ through soil arbitration.

2. Landcreep Prevention Work Plans

Landcreep prevention works are normally planned with safety rates between 1.1 - 1.2 with the methods described below.

- 1) By reducing (equation)
- 2) By increasing (equation)

The following are landcreeps prevention works segregated in accordance with aforementioned principle.

- (a) Prevention Works
- (b) Reduce M1
- (c) Increase M2
- (d) Lowering of ground water level
- (e) Increasing of the resistance with artificial structures
- (f) Dozing Work
- (g) Waterway Work
- (h) Culvert Closed Conduit
- (i) Boring Closed Conduit Work
- (j) Water Catchment Well Work
- (k) Tunnel Closed Conduit Work
- (l) Ground Water Isolation Work
- (m) Torrent Work
- (n) Retaining Work
- (o) Pile Driving Work

3. Landcreep Prevention Work

1) Dozing Work

Efficient results may be attained by removing the top of the landcfeep slopes with dozing work as illustrated in diagram 6-14. However, it is suggested that this work should be executed during the dry season in conjunction with water way works since the ground water level may elevate excessively by rainfall and surface water infiltration.

Diagram Dozing Work

- (a) HAIDO (Soil should be removed)
- (b) Sliding Surface

2) Waterway and closed Conduit Works

Landcreep slopes exhibit large numbers of tension and compression crack generations caused by the movement of the land as well as ponds and lakes where rain and surface water are often infiltrated. Therefore, it is urgently required to treat these water with waterway works. Additionally, flexible structures are employed in landcreep areas since they may be destroyed by the movement of the land.

Furthermore, closed conduit works intended for the drainage of near surface infiltration, are to be executed in conjunction with waterway works.

3) Boring Closed Conduit Work

Boring closed conduit work are executed in places where ground water are distributed widely in shallow sections of the landcreep terrain.

It is important this is case to drain the water in the upper sections of the slope as illustrated in diagram 6-15. Additionally, large drainage effects may be attained by executing the work in a radisl form through the sliding surface.

Diagram Boring Closed Conduit Work

- (a) To waterway
- (b) Ground water
- (c) 10 - 15 degree upward
- (d) Boring closed conduit
- (e) Waterway
- (f) Landcreep

4) Water Catchment Well

Water catchment wells are bored with boring applied from the sildes for the catchment of water in areas where large volumes of ground waters exist in the form of water veins. The collected water is then drained by boring. There are water catchment wells made by methods such as concrete lining and liner plate inserting.

Diagram Water Catchment Well

- (a) Drainage Boring
- (b) Water Catchment Well
- (c) Ground Water
- (d) Water Catchment Boring
- (e) Well

5) Tunnel Closed Conduit Work

Tunnel closed conduit works are executed in broad landcreep areas where abundant ground water exist in the

of the ground as illustrated in diagram 6-17. It is necessary to confirm the positions of the water veins before the execution since tunnel excavation in landcreep areas are costly and hazardous. Moreover, tunnel excavations are required to be applied within rigid immovable terrain. Ground water are collected with horizontal and vertical borings spread out from the tunnel, and are then drained through the tunnel.

Diagram Tunnel Closed Conduit Work

- (a) Tunnel Closed Conduit
- (b) Water Catchment Boring
- (c) Boring
- (d) Sliding Surface
- (e) Tunnel

6) Ground Water Isolation Work

Ground water entry into the landcreep are isolated and drained with this work as illustrated in diagram 6-18 when the flow routes of ground water are known beforehand. Burial of concrete structures and insertion of mortar as well as chemicals are some of the methods for this work.

Diagram Ground Water Isolation Work

- (a) Ground Water
- (b) Drainage beyond the area
- (c) Ground Water

7) Torrent Work

Landslides generated along torrentsides tend to become enlarged due to the falling of slopes caused by the foot attacking of run-offs. Therefore, it is necessary to protect the spurs with the execution of retaining and water regulation works. Additionally dam works are executed at times to form sediment on slope spurs in order to attain landcreep resistance effect with the sediment. Such dams are effective against minor landcreeps.

8) Retaining Work

This is a method where retaining works are applied to the end of the landcreep in order to resist the earth pressure of the slope must be performed when planning this work in order to calculate the size of the corresponding structure. Furthermore, this method is employed for minor and secondary landcreeps, for large stress cannot be expected with retaining works. Moreover, flexible structured retaining works such as cylinder and crib works are most suitable and widely used in landscreeps areas.

Diagram Torrent Work Executed in Landcreep Area

9) Pile Driving Work

Piles are driven into the landcreep ground is this work to resist the landcreep earth pressure with the resistance of the piles. It is important here that these piles be driven into immovable grounds. Additionally two or three rows of piles are normally driven in zigzag form. Positioning of the piles are highly crucial since secondary sliding surface as illustrated in diagram may be generated when the height of piles are too low or too high.

Diagram	Pile Positions
(a)	Secondary Sliding Plane
(b)	Good
(c)	Secondary Sliding Surface
(d)	Bad
(e)	Bad

The following conditions must be fulfilled when designing the pile driving work.

- 1) Piles must be able to withstand the cantilever moment.
- 2) Piles must be able to withstand the shearing stress.
- 3) Soil around the pile must not become destroyed by arbitration.
- 4) The foundation earth beneath the pile should not

become destroyed.

Steel pipe, H framed steel, reinforced concrete piles, and wood piles are the variations of piles, with steel pipes used most commonly.

JICA